

Contents

| | |
|---|-----------|
| 01 - Self-diagnosis | 1 |
| 1 Motronic self-diagnosis | 1 |
| 1.1 Motronic self-diagnosis | 1 |
| 1.2 Technical data of self-diagnosis | 1 |
| 1.3 Exhaust emissions warning lamp (MIL) in dash panel insert | 1 |
| 1.4 Checking exhaust emissions warning lamp (MIL) | 2 |
| 1.5 Safety precautions | 2 |
| 1.6 Connecting up vehicle diagnostic, testing and information system VAS 5051 and selecting functions | 2 |
| 2 Interrogating and erasing fault memory | 6 |
| 2.1 Interrogating and erasing fault memory | 6 |
| 2.2 Interrogating fault memory | 6 |
| 2.3 Erasing fault memory | 7 |
| 2.4 End of output | 8 |
| 3 Fault table (16394 to 17607) | 9 |
| 3.1 Fault table (16394 to 17607) | 9 |
| 4 Fault table (17608 to 17818) | 17 |
| 4.1 Fault table (17608 to 17818) | 17 |
| 5 Fault table (17819 to 19718) | 23 |
| 5.1 Fault table (17819 to 19718) | 23 |
| 6 Final control diagnosis | 31 |
| 6.1 Final control diagnosis | 31 |
| 7 Basic setting | 42 |
| 7.1 Basic setting | 42 |
| 8 Encoding control unit | 44 |
| 8.1 Encoding control unit | 44 |
| 8.2 Encoding table | 45 |
| 9 Reading measured value block | 47 |
| 9.1 Reading measured value block | 47 |
| 10 Encoding II | 48 |
| 10.1 Encoding II | 48 |
| 10.2 Activating/deactivating cruise control system | 49 |
| 11 Readiness code | 51 |
| 11.1 Readiness code | 51 |
| 11.2 Reading out readiness code | 52 |
| 11.3 Generating readiness code | 54 |
| 24 - Mixture preparation, Injection | 75 |
| 1 Servicing Motronic injection system | 75 |
| 1.1 Servicing Motronic injection system | 75 |
| 1.2 Safety precautions | 75 |
| 1.3 Rules for cleanliness | 75 |
| 1.4 Technical data | 76 |
| 1.5 Exploded view of fitting locations | 76 |
| 1.6 Dismantling and assembling air cleaner | 89 |
| 1.7 Replacing air mass meter oil seals | 96 |
| 1.8 Wiring and component check using test box V.A.G 1598/31 | 98 |
| 1.9 Replacing Motronic control unit -J220 | 99 |
| 1.10 Checking idling speed | 106 |
| 1.11 Checking fuel pressure regulator and holding pressure | 108 |
| 1.12 Checking injectors | 111 |
| 1.13 Dismantling and assembling fuel rail with injectors | 115 |



| | | |
|-----------|---|------------|
| 1.14 | Checking injection quantity, freedom from leaks and spray pattern of injectors | 116 |
| 1.15 | Removing and installing fuel rail | 118 |
| 1.16 | Checking fuel pump relay -J17 and actuation | 123 |
| 1.17 | Checking fuel pump control unit -J538 | 127 |
| 1.18 | Checking control unit power supply | 129 |
| 1.19 | Checking air mass meter -G70 and air mass meter 2 -G246 | 130 |
| 1.20 | Checking intake system for leaks (unmetered air) | 138 |
| 2 | Removing and installing intake manifold | 140 |
| 2.1 | Removing and installing intake manifold | 140 |
| 3 | Checking lambda control | 148 |
| 3.1 | Checking lambda control | 148 |
| 3.2 | Lambda control function | 148 |
| 3.3 | Checking lambda control and lambda probes -G39 and -G108 upstream of catalytic converter | 149 |
| 3.4 | Checking ageing of lambda probes -G39 and -G108 upstream of catalytic converter | 155 |
| 3.5 | Checking lambda control and lambda probes -G130 and -G131 downstream of catalytic converter | 159 |
| 3.6 | Checking lambda probe heating | 165 |
| 3.7 | Checking lambda probe signal wire and actuation | 168 |
| 3.8 | Removing and installing lambda probes | 174 |
| 4 | Checking fuel tank breather system | 174 |
| 4.1 | Checking fuel tank breather system | 174 |
| 4.2 | Checking activated charcoal filter system solenoid valve 1 -N80 | 174 |
| 5 | Checking electronic engine output control (electronic throttle) | 177 |
| 5.1 | Checking electronic engine output control (electronic throttle) | 177 |
| 5.2 | Functional description of electronic throttle system | 177 |
| 5.3 | Electronic power control fault lamp in dash panel insert | 178 |
| 5.4 | Checking electronic power control fault lamp -K132 | 178 |
| 5.5 | Checking throttle valve control part -J338 | 179 |
| 5.6 | Adaption of throttle valve control part | 179 |
| 5.7 | Checking throttle valve drive angle senders 1 and 2 -G187 and -G188 | 182 |
| 5.8 | Checking accelerator pedal position senders -G79 and -G185 | 185 |
| 5.9 | Kickdown function adaption | 188 |
| 5.10 | Checking brake light switch -F and brake pedal switch -F47 | 190 |
| 5.11 | Checking cruise control system (CCS) | 192 |
| 6 | Checking additional signals | 194 |
| 6.1 | Checking additional signals | 194 |
| 6.2 | Checking crash signal | 194 |
| 6.3 | Checking engine speed signal | 195 |
| 6.4 | Checking data exchange between engine control unit and connected control units | 195 |
| 28 | Ignition system | 201 |
| 1 | Checking ignition system | 201 |
| 1.1 | Checking ignition system | 201 |
| 1.2 | General notes on ignition system | 201 |
| 1.3 | Safety precautions | 201 |
| 1.4 | Ignition system technical data | 201 |
| 1.5 | Checking ignition coils | 202 |
| 1.6 | Checking ignition coil output stages | 203 |
| 1.7 | Checking Motronic current supply relay -J271 | 205 |
| 1.8 | Checking engine speed sender -G28 | 206 |
| 1.9 | Checking intake air temperature sender -G42 | 208 |
| 1.10 | Checking coolant temperature sender -G62 | 211 |
| 1.11 | Checking knock control stop | 213 |
| 1.12 | Checking knock sensors -G61, -G66 and -G198 | 216 |
| 1.13 | Checking Hall senders -G40 and -G163 | 217 |
| 1.14 | Checking misfiring recognition function | 221 |