

Contents

00 - Technical data	1
1 Engine number	1
2 Engine data	2
3 Safety precautions	3
4 General repair instructions	5
4.1 Rules for cleanliness when working on fuel supply system, injection system and turbocharger/ supercharger	5
4.2 Contact corrosion!	5
4.3 Foreign particles in engine	5
4.4 Installing radiators, condensers and charge air coolers	5
4.5 Checking vacuum system	6
4.6 Routing and attachment of pipes, hoses and wiring	6
4.7 Checking for leaks in the fuel system	6
10 - Removing and installing engine	7
1 Removing engine	7
2 Securing engine to engine and gearbox support	22
3 Installing engine	23
13 - Crankshaft group	28
1 Cylinder block (pulley end)	28
1.1 Poly V-belt drive for alternator, power steering pump and viscous fan - exploded view ..	28
1.2 Poly V-belt drive for air conditioner compressor - exploded view	30
1.3 Removing and installing poly V-belt	31
1.4 Removing and installing vibration damper	33
1.5 Removing and installing bracket for ancillaries	33
1.6 Toothed belt drive - exploded view	36
1.7 Removing and installing toothed belt	38
1.8 Detaching toothed belt from camshaft sprocket	45
1.9 Removing and installing tensioner for toothed belt	48
2 Sealing flanges and dual-mass flywheel/drive plate	52
2.1 Sealing flanges and dual-mass flywheel/drive plate - exploded view	52
2.2 Renewing crankshaft oil seal (pulley end)	54
2.3 Removing and installing sealing flange (pulley end)	56
2.4 Removing and installing dual-mass flywheel - vehicles with manual gearbox	59
2.5 Removing and installing drive plate - vehicles with automatic gearbox	61
3 Crankshaft	63
3.1 Crankshaft - exploded view	63
3.2 Crankshaft dimensions	65
3.3 Measuring axial clearance of crankshaft	65
3.4 Measuring radial clearance of crankshaft	66
3.5 Extracting and driving in needle bearing for crankshaft	67
3.6 Removing and installing chain sprocket	68
4 Pistons and conrods	71
4.1 Pistons and conrods - exploded view	71
4.2 Piston and cylinder dimensions	73
4.3 Measuring axial clearance of conrods	73
4.4 Measuring radial clearance of conrods	74
15 - Cylinder head, valve gear	75
1 Cylinder head	75
1.1 Cylinder head - exploded view	75

1.2	Removing and installing cylinder head cover	77
1.3	Removing and installing cylinder head	79
1.4	Checking compression	88
2	Intake manifold	91
2.1	Intake manifold - exploded view	91
2.2	Removing and installing intake manifold	91
3	Valve gear	95
3.1	Valve gear - exploded view	95
3.2	Checking axial clearance of camshafts	98
3.3	Renewing exhaust camshaft oil seal	99
3.4	Renewing inlet camshaft oil seal	102
3.5	Removing and installing camshafts and camshaft adjuster	105
3.6	Checking hydraulic bucket tappets	110
3.7	Renewing valve stem oil seals with cylinder head installed	111
3.8	Renewing valve stem oil seals with cylinder head removed	115
3.9	Valve dimensions	119
3.10	Checking valves	119
3.11	Checking valve guides	119
3.12	Machining valve seats	120
4	Checking variable valve timing	124
4.1	Checking inlet camshaft control valve 1 N205	124
17 - Lubrication		128
1	Sump and oil pump	128
1.1	Sump, oil pump - exploded view	128
1.2	Removing and installing oil level and oil temperature sender G266	131
1.3	Removing and installing sump	131
1.4	Removing and installing oil pump	139
2	Oil filter and oil cooler	140
2.1	Oil filter and oil cooler - exploded view	140
2.2	Removing and installing oil pressure switch F1	141
3	Engine oil	143
3.1	Checking engine oil level	143
3.2	Checking oil pressure and oil pressure switch	143
19 - Cooling		145
1	Cooling system	145
1.1	Diagram of coolant hose connections	145
1.2	Draining and filling cooling system	147
1.3	Removing and installing coolant pump	153
1.4	Removing and installing thermostat	154
1.5	Checking thermostat	156
1.6	Removing and installing coolant pipe (bottom)	157
2	Radiator and viscous fan	159
2.1	Removing and installing radiator	159
2.2	Removing and installing viscous fan	162
2.3	Removing and installing bearing for viscous fan in bracket	165
2.4	Checking cooling system for leaks	167
21 - Turbocharging/supercharging		170
1	Charge air system with turbocharger	170
1.1	Diagram of connections for charge pressure control system and vacuum system	170
1.2	Effects of leaks in charge air system	171
1.3	Checking turbocharger and charge pressure regulating valve	172
1.4	Checking mechanical air recirculation valve	175

1.5	Checking air recirculation valve for turbocharger N249	176
1.6	Checking charge pressure control solenoid valve N75	181
1.7	Checking charge pressure sender G31	184
2	Turbocharger	188
2.1	Turbocharger - exploded view	188
2.2	Removing and installing turbocharger	190
3	Charge air cooling	196
3.1	Charge air cooler - exploded view	196
3.2	Removing and installing charge air cooler	196
26	- Exhaust system	198
1	Exhaust system on vehicles with front-wheel drive	198
1.1	Silencers, catalytic converter - exploded view	198
1.2	Separating centre and rear silencers	201
1.3	Stress-free alignment of exhaust system	202
2	Exhaust system on vehicles with four-wheel drive	204
2.1	Silencers, catalytic converter - exploded view	204
2.2	Separating centre and rear silencers	207
2.3	Stress-free alignment of exhaust system	208
3	Front exhaust pipe, catalytic converter, exhaust manifold	210
3.1	Removing and installing front exhaust pipe	210
3.2	Removing and installing catalytic converter	211
3.3	Removing and installing exhaust manifold	214
3.4	Checking exhaust system for leaks	217
4	Secondary air system	218
4.1	Secondary air system - overview	218
4.2	Checking combination valve for secondary air system for proper operation and leakage ..	220
4.3	Checking secondary air inlet valve N112	221
4.4	Checking secondary air pump relay J299 and secondary air pump motor V101	226
4.5	Removing and installing combination valve for secondary air system	232