

## Contents

<b>01 - Self-diagnosis, Electrical check</b> . . . . .	<b>1</b>
<b>1 Auxiliary/additional heater self-diagnosis (type "Z/C" heaters only)</b> . . . . .	<b>1</b>
1.1 Auxiliary/additional heater self-diagnosis (type "Z/C" heaters only) . . . . .	1
1.2 Operation . . . . .	2
1.3 Technical data of self-diagnosis . . . . .	3
1.4 Test requirements for self-diagnosis . . . . .	4
1.5 Safety precautions . . . . .	4
<b>2 Modifications to auxiliary/additional heater</b> . . . . .	<b>5</b>
2.1 Modifications to auxiliary/additional heater . . . . .	5
2.2 Modifications to auxiliary/additional heater introduced in Model Year 1999 . . . . .	5
2.3 Modifications to auxiliary/additional heater introduced in Model Year 2001 . . . . .	6
<b>3 Connecting fault reader V.A.G 1551 and selecting function</b> . . . . .	<b>7</b>
3.1 Connecting fault reader V.A.G 1551 and selecting function . . . . .	7
<b>4 Interrogating fault memory of auxiliary/additional heater</b> . . . . .	<b>13</b>
4.1 Interrogating fault memory of auxiliary/additional heater . . . . .	13
<b>5 Auxiliary/additional heater fault table</b> . . . . .	<b>14</b>
5.1 Auxiliary/additional heater fault table . . . . .	14
<b>6 Auxiliary/additional heater final control diagnosis</b> . . . . .	<b>18</b>
6.1 Auxiliary/additional heater final control diagnosis . . . . .	18
<b>7 Basic setting of auxiliary/additional heater</b> . . . . .	<b>22</b>
7.1 Basic setting of auxiliary/additional heater . . . . .	22
7.2 Basic setting of auxiliary heater (adaption of battery) . . . . .	22
7.3 Basic setting of auxiliary/additional heater (switching on and off) . . . . .	26
<b>8 Erasing fault memory, end of output</b> . . . . .	<b>28</b>
8.1 Erasing fault memory, end of output . . . . .	28
<b>9 Encoding auxiliary/additional heater</b> . . . . .	<b>29</b>
9.1 Encoding auxiliary/additional heater . . . . .	29
<b>10 Reading measured value block</b> . . . . .	<b>34</b>
10.1 Reading measured value block . . . . .	34
<b>11 Adaption of auxiliary/additional heater</b> . . . . .	<b>43</b>
11.1 Adaption of auxiliary/additional heater . . . . .	43
11.2 Performing adaption (adaption channel "01", fixed value for manual undervoltage cut-out) . . . . .	44
11.3 Performing adaption (adaption channel "10", actuation as additional heater/of recirculating pump -V55) . . . . .	46
<b>12 Electrical check on auxiliary/additional heater</b> . . . . .	<b>49</b>
12.1 Electrical check on auxiliary/additional heater . . . . .	49
<b>13 Functional description of auxiliary/additional heater (heater type "Z/C")</b> . . . . .	<b>59</b>
13.1 Functional description of auxiliary/additional heater (heater type "Z/C") . . . . .	59
13.2 Required heat output between 50 and 100 % . . . . .	67
13.3 Required heat output less than 50 % . . . . .	68
<b>14 Coolant shut-off valve relay -J541</b> . . . . .	<b>69</b>
14.1 Coolant shut-off valve relay -J541 . . . . .	69
14.2 Contact assignment and operation of coolant shut-off valve relay -J541 . . . . .	70
14.3 Checking coolant shut-off valve relay -J541 . . . . .	73
<b>82 - Auxiliary heating</b> . . . . .	<b>74</b>
<b>1 Servicing auxiliary/additional heater</b> . . . . .	<b>74</b>
1.1 Servicing auxiliary/additional heater . . . . .	74
1.2 Contact corrosion . . . . .	74
1.3 Notes on auxiliary/additional heater . . . . .	74



<b>2</b>	<b>Safety precautions when working on vehicles fitted with auxiliary/additional heater</b>	<b>75</b>
2.1	Safety precautions when working on vehicles fitted with auxiliary/additional heater	75
<b>3</b>	<b>Notes on general repair work on vehicles fitted with auxiliary/additional heater</b>	<b>75</b>
3.1	Notes on general repair work on vehicles fitted with auxiliary/additional heater	75
<b>4</b>	<b>Rules for cleanliness when working on auxiliary/additional heater and fuel system</b>	<b>76</b>
4.1	Rules for cleanliness when working on auxiliary/additional heater and fuel system	76
<b>5</b>	<b>Layout of components for auxiliary/additional heater in vehicle</b>	<b>77</b>
5.1	Layout of components for auxiliary/additional heater in vehicle	77
5.2	Removing and installing coolant shut-off valve -N279	92
5.3	Display panel and controls of pre-selection clock -E111	93
5.4	Operation of heater/heat output switch -E16	95
5.5	Encoding remote control receiver for corresponding remote control unit	95
5.6	Switching auxiliary heating/auxiliary ventilation on and off via dash panel insert	97
5.7	Checking operation of remote control and auxiliary heating radio wave receiver -R64	104
5.8	Replacing remote control batteries	108
5.9	Detecting remote control faults on vehicles with pre-selection clock -E111	109
5.10	Detecting remote control faults on vehicles with no pre-selection clock -E111	110
5.11	Removing and installing pre-selection clock -E111	112
5.12	Removing and installing heater/heat output switch -E16	113
5.13	Checking power supply of pre-selection clock	114
<b>6</b>	<b>Diverting fuel for auxiliary/additional heater</b>	<b>115</b>
6.1	Diverting fuel for auxiliary/additional heater	115
6.2	Diverting fuel (for auxiliary/additional heater) from fuel tank	118
6.3	Checking fuel delivery of metering pump -V54 (heater type "S")	118
6.4	Checking fuel delivery of metering pump -V54 (heater type "Z/C")	120
6.5	Removing and installing metering pump -V54	122
6.6	Checking and adjusting CO <sub>2</sub> level in auxiliary heater exhaust gas (heater type "S")	123
<b>7</b>	<b>Checking and adjusting CO<sub>2</sub> level in auxiliary/additional heater exhaust gas for heaters of type "Z/C"</b>	<b>125</b>
7.1	Checking and adjusting CO <sub>2</sub> level in auxiliary/additional heater exhaust gas for heaters of type "Z/C"	125
7.2	Checking CO <sub>2</sub> level in auxiliary/additional heater exhaust gas (heater with recirculating pump -V55)	125
7.3	Adjusting CO <sub>2</sub> level in auxiliary/additional heater exhaust gas (heater with recirculating pump -V55)	126
7.4	Checking CO <sub>2</sub> level in additional heater exhaust gas (heater with no recirculating pump -V55)	129
7.5	Adjusting CO <sub>2</sub> level in additional heater exhaust gas (heater with no recirculating pump -V55)	130
7.6	Removing residue from burner element (operation with vegetable-oil methylester fuel only)	132
<b>8</b>	<b>Incorporation of auxiliary/additional heater into coolant circuit</b>	<b>134</b>
8.1	Incorporation of auxiliary/additional heater into coolant circuit	134
8.2	Vehicles with 8-cyl. petrol engine (up to January 2001)	135
8.3	Vehicles with 8-cyl. petrol engine (as of January 2001)	136
8.4	Vehicles with 8-cyl. diesel engine	139
8.5	Vehicles with 6-cyl. petrol engine and "large" coolant circuit	142
8.6	Vehicles with 6-cyl. petrol engine and "small" coolant circuit	144
8.7	Vehicles with 6-cyl. TDI engine	146
8.8	Vehicles with 12-cyl. engine	148
8.9	Bleeding coolant circuit	149
<b>9</b>	<b>Removing and installing auxiliary/additional heater</b>	<b>150</b>
9.1	Removing and installing auxiliary/additional heater	150
9.2	Vehicles with 6-cyl. engine or 8-cyl. petrol engine	150
9.3	Vehicles with 8-cyl. diesel engine or 12-cyl. engine	152
<b>10</b>	<b>Dismantling and assembling auxiliary heater (heater type "S")</b>	<b>154</b>
10.1	Dismantling and assembling auxiliary heater (heater type "S")	154

10.2	Dismantling and assembling bracket, exhaust system and heater	154
10.3	Dismantling and assembling auxiliary heater	156
10.4	Removing and installing central cover	160
10.5	Removing and installing glow plug and flame monitor	160
10.6	Removing and installing burner element	161
10.7	Removing and installing combustion air blower unit (with combustion air blower -V6)	161
10.8	Removing and installing recirculating pump -V55	162
<b>11</b>	<b>Dismantling and assembling auxiliary/additional heater (type "Z/C")</b>	<b>163</b>
11.1	Dismantling and assembling auxiliary/additional heater (type "Z/C")	163
11.2	Detaching exhaust system bracket from heater/re-attaching (6-cyl. engines and 8-cyl. petrol engine)	165
11.3	Detaching exhaust system bracket from heater/re-attaching (8-cyl. diesel engine and 12-cyl. engine)	169
11.4	Attaching intake hose with intake silencer	173
11.5	Detaching recirculating pump -V55 from auxiliary heater/re-attaching	174
11.6	Routing wiring to recirculating pump -V55	176
11.7	Dismantling and assembling auxiliary/additional heater	176
11.8	Removing and installing cover for connector rail	179
11.9	Assignment of auxiliary/additional heater connector rail	179
11.10	Removing and installing combustion air blower -V6	179
11.11	Removing and installing burner element	180
11.12	Removing and installing glow plug with flame monitor -Q8	181
<b>12</b>	<b>Block diagram of auxiliary heater (heater type "S")</b>	<b>183</b>
12.1	Block diagram of auxiliary heater (heater type "S")	183
<b>13</b>	<b>Block diagram of auxiliary/additional heater (type "Z/C")</b>	<b>185</b>
13.1	Block diagram of auxiliary/additional heater (type "Z/C")	185
<b>14</b>	<b>Block diagram of auxiliary heater actuation with remote control (heater type "Z/C")</b>	<b>193</b>
14.1	Block diagram of auxiliary heater actuation with remote control (heater type "Z/C")	193
14.2	Block diagram for vehicles with pre-selection clock -E111	194
14.3	Block diagram for vehicles with no pre-selection clock -E111	197
<b>15</b>	<b>Checking operation of auxiliary heater (heater type "S")</b>	<b>200</b>
15.1	Checking operation of auxiliary heater (heater type "S")	200
15.2	Checking actuation of auxiliary heater	200
15.3	Checking actuation of metering pump -V54	204
15.4	Checking electrical components of auxiliary heater	205
<b>16</b>	<b>Functional description of auxiliary heating/auxiliary ventilation mode (heater type "S")</b>	<b>211</b>
16.1	Functional description of auxiliary heating/auxiliary ventilation mode (heater type "S")	211
16.2	Functional description	212
16.3	Function chart	214
<b>17</b>	<b>Problem-specific auxiliary heater fault localisation (heater type "S")</b>	<b>217</b>
17.1	Problem-specific auxiliary heater fault localisation (heater type "S")	217
<b>18</b>	<b>Conversion of auxiliary heater to small coolant circuit (vehicles with 8-cyl. 4V petrol engine)</b>	<b>220</b>
18.1	Conversion of auxiliary heater to small coolant circuit (vehicles with 8-cyl. 4V petrol engine)	220
18.2	Conversion kits for vehicles with 8-cyl. 4V petrol engine 3.7 l / 4.2 l	221
18.3	Preparation for fitting	221
18.4	Auxiliary heater/large coolant circuit	223
18.5	Auxiliary heater/small coolant circuit	225
18.6	Installing pipe/valve holder and coolant shut-off valve -N279	228
18.7	Installing coolant hose kit	230
18.8	Electrics kit (4D0 998 147)	233
18.9	Installing electrics kit	236
18.10	Bleeding coolant circuit	242
18.11	Concluding operations	242



<b>19</b>	<b>Conversion to small coolant circuit for auxiliary heating mode (vehicles with 8-cyl. 5V petrol engine) . . . . .</b>	<b>243</b>
19.1	Conversion to small coolant circuit for auxiliary heating mode (vehicles with 8-cyl. 5V petrol engine) . . . . .	243
19.2	Conversion kits for vehicles with 8-cyl. 5V petrol engine 3.7 l / 4.2 l . . . . .	243
19.3	Preparation for fitting . . . . .	244
19.4	Auxiliary heater/large coolant circuit . . . . .	246
19.5	Auxiliary heater/small coolant circuit . . . . .	248
19.6	Installing hose kit and pipe/valve kit . . . . .	251
19.7	Electrics kit (4D0 998 147A) . . . . .	259
19.8	Installing electrics kit . . . . .	262
19.9	Bleeding coolant circuit . . . . .	271
19.10	Concluding operations . . . . .	271