

## Contents

<b>01 - Self-diagnosis</b> .....	<b>1</b>
<b>1 Self-diagnosis of Motronic system</b> .....	<b>1</b>
1.1 Self-diagnosis of Motronic system .....	1
1.2 Technical data of self-diagnosis .....	1
1.3 Safety precautions .....	1
1.4 Connecting vehicle diagnostic, testing and information system VAS 5051 or fault reader V.A.G 1551 and selecting functions .....	1
<b>2 Interrogating and erasing fault memory</b> .....	<b>4</b>
2.1 Interrogating and erasing fault memory .....	4
<b>3 Fault table (16485 to 17626)</b> .....	<b>6</b>
3.1 Fault table (16485 to 17626) .....	6
3.2 Fault table .....	6
<b>4 Fault table (17633 to 19718)</b> .....	<b>13</b>
4.1 Fault table (17633 to 19718) .....	13
<b>5 Final control diagnosis</b> .....	<b>21</b>
5.1 Final control diagnosis .....	21
<b>6 Basic setting</b> .....	<b>25</b>
6.1 Basic setting .....	25
<b>7 Encoding control unit</b> .....	<b>26</b>
7.1 Encoding control unit .....	26
7.2 Encoding table .....	27
<b>8 Reading measured value block</b> .....	<b>27</b>
8.1 Reading measured value block .....	27
<b>9 Readiness code</b> .....	<b>28</b>
9.1 Readiness code .....	28
9.2 Reading out readiness code .....	29
9.3 Generating the readiness code .....	30
<b>24 - Mixture preparation, Injection</b> .....	<b>43</b>
<b>1 Servicing Motronic injection system</b> .....	<b>43</b>
1.1 Servicing Motronic injection system .....	43
1.2 Safety precautions .....	43
1.3 Rules for cleanliness .....	43
1.4 Technical data .....	44
1.5 Fitting locations overview .....	45
1.6 Dismantling and assembling air cleaner .....	57
1.7 Removing and installing intake manifold changeover system components .....	59
1.8 Removing and installing throttle valve control part .....	61
1.9 Wiring and component check with test box V.A.G 1598/31 .....	62
1.10 Procedure following interruption of voltage supply .....	64
1.11 Replacing engine control unit .....	64
1.12 Exhaust warning lamp -K83 in dash panel insert .....	70
1.13 Checking exhaust warning lamp -K83 .....	71
1.14 Checking idling speed .....	71
1.15 Checking fuel pressure regulator and holding pressure .....	73
1.16 Checking injectors .....	76
1.17 Dismantling and assembling fuel rail with injectors .....	80
1.18 Removing and installing injectors .....	82
1.19 Checking injection quantity, leak tightness and spray pattern of injectors .....	83
1.20 Checking fuel pump relay -J17 and actuation .....	85
1.21 Checking air mass meter -G70 .....	91
1.22 Checking intake air system for leaks (unmetered air) .....	95



<b>2</b>	<b>Checking intake manifold changeover function</b>	<b>96</b>
2.1	Checking intake manifold changeover function	96
2.2	Checking function	96
2.3	Checking vacuum system for leaks	97
2.4	Checking intake manifold changeover valve -N156	99
<b>3</b>	<b>Checking lambda control</b>	<b>102</b>
3.1	Checking lambda control	102
3.2	Function of lambda control	102
3.3	Checking lambda probe and lambda control upstream of catalytic converter	103
3.4	Check lambda probe ageing of lambda probe upstream of catalytic converter	109
3.5	Check lambda probe and lambda control downstream of catalytic converter	112
3.6	Lambda probe heater for lambda probes upstream or downstream of catalytic converter	120
3.7	Removing and installing lambda probe	125
<b>4</b>	<b>Checking fuel tank breather</b>	<b>126</b>
4.1	Checking fuel tank breather	126
4.2	Checking ACF system solenoid valve 1 -N80	126
<b>5</b>	<b>Checking electronic engine power control (electronic throttle)</b>	<b>130</b>
5.1	Checking electronic engine power control (electronic throttle)	130
5.2	Function of the electronic throttle system	130
5.3	Fault lamp for electronic throttle in dash panel insert	131
5.4	Checking electronic throttle control fault lamp -K132	131
5.5	Checking throttle valve control part -J338	131
5.6	Performing adaption of throttle valve control part	132
5.7	Checking angle sender for throttle valve actuator	135
5.8	Checking accelerator position sender	138
5.9	Checking brake light switch and brake pedal switch	141
5.10	Clutch pedal switch -F36	145
<b>6</b>	<b>Checking auxiliary signals</b>	<b>148</b>
6.1	Checking auxiliary signals	148
6.2	Checking engine speed signal	149
6.3	Checking vehicle speed signal	149
6.4	Checking air conditioner compressor shut-off	150
6.5	Checking wiring for crash signal	151
6.6	Checking consumption signal for on-board computer	152
6.7	Checking fuel level signal wiring	152
6.8	Checking signal for rough-road recognition	152
6.9	Checking the data exchange between engine control unit and other CAN-control units	152
<b>7</b>	<b>Vacuum diagram</b>	<b>156</b>
7.1	Vacuum diagram	156
<b>28</b>	<b>Ignition system</b>	<b>159</b>
<b>1</b>	<b>Checking ignition system</b>	<b>159</b>
1.1	Checking ignition system	159
1.2	General notes on ignition system	159
1.3	Safety precautions	159
1.4	Technical data for ignition system	159
1.5	Removing and installing ignition system components	160
1.6	Checking ignition coils	163
1.7	Checking intake air temperature sensor -G42	167
1.8	Checking engine speed sender -G28	170
1.9	Checking coolant temperature sender -G62	172
1.10	Checking control unit power supply	175
1.11	Checking knock control stop	176
1.12	Checking knock sensors	180
1.13	Checking Hall sender	183
1.14	Checking misfire detection	187