

## Contents

<b>01 - Self-diagnosis</b> .....	<b>1</b>
<b>1 Motronic self-diagnosis</b> .....	<b>1</b>
1.1 Motronic self-diagnosis .....	1
1.2 Technical data of self-diagnosis .....	1
1.3 Connecting fault reader V.A.G 1551 and selecting engine electronics control unit .....	1
1.4 Interrogating and erasing fault memory .....	3
1.5 Fault table .....	5
1.6 Fault code numbers 00532 to 16717 .....	5
1.7 Fault code numbers 16885 to 17817 .....	14
1.8 Fault code numbers 17818 to 18101 .....	22
1.9 Final control diagnosis .....	26
1.10 Reading measured value block: List of Display Groups .....	28
1.11 Read measured value block: Display Groups 01 to 06 .....	34
1.12 Read measured value block: Display Groups 7 to 24 and 35 .....	40
1.13 Engine basic setting .....	49
1.14 Coding engine control unit .....	53
1.15 Engine control unit coding versions .....	55
<b>24 - Mixture preparation, Injection</b> .....	<b>58</b>
<b>1 Servicing Motronic fuel injection system</b> .....	<b>58</b>
1.1 Servicing Motronic fuel injection system .....	58
1.2 Safety precautions .....	58
1.3 Rules for cleanliness .....	58
1.4 Technical data .....	58
1.5 Overview of fitting locations .....	59
1.6 Overview of air intake tract with air mass meter .....	63
1.7 Overview of fuel injection tract .....	64
1.8 Overview of variable intake manifold .....	66
1.9 Connecting test box V. A .G. 1598/19 .....	68
1.10 Renewing engine control unit .....	69
1.11 Testing idling speed and CO content .....	70
1.12 Testing fuel pressure regulator and holding pressure .....	70
1.13 Testing injection rate, leakage and spray pattern of injectors .....	72
1.14 Testing injectors .....	74
1.15 Testing fuel pump relay and activation .....	77
<b>2 Testing lambda control</b> .....	<b>80</b>
2.1 Testing lambda control .....	80
2.2 Testing function of lambda control .....	80
2.3 Testing lambda probe heating .....	81
2.4 Testing lambda probe signal wire and activation .....	83
2.5 Removing and installing lambda probe .....	85
<b>3 Testing idling speed stabilisation</b> .....	<b>85</b>
3.1 Testing idling speed stabilisation .....	85
3.2 Testing function of idling speed stabilisation .....	85
3.3 Electrical testing of idling speed stabilisation valve .....	86
3.4 Testing and adjusting idling speed switch .....	88
<b>4 Testing intake manifold change-over function</b> .....	<b>90</b>
4.1 Testing intake manifold change-over function .....	90
4.2 Testing function .....	90
4.3 Testing intake manifold change-over valve .....	91
4.4 Pneumatic testing of intake manifold change-over function .....	93
<b>5 Testing tank breather system</b> .....	<b>93</b>
5.1 Testing tank breather system .....	93



5.2	Testing function . . . . .	93
5.3	Electrical testing of activated charcoal filter system solenoid valve 1 . . . . .	94
<b>6</b>	<b>Testing air control valve for injectors . . . . .</b>	<b>96</b>
6.1	Testing air control valve for injectors . . . . .	96
6.2	Electrical testing of air control valve for injectors . . . . .	98
<b>7</b>	<b>Testing control unit input variables . . . . .</b>	<b>100</b>
7.1	Testing control unit input variables . . . . .	100
7.2	Testing current supply relay for engine control unit . . . . .	100
7.3	Testing and adjusting throttle valve potentiometer . . . . .	102
7.4	Testing air mass meter . . . . .	104
7.5	Testing engine speed sender . . . . .	107
7.6	Testing coolant temperature sender . . . . .	108
7.7	Testing intake air temperature sender . . . . .	111
<b>8</b>	<b>Testing auxiliary signals . . . . .</b>	<b>113</b>
8.1	Testing auxiliary signals . . . . .	113
8.2	Testing AC compressor shut-off . . . . .	113
8.3	Testing air conditioner signal . . . . .	114
8.4	Testing rear window heater signal . . . . .	115
8.5	Testing engine speed signal for ABS/ASR . . . . .	117
8.6	Testing engine speed signal for rev counter and air conditioner . . . . .	118
8.7	Testing vehicle speed signal . . . . .	118
8.8	Testing signal from throttle valve potentiometer . . . . .	119
8.9	Testing engine speed signal for automatic gearbox . . . . .	120
8.10	Testing Motronic/gearbox torque information . . . . .	120
8.11	Testing ignition timing retard during gearshift . . . . .	121
8.12	Testing automatic gearbox selector lever position . . . . .	122
8.13	Testing data exchange between Motronic and gearbox (CAN data bus) . . . . .	124
8.14	Testing data exchange between Motronic and ABS (CAN data bus) . . . . .	125
8.15	Testing signal for ASR . . . . .	125
8.16	Testing actuation of CAT warning lamp . . . . .	126
<b>28</b>	<b>- Ignition system . . . . .</b>	<b>128</b>
<b>1</b>	<b>Technical data of ignition system . . . . .</b>	<b>128</b>
1.1	Technical data of ignition system . . . . .	128
1.2	Safety precautions . . . . .	128
1.3	Testing ignition coils . . . . .	128
1.4	Testing output stages for ignition coils . . . . .	131
1.5	Testing voltage supply to engine control unit . . . . .	133
1.6	Testing knock sensors . . . . .	134
1.7	Testing Hall sender . . . . .	136