

## Contents

<b>01 - Self-diagnosis</b> .....	<b>1</b>
<b>1 Self-diagnosis of Motronic system</b> .....	<b>1</b>
1.1 Self-diagnosis of Motronic system .....	1
1.2 Technical data of self-diagnosis .....	1
1.3 Significance of exhaust warning lamp -K83 MIL (Malfunction Indicator Lamp) .....	2
1.4 Significance of the EPC warning lamp -K132 (fault warning lamp for electronic throttle) ..	3
1.5 Connecting vehicle diagnostic, testing and information system VAS 5051 and selecting control unit for engine electronics .....	4
1.6 Connecting fault reader V.A.G 1551 and selecting engine electronics control unit .....	7
<b>2 Interrogating and erasing fault memory</b> .....	<b>9</b>
2.1 Interrogating and erasing fault memory .....	9
<b>3 Fault table (16486 to 17607)</b> .....	<b>11</b>
3.1 Fault table (16486 to 17607) .....	11
<b>4 Fault table (17609 to 18261)</b> .....	<b>17</b>
4.1 Fault table (17609 to 18261) .....	17
<b>5 Final control diagnosis</b> .....	<b>28</b>
5.1 Final control diagnosis .....	28
<b>6 Basic setting</b> .....	<b>39</b>
6.1 Basic setting .....	39
<b>7 Encoding control unit</b> .....	<b>41</b>
7.1 Encoding control unit .....	41
<b>8 Reading measured value block</b> .....	<b>43</b>
8.1 Reading measured value block .....	43
<b>9 Readiness code</b> .....	<b>44</b>
9.1 Readiness code .....	44
9.2 Reading out readiness code .....	44
9.3 Producing the readiness code .....	47
<b>24 - Mixture preparation, Injection</b> .....	<b>57</b>
<b>1 Servicing Motronic injection system</b> .....	<b>57</b>
1.1 Servicing Motronic injection system .....	57
1.2 Safety precautions .....	57
1.3 Rules for cleanliness .....	57
1.4 Technical Data (A8-models) .....	58
1.5 Technical Data (S8-models) .....	58
1.6 Fitting locations overview .....	59
1.7 Wiring and component check with test box V.A.G 1598/31 .....	65
1.8 Replacing engine control unit -J220 .....	66
1.9 Checking idling speed .....	72
1.10 Checking fuel pressure regulator and holding pressure .....	74
1.11 Testing injection quantity, leak tightness and spray pattern of injectors .....	76
1.12 Checking injectors .....	78
1.13 Checking fuel pump relay -J17 and relay actuation .....	81
1.14 Checking power supply relay for Motronic system -J271 .....	85
1.15 Checking control unit power supply .....	86
1.16 Checking air mass meter -G70 .....	88
1.17 Checking intake air temperature sender -G42 .....	92
1.18 Checking coolant temperature sender -G62 .....	93
<b>2 Checking lambda control</b> .....	<b>95</b>
2.1 Checking lambda control .....	95
2.2 Function of lambda control .....	95
2.3 Checking lambda control and lambda probe -G39 and -G108 upstream of catalytic converter .....	96



2.4	Checking lambda control and lambda probe -G39 and -G108 upstream of catalytic converter	100
2.5	Checking lambda control and lambda probe -G130 and -G131 downstream of catalytic converter	103
2.6	Checking lambda probe heating for lambda probes	108
2.7	Checking lambda probe signal wiring and actuation	111
2.8	Removing and installing lambda probes	117
<b>3</b>	<b>Checking intake manifold changeover (A8 models)</b>	<b>118</b>
3.1	Checking intake manifold changeover (A8 models)	118
3.2	Checking function	118
3.3	Checking solenoid valves -N156 and -N261 for intake manifold changeover	120
3.4	Checking vacuum system	123
<b>4</b>	<b>Checking intake manifold changeover (S8 models)</b>	<b>124</b>
4.1	Checking intake manifold changeover (S8 models)	124
4.2	Checking function	124
4.3	Checking intake manifold changeover solenoid valve -N156	125
4.4	Checking vacuum system	128
<b>5</b>	<b>Checking fuel tank breather</b>	<b>129</b>
5.1	Checking fuel tank breather	129
5.2	Checking activated charcoal filter system solenoid valve 1 -N80	129
<b>6</b>	<b>Checking secondary air inlet valve -N112</b>	<b>132</b>
6.1	Checking secondary air inlet valve -N112	132
6.2	Checking secondary air pump relay -J299	134
<b>7</b>	<b>Checking electronic engine power control (electronic throttle)</b>	<b>135</b>
7.1	Checking electronic engine power control (electronic throttle)	135
7.2	Function of the electronic throttle system	135
7.3	Checking throttle valve control part -J338	136
7.4	Performing adaption of throttle valve control part	136
7.5	Checking drive angle sender for throttle valve drive -G187 and -G188	138
<b>8</b>	<b>Checking accelerator position senders -G79 and -G185</b>	<b>140</b>
8.1	Checking accelerator position senders -G79 and -G185	140
8.2	Checking brake light switch -F or brake pedal switch -F47	143
8.3	Checking clutch pedal switch -F36	145
<b>9</b>	<b>Checking auxiliary signals</b>	<b>147</b>
9.1	Checking auxiliary signals	147
9.2	Checking crash signal	147
9.3	Checking engine speed signal	148
9.4	Testing air conditioner compressor shut-off	148
9.5	Checking engine mounting	150
9.6	Checking exchange of data between connected control units	154
<b>28</b>	<b>Ignition system</b>	<b>158</b>
<b>1</b>	<b>Checking ignition system</b>	<b>158</b>
1.1	Checking ignition system	158
1.2	General notes on ignition system	158
1.3	Safety precautions	158
1.4	Technical data for ignition system	158
1.5	Checking ignition coils	159
1.6	Checking output stages for ignition coils	160
1.7	Checking misfire detection	162
1.8	Checking engine speed sender -G28	163
1.9	Checking knock control stop	165
1.10	Checking knock sensors -G61 and -G66	165
1.11	Checking Hall senders -G40 and -G163	166
<b>2</b>	<b>Checking camshaft timing control</b>	<b>170</b>
2.1	Checking camshaft timing control	170

2.2	Function of camshaft timing control . . . . .	170
2.3	Checking solenoid valves for camshaft timing control -N205 and -N208 . . . . .	171