

Contents

87 - Air conditioning system	1
1 Safety precautions when working on vehicles fitted with an air conditioner and for handling refrigerant	1
1.1 Safety precautions	1
1.2 Draining refrigerant circuit	2
1.3 Working on refrigerant circuit	2
1.4 Painting work on vehicles fitted with an air conditioner	3
1.5 Further information	3
2 Notes on general repairs	4
2.1 Note on vehicles with auxiliary heater (poor heating output)	4
2.2 Notes on air conditioner self-diagnosis	5
2.3 Electrical checking of air conditioner components	6
3 Servicing refrigerant circuit	8
3.1 General view of components	8
3.2 Removing and installing air conditioner high-pressure sender G65	10
3.3 Checking pressure signal from high-pressure sender G65	11
3.4 O-rings for refrigerant circuit	14
3.5 Detaching compressor from holder/attaching on vehicles with 6-cyl. engine, 8-cyl. MPI engine or 8-cyl. diesel engine	15
3.6 Checking activation signal for air conditioner compressor regulating valve N280	17
4 Replacing compressor pulley	20
4.1 Replacing pulley	20
4.2 Detaching pulley from compressor/re-attaching	21
4.3 Replacing pulley	23
4.4 Detaching pulley from compressor/re-attaching	24
5 Components for control and regulation of air conditioner not located in passenger compartment	27
5.1 Components not located in passenger compartment	27
5.2 Removing and installing dust and pollen filter	33
5.3 Dust and pollen filter with activated charcoal filter element	33
5.4 Cleaning air conditioner evaporator	34
5.5 Removing and installing air quality sensor G238	37
5.6 Mode of operation of air quality sensor G238	38
5.7 Checking air quality sensor G238	39
5.8 Checking vent frame	43
5.9 Checking and cleaning plenum chamber water drain	43
5.10 Removing and installing intake housing with air flow flap	44
5.11 Removing and installing air flow flap control motor V71 with potentiometer G113	47
5.12 Preparing adapter cables for control motor actuation	49
5.13 Removing and installing fresh air intake duct temperature sensor G89	49
5.14 Removing and installing air recirculation flap control motor V113	49
5.15 Removing and installing cover with air recirculation flap	54
5.16 Removing and installing fresh air blower V2	56
5.17 Removing and installing fresh air blower control unit J126	57
5.18 Removing and installing pump valve unit	57
5.19 Operation of solar roof	62
6 Heated windscreen	65
6.1 Operation of heated windscreen	65
7 Electrical checking of components actuated by the air conditioner	67
7.1 Checking of heated rear window Z1	67
7.2 Checking of heated seats and seat ventilation	68
7.3 Checking fuel-driven supplementary heater	70

7.4	Checking electric supplementary heater for rear footwell	71
7.5	Checking actuation of heated windscreen Z2	71
8	Components for control and regulation of air conditioner located in passenger compartment	72
8.1	Components located in passenger compartment	72
8.2	Removing and installing left centre vent control motor V110	79
8.3	Removing and installing right centre vent control motor V111	82
8.4	Removing and installing centre vent temperature sender G191	82
8.5	Removing and installing sunlight penetration photosensor G107	83
8.6	Removing and installing temperature sensor blower V42	83
8.7	Removing and installing front operating and display unit, Climatronic control unit J255 ..	83
8.8	Removing and installing rear left footwell heater element Z42 / rear right footwell heater element Z43	87
8.9	Removing and installing rear left centre console temperature sensor G311 and rear right centre console temperature sensor G312	88
8.10	Removing and installing rear left vent warm air and cold air flap control motor V220	89
8.11	Removing and installing rear right vent warm air and cold air flap control motor V221 ..	91
8.12	Removing and installing rear Climatronic operating and display unit E265	91
8.13	Removing, checking and installing condensation drain hose	95
8.14	Air conditioning unit components located in passenger compartment	97
8.15	Removing and installing defroster flap control motor V107	98
8.16	Removing and installing centre vent control motor V102	100
8.17	Removing and installing front left defroster and chest vent shut-off flap control motor V200	102
8.18	Removing and installing front right defroster and chest vent shut-off flap control motor V199	104
8.19	Removing and installing left footwell flap control motor V108	106
8.20	Removing and installing right footwell flap control motor V109	108
8.21	Removing and installing temperature flap control motor V68	110
8.22	Removing and installing left vent temperature sender G150	111
8.23	Removing and installing right vent temperature sender G151	112
8.24	Removing and installing evaporator output temperature sender G263	112
8.25	Removing and installing rear left vent control motor V218 and rear right vent control motor V219	113
9	Removing and installing heat exchanger of air conditioning unit	116
9.1	Preparation for heat exchanger removal	116
9.2	Removing and installing right (front passenger side) heat exchanger	117
9.3	Removing and installing left (driver side) heat exchanger	121
10	Block diagram of air distribution system	123
10.1	Air intake and air routing in air conditioning unit	123
10.2	Air routing and air distribution in passenger compartment	125
11	Checking cooling output of air conditioner	128
11.1	Prerequisites for checking cooling output	128
11.2	Checking cooling output	129
11.3	Measures to be taken if readout does not match specification	134
11.4	Measures to be taken in the event of temperature increase downstream of evaporator ..	136
12	Checking heat output of air conditioner and operation of pump valve unit	138
12.1	Checking operation of pump valve unit	138
13	Servicing refrigerant circuit	141
13.1	Servicing refrigerant circuit	141
13.2	Detaching refrigerant lines at compressor/attaching	144
13.3	Removing and installing compressor (basic information)	146
13.4	Removing and installing compressor (on vehicles with 8-cyl. FSI engine)	147
13.5	Detaching compressor from holder/removing and installing (on vehicles with 12-cyl. engine)	155
13.6	Removing and installing compressor (on vehicles with 10-cyl. engine, Audi S8)	159

13.7	Checking/replacing compressor drive unit	167
13.8	Unfastening and tightening compressor drive shaft	168
13.9	Removing and installing compressor drive shaft	169
13.10	Detaching drive plate with overload safeguard/attaching	170
13.11	Checking concentricity of drive plate with overload safeguard/adjusting	170
13.12	Unscrewing drive plate from compressor/screwing on	171
13.13	Removing and installing drive plate with rolling bearing	172
13.14	Detaching refrigerant lines from condenser/re-attaching	172
13.15	Removing and installing condenser	174
13.16	Removing and installing restrictor	175
13.17	Removing and installing reservoir	176
13.18	Detaching refrigerant lines at evaporator connection/attaching	178
13.19	Removing and installing evaporator	180
13.20	Capacities	182
13.21	Starting up air conditioner after charging refrigerant circuit	184
14	Removing and installing air conditioning unit	186
14.1	Removing	186
14.2	Installing	187
15	Dismantling and assembling air conditioning unit	190
15.1	Removing and installing covers in plenum chamber, fresh air blower and evaporator	190
15.2	Dismantling and assembling bottom part of housing and air distribution housing	193
15.3	Dismantling and assembling air distribution housing	196