

Contents

| | |
|---|------------|
| 87 - Air conditioning system | 1 |
| 1 Safety information | 1 |
| 1.1 Safety precautions when working on air conditioners | 1 |
| 1.2 Safety precautions when handling refrigerants | 1 |
| 1.3 Safety precautions when working on vehicles with start/stop system | 2 |
| 1.4 Safety precautions when working on vehicles with high-voltage system | 2 |
| 1.5 Safety precautions when working in the vicinity of high-voltage components | 3 |
| 1.6 Safety precautions when using testers and measuring instruments during a road test | 3 |
| 2 General information on air conditioning systems | 5 |
| 2.1 Introduction | 5 |
| 2.2 Other reference material | 5 |
| 2.3 Principles of air conditioning systems | 6 |
| 2.4 Refrigerant R134a | 9 |
| 2.5 Properties of refrigerant R134a | 10 |
| 2.6 Refrigerant oil | 12 |
| 2.7 How air conditioning works | 13 |
| 2.8 General work safety | 15 |
| 2.9 Product properties | 15 |
| 2.10 Handling refrigerant | 15 |
| 2.11 Handling pressure vessels | 17 |
| 2.12 Basic rules for working on refrigerant circuit | 17 |
| 2.13 (before using air conditioner after it has been re-charged). | 20 |
| 3 General information on refrigerant circuit | 21 |
| 3.1 Components of refrigerant circuit | 21 |
| 3.2 Layout of components of refrigerant circuit and their influence on high-pressure and low-pressure sides | 21 |
| 3.3 Design of refrigerant circuit | 44 |
| 3.4 Refrigerant circuit with electrically driven air conditioner compressor | 46 |
| 3.5 Connections for quick-release coupling in refrigerant circuit | 48 |
| 3.6 Switches and senders in refrigerant circuit and related connections | 54 |
| 3.7 Electrical components not installed in refrigerant circuit | 63 |
| 3.8 Pressures and temperatures in refrigerant circuit | 64 |
| 3.9 Tests and measurements performed with pressure gauge | 69 |
| 3.10 Air conditioner service and recycling units | 70 |
| 3.11 Repair instructions for refrigerant circuit | 71 |
| 4 Laws and regulations | 73 |
| 4.1 Laws and regulations | 73 |
| 5 Refrigerant circuit | 78 |
| 5.1 Important repair instructions for air conditioning systems | 78 |
| 5.2 Converting refrigerant circuits from refrigerant R12 to refrigerant R134a | 78 |
| 5.3 Working with the air conditioner service station | 79 |
| 5.4 Blowing out refrigerant circuit with compressed air and nitrogen | 95 |
| 5.5 Cleaning (flushing) refrigerant circuit with refrigerant R134a | 99 |
| 5.6 Tracing leaks in refrigerant circuit | 174 |
| 6 Problems with refrigerant circuit | 189 |
| 6.1 Possible complaints about refrigerant circuit | 189 |
| 7 Connecting air conditioner service station | 191 |
| 7.1 Connecting air conditioner service station - vehicles with a connection on the low-pressure and high-pressure side of the refrigerant circuit | 191 |
| 7.2 Connecting air conditioner service station - vehicles with no connection on the low-pressure side of the refrigerant circuit | 192 |
| 8 Checking pressures | 196 |



| | | |
|-----------|---|------------|
| 8.1 | Checking pressures in refrigerant circuit with air conditioner service station (with ignition switched off) | 196 |
| 8.2 | Checking pressures - vehicles with restrictor and reservoir (with internally regulated air conditioner compressor) | 203 |
| 8.3 | Checking pressures - vehicles with expansion valve and receiver (with internally regulated air conditioner compressor) | 208 |
| 8.4 | Checking pressures - vehicles with restrictor, reservoir and air conditioner compressor regulating valve N280 (with externally regulated air conditioner compressor) | 213 |
| 8.5 | Checking pressures - vehicles with expansion valve, receiver and air conditioner compressor regulating valve N280 (with externally regulated air conditioner compressor) .. | 220 |
| 8.6 | Checking pressures - vehicles with electrically driven air conditioner compressor (vehicles with high-voltage system) | 232 |
| 9 | Renewing components of refrigerant circuit | 274 |
| 9.1 | Renewing components | 274 |
| 10 | Capacities for refrigerant R134a/refrigerant oil and approved refrigerant oils | 293 |
| 10.1 | Capacities for refrigerant R134a | 293 |
| 10.2 | Approved refrigerant oils and refrigerant oil capacities | 334 |
| 11 | Test equipment and tools | 380 |
| 11.1 | List of testers, tools and materials | 380 |
| 11.2 | Tools and materials available from regional sales centre or importer | 382 |
| 11.3 | Commercially available tools and materials | 386 |
| 11.4 | Improvised tools | 389 |