

Contents

01 - Self-diagnosis	1
1 Self-diagnosis	1
1.1 Self-diagnosis	1
1.2 Technical data of self-diagnosis	1
1.3 Safety precautions	1
1.4 Connecting vehicle diagnostic, testing and information system VAS 5051/ fault reader V.A.G 1551 and selecting functions	1
2 Interrogating and erasing fault memory	5
2.1 Interrogating and erasing fault memory	5
2.2 Fault table	6
3 Final control diagnosis	13
3.1 Final control diagnosis	13
3.2 Preparing differential pressure regulator for current measurement	14
3.3 Implementing final control diagnosis	15
4 Basic setting	16
4.1 Basic setting	16
5 Encoding control unit	17
5.1 Encoding control unit	17
6 Reading measured value block	18
6.1 Reading measured value block	18
7 Checking wiring of diagnostic connectors	22
7.1 Checking wiring of diagnostic connectors	22
7.2 Checking power supply for "black" diagnostic connector	23
7.3 Checking wiring between "white" diagnostic connector and engine control unit	23
7.4 Checking wiring of encoding connector	26
25 - Mixture preparation, Injection	27
1 Servicing KE Motronic injection system	27
1.1 Servicing KE Motronic injection system	27
1.2 Safety precautions	27
1.3 Rules for cleanliness	27
1.4 Technical data	28
1.5 Exploded view of fitting locations	29
1.6 Wiring and component check using test box V.A.G 1598 A	34
1.7 Replacing engine control unit	35
1.8 Checking fuel pump relay -J17 and actuation	38
1.9 Checking cold start valve -N17	43
1.10 Checking idling-speed stabilisation valve -N71	49
1.11 Checking and adjusting idling switch -F60 and full throttle switch -F81	53
1.12 Checking air-flow meter potentiometer -G19	57
1.13 Checking pressure regulator -N73	62
1.14 Basic setting of throttle valve	64
1.15 Checking intake system for leaks (unmetered air)	65
2 Servicing fuel system	66
2.1 Servicing fuel system	66
2.2 Exploded view of fuel distributor	66
2.3 Removing and installing injection system components	74
2.4 Checking idling speed, CO content and ignition point	80
2.5 Connecting remote control V.A.G 1348/3A with adapter lead V.A.G 1348/3-2	84
2.6 Connecting pressure gauge V.A.G 1318 with test adapter 1318/4	84
2.7 Checking system pressure, differential pressure and holding pressure	85
2.8 Removing and installing injectors	89
2.9 Checking injectors	90



2.10	Checking adjusting lever and control plunger	94
2.11	Checking and adjusting rest position and idle motion of sensor plate	95
2.12	Basic setting of adjusting lever	98
2.13	Removing and installing control plunger	98
2.14	Checking cold acceleration enrichment and overrun shutoff	99
2.15	Checking post-start and warm-up enrichment	101
3	Checking Lambda control	103
3.1	Checking Lambda control	103
3.2	Checking Lambda probe -G39 and Lambda control	103
3.3	Checking Lambda probe heater -Z19	105
3.4	Removing and installing Lambda probe	107
4	Checking fuel tank breather system	108
4.1	Checking fuel tank breather system	108
4.2	Checking activated charcoal filter solenoid valve -N80	108
5	Checking additional signals	113
5.1	Checking additional signals	113
5.2	Checking air-conditioner compressor shutoff	114
5.3	Checking engine-speed signal	115
5.4	Checking consumption signal for on-board computer	115
5.5	Checking vehicle-speed signal	115
6	Vacuum diagram	116
6.1	Vacuum diagram	116
28	- Ignition system	118
1	Checking ignition system	118
1.1	Checking ignition system	118
1.2	Safety precautions	118
1.3	Adjustment data, spark plugs	118
1.4	Servicing ignition system	119
1.5	Dismantling and assembling ignition distributor	124
1.6	Replacing ignition distributor rotor	125
1.7	Checking and adjusting ignition point	126
1.8	Checking ignition transformer -N152	128
1.9	Checking output stage for ignition transformer	130
1.10	Checking firing point sender -G4	134
1.11	Checking coolant temperature sender -G62	136
1.12	Checking control unit power supply	139
1.13	Checking knock sensors	142
1.14	Checking Hall sender -G40	144