

Contents

01 - Self-diagnosis	1
1 Multi Point Injection self-diagnosis	1
1.1 Multi Point Injection self-diagnosis	1
1.2 Technical data of self-diagnosis	1
1.3 Safety precautions	1
1.4 Connecting vehicle diagnostic, testing and information system VAS 5051/ fault reader V.A.G 1551 and selecting functions	1
2 Interrogating and erasing fault memory	4
2.1 Interrogating and erasing fault memory	4
2.2 Fault table	6
2.3 Fault codes 00281 - 00537	6
2.4 Fault codes 00540 - 65535	15
3 Final control diagnosis	23
3.1 Final control diagnosis	23
4 Basic setting	25
4.1 Basic setting	25
5 Encoding control unit	27
5.1 Encoding control unit	27
5.2 Encoding table	28
6 Reading measured value block	28
6.1 Reading measured value block	28
6.2 List of display groups	29
6.3 Reading measured value block: Display groups 000 to 010	32
6.4 Reading measured value block: Display groups 011 - 019	46
7 Adaption	51
7.1 Adaption	51
7.2 CO setting on vehicles with no Lambda probes	51
8 Checking wiring of diagnostic connectors	54
8.1 Checking wiring of diagnostic connectors	54
8.2 Checking power supply for "black" diagnostic connector	55
8.3 Checking wiring between "white" diagnostic connector and engine control unit	55
24 - Mixture preparation, Injection	58
1 Servicing Multi Point Injection system	58
1.1 Servicing Multi Point Injection system	58
1.2 Safety precautions	58
1.3 Rules for cleanliness	58
1.4 Technical data	59
1.5 Exploded view of fitting locations	60
1.6 Removing and installing throttle valve unit and intake-manifold changeover system components	64
1.7 Wiring and component check using test box V.A.G 1598 A	67
1.8 Replacing engine control unit	68
1.9 Checking idling speed and CO content	71
1.10 Checking system pressure, fuel pressure regulator and holding pressure	72
1.11 Checking injectors	76
1.12 Dismantling and assembling fuel rail with injectors	81
1.13 Removing and installing injectors	82
1.14 Checking injection quantity, freedom from leaks and spray pattern of injectors	84
1.15 Checking fuel pump relay -J17 and actuation	86
1.16 Checking idling-speed stabilisation valve -N71	91
1.17 Checking air-mass meter -G70	95
1.18 Checking intake system for leaks (unmetered air)	99



2	Checking intake manifold changeover	100
2.1	Checking intake manifold changeover	100
2.2	Checking operation	100
2.3	Checking vacuum system for leaks	101
2.4	Checking intake-manifold changeover valve -N156	103
3	Checking Lambda control	107
3.1	Checking Lambda control	107
3.2	Checking operation of Lambda probes	108
3.3	Checking Lambda probe heating	110
3.4	Checking Lambda probe and signal wire	113
3.5	Removing and installing Lambda probe	114
4	Checking fuel tank breather system	115
4.1	Checking fuel tank breather system	115
4.2	Checking activated charcoal filter solenoid valve -N80	116
5	Checking throttle valve potentiometer -G69	121
5.1	Checking throttle valve potentiometer -G69	121
5.2	Checking idling switch -F60	125
6	Checking exhaust gas recirculation system	129
6.1	Checking exhaust gas recirculation system	129
6.2	Checking exhaust-gas recirculation valve -N18	129
6.3	Checking mechanical EGR valve	133
6.4	Checking exhaust gas recirculation temperature sensor -G98	135
7	Checking additional signals	138
7.1	Checking additional signals	138
7.2	Checking air-conditioner compressor signal and air-conditioner compressor shutoff	138
7.3	Checking engine-speed signal	141
7.4	Checking vehicle-speed signal	142
7.5	Checking consumption signal for on-board computer	144
7.6	Checking output signal for throttle valve position	144
7.7	Checking gear signal	146
7.8	Checking ignition timing retardation on changing gear	149
8	Vacuum diagram	152
8.1	Vacuum diagram	152
8.2	Vehicles with manual gearbox and no exhaust gas recirculation	152
8.3	Vehicles with automatic gearbox and no exhaust gas recirculation	154
8.4	Vehicles with manual gearbox and exhaust gas recirculation	156
8.5	Vehicles with automatic gearbox and exhaust gas recirculation	159
28 - Ignition system	162	
1	Checking ignition system	162
1.1	Checking ignition system	162
1.2	Safety precautions	162
1.3	Technical data	162
1.4	Removing and installing ignition system components	163
1.5	Checking ignition coil-N, ignition coil 2 -N128 and ignition coil 3 -N158	166
1.6	Checking final output stage -N122	169
1.7	Checking firing point sender -G4	172
1.8	Checking engine speed sender -G28	174
1.9	Checking coolant temperature sender -G62	179
1.10	Checking control unit power supply	182
1.11	Checking knock sensors	185
1.12	Checking Hall sender -G40	188