

Contents

1	General information	1
1.1	--- Change history ---	1
1.2	General notes on Maintenance Manuals	1
1.3	Motor number	2
1.4	Vehicle identification number	2
1.5	Vehicle data sticker	2
1.6	Warnings for high-voltage vehicles	3
2	Preparations	6
2.1	Vehicle: raising	6
2.2	Noise insulation: removing and installing	7
2.3	Head-up display: checking and activating if necessary	7
2.4	Window regulators: activating automatic open/close function	8
2.5	Vehicle diagnostic tester: connecting	8
3	Maintenance	11
3.1	Event memory: reading out	14
3.2	ERA-GLONASS: checking emergency call function	15
3.3	Emergency call function: checking status LED (must be green before delivery to customer)	15
3.4	Service interval display: resetting service event	16
3.5	Diagnostic work: performing	17
3.6	Transport mode: deactivating	17
3.7	Readiness for sending and receiving information: establishing	18
3.8	Shipping mode: deactivating	19
3.9	High-voltage components: checking for damage, leaks and secure seating	19
3.10	Battery: reading out status	20
3.11	Roof insert for panoramic sliding sunroof: checking operation	21
3.12	Vehicle diagnosis: completing	21
3.13	Range calculation: resetting	21
3.14	Static event memory: working through	22
3.15	Transport mode: checking activation and activating if necessary	23
3.16	Battery: reading out status	23
3.17	Battery: checking electrolyte level	24
3.18	Battery: connecting stationary battery charger (min. 30A, charging voltage max. 14.8 V on IV characteristic curve)	26
3.19	Battery: determining and recording state of charge (SOC)	27
3.20	Mirror hanger indicating defective battery: renewing battery on affected vehicles	29
3.21	Certificate of conformity (COC): checking COC is present in vehicle	29
3.22	Connectivity box: checking emergency battery, telematics	29
3.23	Brake fluid: changing	29
3.24	Brake fluid (vehicles older than 12 months): changing	33
3.25	Brake fluid: checking fluid level	34
3.26	Brake system: checking condition of brake hoses, and checking that caps are fitted on bleeder screws	35
3.27	Brake pads: checking thickness	36
3.28	Vehicle identification numbers: checking numbers match and are embossed properly	38
3.29	Brake discs: checking for surface rust and operating brakes to clean if necessary	38
3.30	Emergency flare: fitted so it is visible from driver's seat or driver's entrance	39
3.31	Parking brake: releasing	39
3.32	Tyres: checking condition, age and wear pattern, and checking and recording tread depth	39
3.33	Tyres: checking tyre pressures and adjusting if necessary	41
3.34	Tyres (except spare wheel): checking tyre pressures and adjusting to 3.5 bar if necessary	42
3.35	Tyre Pressure Loss Indicator: storing changed tyre pressures	42
3.36	Tyre repair kit: checking that set is complete, and checking and recording expiry date	42
3.37	Wheel bolts: tightening to specified torque	43



3.38	Axles (front and rear): checking components for play, secure attachment and damage, and checking protective boots	43
3.39	Suspension struts on front and rear axle: removing locking elements and correctly fitting bump stops	48
3.40	Service disconnect: checking for dirt and damage	51
3.41	Electric drive motors, transmission unit, final drive and steering: checking for leaks and damage	51
3.42	Vehicle (from below): checking for damage	52
3.43	Water drains - panoramic sliding sunroof: checking	52
3.44	Underbody: checking trim, wheel housing liners, side members and pipes/wiring for damage, and checking that they are properly secured	53
3.45	Refrigerant R744: renewing	53
3.46	Rear axle: checking that stone deflector on track control links is undamaged and securely fitted	54
3.47	Door hinges with separate door arrester: cleaning and lubricating	54
3.48	Windscreen/rear window washer system: checking spray pattern and adjusting if necessary	55
3.49	Wiper blades: checking for damage	56
3.50	Headlight washer system: checking operation	57
3.51	Headlights: checking for correct adjustment	57
3.52	Headlights and reversing lights, brake lights, side lights, number plate lights, turn signals, hazard warning lights: checking operation	58
3.53	Luggage compartment lighting: checking operation	59
3.54	Luggage compartment: removing protective film and felt pieces	59
3.55	Glove compartment light, interior lighting and reading light: checking operation	59
3.56	Horn: checking operation	60
3.57	Passenger airbag: checking key switch on/off and setting to "on"	60
3.58	High-voltage battery: charging	60
3.59	High-voltage battery on electric vehicles and hybrid vehicles: determining and recording state of charge (SOC)	61
3.60	High-voltage battery on electric vehicles and hybrid vehicles: charging to a state of charge (SOC) of 3/4 according to manufacturer's instructions	61
3.61	High-voltage battery: checking state of charge (recommendation: approx. 80% when delivering to customer)	61
3.62	Owner's literature: checking that all documents are present	62
3.63	Service Schedule: affixing vehicle data sticker	62
3.64	Owner's Manual: attaching vehicle data sticker	62
3.65	Service Schedule: entering Delivery Inspection	62
3.66	Seat belts: checking retainers for latch plate and belt buckle, and checking locking action of automatic belt retractor	63
3.67	Vehicle interior: removing protective film (if present) and protective covers for seats	63
3.68	Vehicle interior: checking that it is clean and cleaning if necessary	63
3.69	Vehicle interior: removing any objects other than those protecting interior surfaces	64
3.70	Vehicle interior and exterior: checking for and documenting any damage	64
3.71	Instrument cluster: checking warning lamps	64
3.72	Warning triangle: checking availability	64
3.73	First-aid kit: checking and recording expiry date	64
3.74	Vehicle keys: checking operation and recording number of keys given to customer	65
3.75	Vehicle key: removing from ignition lock	65
3.76	Vehicle key(s), wheel covers and owner's literature: checking availability and recording number present	65
3.77	Sun visors: checking that they are folded up and folding up if necessary	65
3.78	Luggage compartment cover and sun blind: checking that they are rolled up and rolling up if necessary	66
3.79	Cooling system for high-voltage system: checking anti-freeze protection and coolant level, and correcting if necessary	66
3.80	Deodorising and allergen filter: renewing	69
3.81	Charging cable: checking that cable is present and complete	70
3.82	Charging system: checking that system is present and complete	70

3.83	Charging socket(s): checking for dirt and damage	71
3.84	Vehicle doors: removing edge protection	71
3.85	Vehicle exterior: checking unprotected areas for dirt, and cleaning if necessary	71
3.86	Vehicle exterior: removing protective film, if present	71
3.87	Vehicle: cleaning interior and exterior	71
3.88	Protective display films: removing if present	72
3.89	Vehicle cover: checking position and correcting if necessary	72
3.90	Vehicle cover: removing according to manufacturer's instructions	72
3.91	Paintwork, trims, side windows and wiper blades: checking cleanliness	72
3.92	Body: checking vehicle paintwork for damage and corrosion from below and with bonnet, rear lid and doors open	72
3.93	Vehicles parked outdoors: locking	72
3.94	Road test	72
3.95	Stock vehicles: observing measures specified in maintenance table for stock vehicles (see "Before handing vehicle over to customer")	73
3.96	Accessories: installing	73
3.97	"TQS – Documentation of the vehicle care" checklist: checking that list is present	74
3.98	"Stock vehicle maintenance" checklist: signing and placing in vehicle wallet	74
3.99	Cleaning and care: checking that required measures have been carried out on time	74
3.100	Stock vehicle care management: deciding and recording date of next check	74
3.101	Display instruments: setting time and date	74
3.102	Manual gearbox/automatic gearbox: selecting 1st gear/park	74
3.103	Interior mirror: calibrating compass	75
3.104	Instrument cluster: resetting driver information system	75
4	Periodic technical inspection (PTI)	76