

## Contents

<b>93</b>	<b>Electric drive systems</b>	<b>1</b>
1	<b>General warning instructions for work on the high-voltage system</b>	1
1.1	General warning instructions for work on the high-voltage system	1
1.2	Warning labels	5
2	<b>Overview of fitting locations - high-voltage components</b>	7
3	<b>Description of high-voltage technology</b>	9
3.1	Maintenance connector for high-voltage system -TW-	9
3.2	Electrical air conditioner compressor V470	9
3.3	Brake servo vacuum pump V469	9
4	<b>High-voltage battery unit</b>	11
4.1	General description - high-voltage battery unit	11
4.2	Exploded view - high-voltage battery	11
4.3	Removing and installing high-voltage battery	12
4.4	Charging high-voltage battery	19
5	<b>Power and control electronics for electric drive</b>	22
5.1	General description - power and control electronics for electric drive	22
5.2	Removing and installing power and control electronics for electric drive	23
6	<b>Electric drive motor</b>	32
6.1	General description - electric drive motor	32
6.2	Removing and installing electric drive motor	32
7	<b>High-voltage wiring</b>	36
7.1	General description - high-voltage wires	36
7.2	Overview of fitting locations - high-voltage wires	37
7.3	Identification of high-voltage wiring	37
7.4	Removing and installing high-voltage wiring harness for high-voltage battery	39
7.5	Removing and installing high-voltage wiring harness for drive motor	44
7.6	Removing and installing high-voltage wire for electrical air conditioner compressor	50
8	<b>Cooling system for high-voltage components</b>	55
8.1	General description - cooling components for high-voltage system	55
9	<b>De-energising high-voltage system</b>	56
10	<b>Re-energising high-voltage system</b>	57
11	<b>Potential equalisation lines</b>	58