

## Contents

<b>00 - Technical data</b>	<b>1</b>
<b>1 Safety information</b>	<b>1</b>
1.1 Safety precautions when working on the high-voltage system	1
1.2 Safety precautions when working in the vicinity of high-voltage components	2
1.3 Safety precautions when working on the fuel system	2
1.4 Safety precautions when working on vehicles with start/stop system	3
1.5 Safety precautions when using testers and measuring instruments during a road test	3
<b>2 Repair instructions</b>	<b>4</b>
2.1 Rules for cleanliness	4
2.2 Test conditions	4
2.3 Bleeding fuel system	5
2.4 Contact corrosion	5
2.5 Routing and attachment of pipes, hoses and wiring	5
2.6 Identification plates	5
2.7 Use of impact wrenches	5
2.8 Nuts, bolts	6
2.9 Checking fuel system for leaks	7
<b>20 - Fuel supply system</b>	<b>8</b>
<b>1 Safety information</b>	<b>8</b>
<b>2 Fuel tank</b>	<b>9</b>
2.1 Assembly overview - fuel tank	9
2.2 Draining fuel tank	16
2.3 Removing and installing fuel tank	24
<b>3 Fuel delivery unit/fuel gauge senders</b>	<b>39</b>
3.1 Assembly overview - fuel delivery unit/fuel gauge senders	39
3.2 Removing and installing fuel delivery unit/fuel gauge sender	41
3.3 Removing and installing fuel gauge sender G	47
<b>4 Plug-in connectors</b>	<b>49</b>
4.1 Disconnecting plug-in connectors	49
<b>5 Activated charcoal filter system</b>	<b>53</b>
5.1 Connection diagram - activated charcoal filter system	53
5.2 Assembly overview - activated charcoal filter system	61
5.3 Removing and installing activated charcoal filter	72
5.4 Checking fuel system for leaks	78
5.5 Operation of activated charcoal filter system	84
5.6 Operation of fuel tank leak detection - NAR, Korea and China only	85
<b>6 Accelerator mechanism</b>	<b>86</b>
6.1 Assembly overview - accelerator pedal module	86
6.2 Removing and installing accelerator pedal module with accelerator position sender G79 / G185	88
<b>7 Fuel pump</b>	<b>91</b>
7.1 Checking fuel system pressurisation pump G6	91
7.2 Removing and installing suction-jet pump	96
7.3 Removing and installing fuel pump control unit J538	96