

Contents

1	General information	1
1.1	--- Change history ---	1
1.2	General notes on Maintenance Manuals	2
1.3	Cleaning engine	2
1.4	Engine number	2
1.5	Vehicle identification number	3
1.6	Vehicle data sticker	3
2	Preparations	4
2.1	Vehicle: raising	4
2.2	Engine cover panel: removing and installing	5
2.3	Noise insulation: removing and installing	5
2.4	Window regulators: activating automatic open/close function	7
2.5	Vehicle diagnostic tester: connecting	7
3	Maintenance	10
3.1	Using vehicle protectors during maintenance and repairs	13
3.2	Event memory: reading out	13
3.3	Static event memory: working through	14
3.4	Service interval display: resetting service event	14
3.5	Transport mode: deactivating	14
3.6	Transport mode (engine): deactivating	15
3.7	Transport mode: checking activation and activating if necessary	16
3.8	Rollover bars: checking function with convertible roof open	17
3.9	Battery: reading out status	18
3.10	Connecting vehicle diagnostic tester and sending diagnostic log	19
3.11	Battery: checking electrolyte level	19
3.12	Battery: connecting stationary battery charger (min. 30A, charging voltage max. 14.8 V on IV characteristic curve)	21
3.13	Battery: determining and recording state of charge (SOC)	22
3.14	Mirror hanger indicating defective battery: renewing battery on affected vehicles	25
3.15	Data sheet for Radio Equipment Directive: printing and placing in glove compartment	25
3.16	Diagnostic work: performing	26
3.17	Vehicle identification numbers: checking numbers match and are embossed properly	26
3.18	Connectivity box: checking emergency battery, telematics	27
3.19	Brake fluid: changing	27
3.20	Brake fluid (vehicles older than 12 months): changing	31
3.21	Brake fluid: checking fluid level	31
3.22	Brake system: checking condition of brake hoses, and checking that caps are fitted on bleeder screws	32
3.23	Brake pads: checking thickness	33
3.24	Brake discs: checking for surface rust and operating brakes to clean if necessary	34
3.25	Parking brake: releasing	35
3.26	Tyres: checking condition, age and wear pattern, and checking and recording tread depth	35
3.27	Tyres: checking tyre pressures and adjusting if necessary	37
3.28	Tyres (except spare wheel): checking tyre pressures and adjusting to 3.4 bar if necessary	37
3.29	Tyre Pressure Loss Indicator: storing changed tyre pressures	38
3.30	Tyre repair kit: checking that set is complete, and checking and recording expiry date	38
3.31	Wheel bolts: tightening to specified torque	38
3.32	Suspension struts on front and rear axle: removing locking elements and correctly fitting bump stops	39
3.33	Axles (front and rear): checking components for play, secure attachment and damage, and checking protective boots	43
3.34	Engine, gearbox, final drive and steering: checking for leaks and damage	46
3.35	Vehicle (from below): checking for damage	47



3.36	Underbody: checking trim, wheel housing liners, side members and pipes/wiring for damage, and checking that they are properly secured	47
3.37	Door hinges with separate door arrester: cleaning and lubricating	47
3.38	Front lid arrester hook: lubricating	48
3.39	Front lid locks: lubricating	48
3.40	Poly V-belt for ancillaries: renewing	49
3.41	Windscreen/rear window washer system: checking spray pattern and adjusting if necessary	49
3.42	Wiper blades: checking for damage	50
3.43	Headlights: checking for correct adjustment	50
3.44	Headlights and reversing lights, brake lights, side lights, number plate lights, turn signals, hazard warning lights: checking operation	51
3.45	Luggage compartment lighting: checking operation	52
3.46	Running engine: warming up engine and exhaust system in controlled manner (avoiding revving)	52
3.47	Luggage compartment: removing protective film and felt pieces	52
3.48	Glove compartment light, interior lighting and reading light: checking operation	53
3.49	Horn: checking operation	53
3.50	Passenger airbag: checking key switch on/off and setting to "on"	53
3.51	Owner's literature: checking that all documents are present	54
3.52	Service Schedule: affixing vehicle data sticker	54
3.53	Owner's Manual: attaching vehicle data sticker	54
3.54	Service Schedule: entering Delivery Inspection	54
3.55	Seat belts: checking retainers for latch plate, and checking locking action of automatic belt retractor	55
3.56	Vehicle interior: removing protective film (if present) and protective covers for seats	55
3.57	Vehicle interior: checking that it is clean and cleaning if necessary	55
3.58	Vehicle interior: removing any objects other than those protecting interior surfaces	56
3.59	Vehicle interior and exterior: checking for and documenting any damage	56
3.60	Instrument cluster: checking warning lamps	56
3.61	Warning triangle: checking availability	56
3.62	First-aid kit: checking and recording expiry date	56
3.63	Vehicle keys: checking operation and recording number of keys given to customer	57
3.64	Vehicle key: removing from ignition lock	57
3.65	Vehicle key(s), wheel covers and owner's literature: checking availability and recording number present	57
3.66	Sun visors: checking that they are folded up and folding up if necessary	57
3.67	Luggage compartment cover and sun blind: checking that they are rolled up and rolling up if necessary	58
3.68	Engine oil: draining	58
3.69	Engine oil: renewing oil filter	59
3.70	Engine oil: filling up	62
3.71	Engine oil: checking oil level and correcting if necessary	63
3.72	Water drain for oil filler neck: checking for dirt	65
3.73	Spark plugs: renewing	66
3.74	Coolant level: checking (coolant level must reach at least top marking on coolant expansion tank)	69
3.75	Air filter: renewing filter element and cleaning housing	72
3.76	Dust and pollen filter: renewing	75
3.77	Fuel tank: adding fuel additive	77
3.78	Tank flap unit: checking seal for damage and correct seating, and checking water drain for dirt	78
3.79	Vehicle doors: removing edge protection	79
3.80	Vehicle exterior: checking unprotected areas for dirt, and cleaning if necessary	79
3.81	Vehicle exterior: removing protective film, if present	79
3.82	Vehicle cover: checking position and correcting if necessary	79
3.83	Vehicle cover: removing according to manufacturer's instructions	79
3.84	Paintwork, trims, side windows and wiper blades: checking cleanliness	79

3.85	Body: checking vehicle paintwork for damage and corrosion from below and with front lid, rear lid and doors open	79
3.86	Vehicles parked outdoors: locking	80
3.87	Road test	80
3.88	Stock vehicles: observing measures specified in maintenance table for stock vehicles (see "Before handing vehicle over to customer")	80
3.89	Accessories: installing	81
3.90	Data sheet for Radio Equipment Directive: printing and placing in glove compartment	81
3.91	Checklist "Documentation of cleaning and care routine": checking that list is present	82
3.92	"Stock vehicle maintenance" checklist: signing and placing in vehicle wallet	82
3.93	Cleaning and care: checking that required measures have been carried out on time	82
3.94	Stock vehicle care management: deciding and recording date of next check	82
3.95	Front final drive: changing gear oil	82
3.96	Display instruments: setting time and date	82
3.97	Manual gearbox/automatic gearbox: selecting 1st gear/park	82
3.98	Dual clutch gearbox (S tronic): changing ATF and renewing exchangeable ATF filter	83
3.99	All-wheel drive coupling: changing oil	83
3.100	Interior mirror: calibrating compass	83
3.101	Instrument cluster: resetting driver information system	83
4	Exhaust emissions test	84
4.1	Petrol engines: performing exhaust emissions test	84
5	Periodic technical inspection (PTI)	92