

Contents

1	General information	1
1.1	--- Change history ---	1
1.2	Engine number	1
1.3	Vehicle identification number	3
1.4	Vehicle data sticker	4
2	Preparations	5
2.1	Vehicle: raising	5
2.2	Engine cover panel: removing and installing	7
2.3	Noise insulation: removing and installing	11
2.4	Window regulators: activating automatic open/close function	14
2.5	Vehicle diagnostic tester: connecting	14
3	Maintenance	17
3.1	Diesel particulate filter: reading out ash deposit volume	19
3.2	Event memory: reading out and erasing	20
3.3	Service interval display: resetting service event	20
3.4	Transport mode: deactivating	21
3.5	Transport mode: checking activation and activating if necessary	21
3.6	Battery: reading out status and sending diagnostic log	22
3.7	Battery: checking electrolyte level	23
3.8	Battery: connecting stationary battery charging unit (min. 30A, charging voltage max. 14.8 V on IV characteristic curve)	25
3.9	Battery: determining and recording state of charge (SOC)	27
3.10	Mirror hanger indicating defective battery: renewing battery on affected vehicles	29
3.11	Brake fluid: changing	30
3.12	Brake fluid (vehicles older than 12 months): changing	35
3.13	Brake fluid: checking fluid level	35
3.14	Brake system: checking condition of brake hoses, and checking that caps are fitted on bleeder screws	36
3.15	Brake pads: checking thickness	36
3.16	Brake discs: checking for surface rust and operating brakes to clean if necessary	38
3.17	Parking brake: releasing	38
3.18	Tyres: checking condition and wear pattern, and checking and recording tread depth	38
3.19	Tyres: checking tyre pressures and adjusting if necessary	40
3.20	Tyres (except spare wheel): checking tyre pressures and adjusting to 3.5 bar if necessary	41
3.21	Tyre Pressure Loss Indicator: storing changed tyre pressures	41
3.22	Tyre repair kit: checking that set is complete, and checking and recording expiry date	42
3.23	Wheel bolts: tightening to specified torque	42
3.24	Suspension struts on front and rear axle: removing locking elements and correctly fitting bump stops	43
3.25	Axles (front and rear): checking components for play, secure attachment and damage, and checking protective boots	46
3.26	Engine, gearbox, final drive and steering: checking for leaks and damage	51
3.27	Underbody: checking trim, wheel housing liners, side members and pipes/wiring for damage, and checking that they are properly secured	51
3.28	Front lid hinges: lubricating	51
3.29	Rear spoiler hinges: lubricating	52
3.30	Bonnet arrester hook: lubricating	52
3.31	Door hinges with arresters and locking cylinders: lubricating	53
3.32	Windscreen/rear window washer system: checking spray pattern and adjusting if necessary	54
3.33	Wiper blades: checking for damage	55
3.34	Headlight washer system: checking operation	56
3.35	Headlights: checking for correct adjustment	57
3.36	Headlights and reversing lights, side lights, number plate lights, turn signals, hazard warning lights: checking operation	58

3.37	Luggage compartment lighting: checking operation	59
3.38	Glove compartment light, interior lighting and reading light: checking operation	59
3.39	Horn: checking operation	60
3.40	Passenger airbag: checking key switch on/off and setting to "on"	60
3.41	Vehicle interior: removing any objects other than those protecting interior surfaces	61
3.42	Vehicle interior and exterior: checking for and documenting any damage	61
3.43	Vehicle keys: checking operation and recording number of keys given to customer	61
3.44	Vehicle key: removing from ignition lock	61
3.45	Vehicle key(s), wheel covers and owner's literature: checking availability and recording number present	62
3.46	Sun visors: checking that they are folded up and folding up if necessary	62
3.47	Luggage compartment cover and sun blind: checking that they are rolled up and rolling up if necessary	62
3.48	Engine oil: draining	62
3.49	Engine oil: renewing oil filter	71
3.50	Engine oil: filling up	78
3.51	Engine oil: checking oil level and correcting if necessary	79
3.52	Spark plugs: renewing	81
3.53	Coolant level: checking (coolant level must reach at least top marking on coolant expansion tank)	90
3.54	Air filter: renewing filter element and cleaning housing	94
3.55	Plenum chamber and water drains: checking for dirt	104
3.56	Dust and pollen filter: renewing	106
3.57	Fuel filter: renewing	108
3.58	Fuel tank: adding fuel additive	109
3.59	Vehicle exterior: checking unprotected areas for dirt, and cleaning if necessary	110
3.60	Vehicle cover: checking position and correcting if necessary	110
3.61	Vehicle cover: removing according to manufacturer's instructions	110
3.62	Body: checking vehicle paintwork for damage and corrosion from below and with bonnet, rear lid and doors open	110
3.63	Vehicles parked outdoors: locking	110
3.64	Road test	111
3.65	Stock vehicles: observing measures specified in maintenance table for stock vehicles (see "Before handing vehicle over to customer")	111
3.66	Checklist "Documentation of cleaning and care routine": checking that list is present	112
3.67	"Stock vehicle maintenance" checklist: signing and placing in vehicle wallet	112
3.68	Cleaning and care: checking that required measures have been carried out on time	112
3.69	Stock vehicle care management: deciding and recording date of next check	112
3.70	Display instruments: setting time and date	112
3.71	Manual gearbox/automatic gearbox: selecting 1st gear/park	112
3.72	Dual clutch gearbox (S tronic): changing ATF	112
3.73	Dual clutch gearbox (S tronic): changing gear oil and renewing oil filter	113
3.74	All-wheel drive coupling: changing oil	113
3.75	Interior mirror: calibrating compass	113
3.76	Instrument cluster: resetting driver information system	113
3.77	Toothed belt for camshaft drive: renewing	113
3.78	Toothed belt for camshaft drive and tensioning roller: renewing	113
4	Exhaust emissions test	114
4.1	Petrol engines: performing exhaust emissions test	114
4.2	Diesel engines: performing exhaust emissions test	124