

Contents

01 - Self-diagnosis	1
1 Self-diagnosis of Motronic system	1
1.1 Technical data of self-diagnosis	1
1.2 Safety precautions	2
1.3 Connecting vehicle diagnostic, testing and information system VAS 5051 A	2
2 Interrogating fault memory	6
2.1 Interrogating fault memory	6
2.2 Fault tables	8
2.3 Fault tables for faults 16395 / P0011 to 17608 / P1200	8
2.4 Fault tables for faults 17621 / P1231 to 19534 / P3078	14
3 Final control diagnosis	23
4 Basic setting	27
5 Erasing fault memory	29
6 Ending output	30
7 Coding control unit	31
8 Reading measured value block	33
9 Readiness code	35
9.1 Reading out readiness code	35
9.2 Generating readiness code	37
24 - Mixture preparation - injection	48
1 Servicing Motronic injection system	48
1.1 Safety precautions	48
1.2 Rules for cleanliness	49
1.3 Overview of fitting locations	49
1.4 Dismantling and assembling air cleaner	54
1.5 Removing and installing air filter element	55
1.6 Removing and installing air mass meter G70	57
1.7 Wiring and component check with adapter cable, 121-pin V.A.G 1598/31 (test box)	58
1.8 Procedure following interruption of voltage supply	59
1.9 Removing and installing engine control unit without protective housing	59
1.10 Removing and installing engine control unit with protective housing	61
1.11 Exhaust emissions warning lamp K83 in instrument cluster	63
1.12 Checking exhaust emissions warning lamp K83	64
1.13 Checking idling speed	64
1.14 Checking system pressure, fuel pressure regulator and residual pressure	67
1.15 Checking injectors	69
1.16 Dismantling and assembling fuel rail with injectors	72
1.17 Removing and installing injectors	73
1.18 Checking injection quantity and spray pattern of injectors; checking for leaks	74
1.19 Checking fuel pump relay J17 and activation	76
1.20 Checking air mass meter G70	79
1.21 Checking intake system for leaks (unmetered air)	83
2 Checking Lambda control function	86
2.1 Checking Lambda probe and Lambda control before catalytic converter	86
2.2 Checking ageing of Lambda probe before catalytic converter	90
2.3 Checking Lambda probe heating Z19 for Lambda probe before catalytic converter	92
2.4 Checking Lambda probe and Lambda control after catalytic converter	95
2.5 Checking Lambda probe heating Z29 for Lambda probe after catalytic converter	100
2.6 Removing and installing Lambda probe	103
3 Checking fuel tank breather system	105



3.1	Checking solenoid valve 1 for activated charcoal filter N80	105
4	Checking electronic engine power control (electronic throttle)	108
4.1	Operation of electronic throttle system	108
4.2	Electronic power control fault lamp K132 in instrument cluster	108
4.3	Checking electronic power control fault lamp K132	109
4.4	Checking throttle valve module J338	109
4.5	Performing adaption of throttle valve module	110
4.6	Checking angle senders for throttle valve drive	112
4.7	Checking accelerator position senders	116
4.8	Adapting kickdown function	119
4.9	Checking brake light switch and brake pedal switch	121
4.10	Checking clutch pedal switch F36	125
5	Checking auxiliary signals	130
5.1	Checking engine speed signal	130
5.2	Checking road speed signal	131
5.3	Checking air conditioner compressor cut-out	133
5.4	Checking power assisted steering pressure switch F88	135
5.5	Checking crash signal wire	138
5.6	Checking fuel consumption signal for on-board computer	140
5.7	Checking tank level signal wire	140
6	CAN bus	141
6.1	Checking CAN bus wiring	141
7	Vacuum system layout	146
28	- Ignition system	148
1	Checking ignition system	148
1.1	Safety precautions	148
1.2	Checking ignition coils with output stages	148
1.3	Checking Motronic current supply relay J271	152
1.4	Checking intake air temperature sender G42	156
1.5	Checking engine speed sender G28	159
1.6	Checking coolant temperature sender G62	161
1.7	Checking voltage supply of engine control unit	164
1.8	Checking knock control limit	166
1.9	Checking knock sensors	168
1.10	Checking Hall sender G163	170
1.11	Checking misfiring detection	173