

## Contents

<b>01 - Self-diagnosis</b>	<b>1</b>
1 <b>Motronic self-diagnosis</b>	<b>1</b>
1.1   Technical data of self-diagnosis	1
1.2   Safety precautions	2
1.3   Connecting vehicle diagnostic, testing and information system VAS 5051 A	2
2 <b>Interrogating fault memory</b>	<b>6</b>
2.1   Interrogating fault memory	6
2.2   Fault tables	8
2.3   Fault tables for faults 16395 / P0011 to 17608 / P1200	8
2.4   Fault tables for faults 17609 / P1201 to 19534 / P3078	14
3 <b>Final control diagnosis</b>	<b>22</b>
4 <b>Basic setting</b>	<b>25</b>
5 <b>Erasing fault memory</b>	<b>27</b>
6 <b>End of output</b>	<b>28</b>
7 <b>Encoding control unit</b>	<b>29</b>
8 <b>Reading measured value block</b>	<b>31</b>
9 <b>Readiness code</b>	<b>33</b>
9.1   Reading out readiness code	33
9.2   Generating readiness code	35
<b>24 - Mixture preparation - injection</b>	<b>44</b>
1 <b>Servicing Motronic injection system</b>	<b>44</b>
1.1   Safety precautions	44
1.2   Rules for cleanliness	45
1.3   Exploded view of fitting locations	45
1.4   Dismantling and assembling air cleaner	50
1.5   Removing and installing air mass meter G70	51
1.6   Wiring and component tests with 121-pin adapter cable V.A.G 1598/31 (test box)	52
1.7   Procedure following interruption of power supply	53
1.8   Removing and installing engine control unit without protective housing	53
1.9   Removing and installing engine control unit with protective housing	54
1.10   Exhaust emissions warning lamp K83 in dash panel insert	57
1.11   Checking exhaust emissions warning lamp K83	58
1.12   Checking idling speed	58
1.13   Checking system pressure, fuel pressure regulator and residual pressure	61
1.14   Checking injectors	63
1.15   Dismantling and assembling fuel rail with injectors	66
1.16   Removing and installing injectors	67
1.17   Checking injection quantity, freedom from leaks and spray pattern of injectors	68
1.18   Checking fuel pump relay J17 and actuation	70
1.19   Checking air mass meter G70	73
1.20   Checking intake system for leaks (unmetered air)	77
2 <b>Checking lambda control</b>	<b>80</b>
2.1   Checking lambda probe and lambda control upstream of catalytic converter	80
2.2   Checking ageing of lambda probe upstream of catalytic converter	85
2.3   Checking lambda probe heater Z19 for lambda probe upstream of catalytic converter	87
2.4   Checking lambda probe and lambda control downstream of catalytic converter	89
2.5   Checking lambda probe 1 heater after catalytic converter Z29	94
2.6   Removing and installing lambda probe	97
3 <b>Checking fuel tank breather system</b>	<b>99</b>
3.1   Checking activated charcoal filter system solenoid valve 1 N80	99



<b>4</b>	<b>Checking electronic engine output control (electronic throttle)</b>	<b>102</b>
4.1	Operation of electronic throttle system	102
4.2	Electronic power control fault lamp K132 in dash panel insert	102
4.3	Checking electronic power control fault lamp K132	103
4.4	Checking throttle valve module J338	103
4.5	Adaption procedure for throttle valve module	103
4.6	Checking throttle valve for contamination and cleaning throttle valve	106
4.7	Checking throttle valve drive angle senders	108
4.8	Checking accelerator pedal position senders	112
4.9	Checking brake light switch and brake pedal switch	116
4.10	Checking clutch pedal switch F36	120
<b>5</b>	<b>Checking additional signals</b>	<b>125</b>
5.1	Checking engine speed signal	125
5.2	Checking vehicle speed signal	126
5.3	Checking air conditioner compressor shutoff	128
5.4	Checking power assisted steering pressure switch F88	130
5.5	Checking crash signal wire	133
5.6	Checking consumption signal for on-board computer	135
5.7	Checking tank level signal wire	135
<b>6</b>	<b>CAN bus</b>	<b>136</b>
6.1	Checking CAN bus wiring	136
<b>7</b>	<b>Vacuum diagram</b>	<b>141</b>
<b>28 - Ignition system</b>		<b>143</b>
<b>1</b>	<b>Checking ignition system</b>	<b>143</b>
1.1	Safety precautions	143
1.2	Checking ignition coils with output stages	143
1.3	Checking Motronic current supply relay J271	147
1.4	Checking intake air temperature sender G42	151
1.5	Checking engine speed sender G28	154
1.6	Checking coolant temperature sender G62	156
1.7	Checking engine control unit power supply	159
1.8	Checking knock control stop	161
1.9	Checking knock sensors	163
1.10	Checking Hall sender 2 G163	165
1.11	Checking misfiring detection	168