



Contents

00 - Technical data	1
1 Safety instructions	1
1.1 Safety precautions when working on air Conditioning systems	1
1.2 Safety precautions when working on vehicles with a start/stop system	1
1.3 Safety measures for working on vehicles with high voltage system	1
1.4 Safety measures when working in the vicinity of high-voltage components	2
1.5 Safety precautions when working on cooling system	2
2 General points	3
2.1 Identification plates	3
2.2 Notes concerning odours in air conditioned vehicles	4
3 Repair instructions	5
3.1 Working on refrigerant circuit	5
3.2 Cable routing and securing	5
3.3 Seals and sealing rings	6
4 Technical data	7
4.1 Filling capacities for refrigerant	7
4.2 Filling capacities for refrigerant oil	7
80 - Heating	9
1 Heating	9
87 - Air conditioning system	10
1 Fitting location overview - air conditioning system	10
1.1 Fitting location overview - components outside of passenger compartment	10
1.2 Fitting location overview - components inside of passenger compartment	14
2 Refrigerant circuit	15
2.1 System overview - refrigerant circuit	15
2.2 Removing and installing high-pressure sender G65	18
2.3 Removing and installing the expansion valve	20
2.4 Removing and installing the condenser	21
2.5 Removing and installing desiccator bag/desiccator cartridge	23
2.6 Removing and installing suction and filling valve, low and high pressure side	24
3 AC compressor	26
3.1 Summary of components - AC compressor	26
3.2 Removing and installing AC compressor	26
3.3 Remove and install Fuse 3 for high-voltage system S353	28
4 Control motors	29
4.1 Installation overview: front control motors	29
4.2 Removing and installing the control motor of temperature flap V68	31
4.3 Removing and installing the control motor of central flap V70	34
4.4 Removing and installing the dynamic pressure flap control motor V71	36
4.5 Removing and installing the defroster flap control motor V107	39
5 Heater and air conditioning unit, front	42
5.1 Summary of components - parts of the heating and air conditioning units and air intake box	42
5.2 Summary of components - evaporator housing	46
5.3 Removing and installing evaporator	48
5.4 Removing and installing evaporator temperature sensor G308	49
5.5 Removing and installing heater and air conditioning unit	50
5.6 Removing and installing dust pollen filter	56
5.7 Removing and installing the fresh air blower V2	57
5.8 Removing and installing fresh air blower control unit J126	59



5.9	Removing and installing heat exchanger	61
5.10	Removing and installing condensate water drain	61
5.11	Check condensation water drain	61
6	Air deflector	63
6.1	Summary of components - air duct and air distribution in passenger compartment	63
6.2	Removing and installing right or left vent	64
6.3	Removing and installing air guide for defroster air vent	65
6.4	Removing and installing air duct for the dash panel vents in the centre	65
6.5	Checking exhaust ventilation for passenger compartment	66
6.6	Removing and installing exhaust ventilation for passenger compartment	66
6.7	Removing and installing fresh air intake	67
7	Coolant circuit	69
7.1	Assembly overview - coolant circuit	69
7.2	Removing and installing the high-voltage heating system (PTC) Z115/control unit for high-voltage heating system (PTC) J848	69
8	Control and display unit	72
8.1	Overview - control and display unit	72
8.2	Removing and installing control and display unit	73
9	Other control components	74
9.1	removing and installing ambient temperature sensor G17	74
9.2	Removing and installing sunlight penetration photosensor G107	74
9.3	Removing and installing the ambient humidity sensor for air conditioning system G260 ..	75
9.4	Removing and installing the middle vent temperature sender G191	79
9.5	Removing and installing the Footwell vent temperature sender G192	80