



## Contents

<b>00 - Technical data</b>	<b>1</b>
<b>1 Safety information</b>	<b>1</b>
1.1 Safety measures when working on vehicles with a start/stop system	1
1.2 Safety precautions when working on high-voltage system	1
1.3 Safety precautions when working in the vicinity of high-voltage components	2
1.4 Safety precautions when working on subframe	2
<b>2 Repair instructions</b>	<b>3</b>
2.1 Leaks at shock absorbers	3
2.2 Noises from shock absorbers	3
2.3 Checking shock absorbers when removed	4
2.4 Steering rack	4
2.5 Gaskets and seals	5
2.6 Nuts and bolts	5
2.7 Electrical components	5
2.8 Raising suspension to unladen position (vehicles with coil springs)	6
<b>3 Evaluating accident vehicles</b>	<b>18</b>
3.1 Check list for evaluating running gear on accident vehicles	18
<b>4 Waste disposal</b>	<b>20</b>
4.1 Releasing gas and draining front gas-filled shock absorbers	20
4.2 Releasing gas and draining rear gas-filled shock absorbers	22
<b>40 - Front suspension</b>	<b>24</b>
<b>1 Front axle</b>	<b>24</b>
1.1 Overview of fitting locations - front axle	24
<b>2 Subframe</b>	<b>27</b>
2.1 Assembly overview – subframe	27
2.2 Removing and installing subframe without steering rack	27
2.3 Removing and installing subframe with steering rack	33
2.4 Repairing subframe	41
2.5 Repairing thread in longitudinal member	54
2.6 Fixing position of subframe	54
2.7 Lowering subframe	58
<b>3 Anti-roll bar</b>	<b>64</b>
3.1 Assembly overview - anti-roll bar	64
3.2 Removing and installing anti-roll bar	64
3.3 Removing and installing coupling rod	70
<b>4 Suspension strut, upper suspension link</b>	<b>72</b>
4.1 Assembly overview - suspension strut, upper suspension link	72
4.2 Removing and installing suspension strut	73
4.3 Repairing suspension strut	84
<b>5 Lower suspension link, swivel joint</b>	<b>89</b>
5.1 Assembly overview - lower suspension link, swivel joint	89
5.2 Removing and installing lower suspension link	90
5.3 Checking swivel joint	104
5.4 Removing and installing swivel joint	104
5.5 Renewing front bonded rubber bush for lower suspension link	109
5.6 Renewing rear bonded rubber bush for lower suspension link	113
<b>6 Wheel bearing</b>	<b>117</b>
6.1 Assembly overview - wheel bearing	117
6.2 Removing and installing wheel bearing housing	117
6.3 Removing and installing wheel bearing unit	124



<b>7</b>	<b>Drive shaft</b> .....	<b>129</b>
7.1	Overview - drive shaft .....	129
7.2	Assembly overview - drive shaft .....	130
7.3	Removing and installing drive shaft .....	136
7.4	Loosening and tightening threaded connections of drive shaft .....	158
7.5	Removing and installing drive shaft heat shield .....	159
7.6	Dismantling and assembling drive shaft .....	160
7.7	Checking outer constant velocity joint .....	184
7.8	Checking inner constant velocity joint .....	185
<b>42</b>	<b>- Rear suspension</b> .....	<b>189</b>
<b>1</b>	<b>Rear axle</b> .....	<b>189</b>
1.1	Overview - rear axle .....	189
1.2	Lowering rear axle .....	191
1.3	Removing and installing rear axle .....	201
1.4	Removing and installing shield for rear axle .....	215
<b>2</b>	<b>Subframe</b> .....	<b>217</b>
2.1	Assembly overview – subframe .....	217
2.2	Assembly overview - add-on parts for subframe .....	218
2.3	Fixing position of subframe .....	219
2.4	Repairing subframe .....	234
<b>3</b>	<b>Anti-roll bar</b> .....	<b>249</b>
3.1	Assembly overview - anti-roll bar .....	249
3.2	Removing and installing anti-roll bar .....	250
3.3	Removing and installing coupling rod .....	252
<b>4</b>	<b>Suspension link, track rod</b> .....	<b>255</b>
4.1	Assembly overview - transverse link .....	255
4.2	Assembly overview - track rod .....	259
4.3	Removing and installing upper transverse link .....	260
4.4	Removing and installing lower transverse link .....	261
4.5	Removing and installing track rod .....	263
<b>5</b>	<b>Suspension strut, shock absorber, spring</b> .....	<b>266</b>
5.1	Assembly overview - suspension strut, shock absorber, spring .....	266
5.2	Removing and installing shock absorbers .....	267
5.3	Repairing shock absorber .....	271
5.4	Removing and installing spring .....	273
<b>6</b>	<b>Wheel bearing assembly, trailing arm</b> .....	<b>281</b>
6.1	Assembly overview - wheel bearing .....	281
6.2	Assembly overview - trailing arm .....	283
6.3	Removing and installing wheel bearing housing .....	284
6.4	Removing and installing wheel bearing unit .....	296
6.5	Renewing bonded rubber bush for wheel bearing housing .....	304
6.6	Removing and installing trailing arm with mounting bracket .....	307
6.7	Repairing trailing arm .....	311
<b>7</b>	<b>Drive shaft</b> .....	<b>316</b>
7.1	Assembly overview - drive shaft .....	316
7.2	Loosening and tightening threaded connections of drive shaft .....	320
7.3	Removing and installing drive shaft .....	321
7.4	Dismantling and assembling drive shaft .....	329
7.5	Checking outer constant velocity joint .....	334
7.6	Checking inner constant velocity joint .....	336
<b>43</b>	<b>- Self-levelling suspension</b> .....	<b>339</b>
<b>1</b>	<b>Electronically controlled damping system</b> .....	<b>339</b>
1.1	Overview of fitting locations - electronically controlled damping system .....	339



1.2	Removing and installing electronically controlled damping control unit J250	341
1.3	Removing and installing front body acceleration senders G341/G342	344
1.4	Removing and installing rear left body acceleration sender G699	346
<b>2</b>	<b>Vehicle level sender</b>	<b>351</b>
2.1	Assembly overview - front vehicle level senders	351
2.2	Assembly overview - rear vehicle level senders	352
2.3	Removing and installing front vehicle level senders G78/G289	353
2.4	Removing and installing rear vehicle level senders G76/G77	355
<b>44</b>	<b>- Wheels, tyres, vehicle geometry</b>	<b>358</b>
<b>1</b>	<b>Wheel alignment</b>	<b>358</b>
1.1	Notes for wheel alignment	358
1.2	Conditions for testing	359
1.3	Test preparations	359
1.4	Specifications for wheel alignment	361
1.5	Wheel alignment procedure	364
1.6	Necessity of wheel alignment	366
1.7	Vehicle data sticker	367
1.8	Adjusting camber at front wheels	367
1.9	Adjusting camber on rear axle	369
1.10	Adjusting toe at rear axle	371
1.11	Adjusting front axle toe	371
1.12	Wheel runout compensation	373
1.13	Checking maximum wheel lock	373
<b>2</b>	<b>Adaptive cruise control</b>	<b>375</b>
2.1	Calibrating adaptive cruise control	375
<b>3</b>	<b>Front camera for assist systems</b>	<b>387</b>
3.1	Calibrating front camera for assist systems	387
<b>48</b>	<b>- Steering</b>	<b>395</b>
<b>1</b>	<b>Steering wheel</b>	<b>395</b>
1.1	Assembly overview - steering wheel	395
1.2	Removing and installing steering wheel	395
<b>2</b>	<b>Steering column</b>	<b>398</b>
2.1	Assembly overview - steering column	398
2.2	Checking steering column for damage	399
2.3	Handling and transporting steering column	400
2.4	Removing and installing steering column	401
2.5	Removing and installing control unit for electronic steering column lock J764	411
<b>3</b>	<b>Steering rack</b>	<b>414</b>
3.1	Assembly overview - steering rack	414
3.2	Removing and installing steering rack	419
3.3	Removing and installing boot	430
3.4	Removing and installing track rod	433
3.5	Removing and installing track rod ball joint	438
3.6	Repairing steering rack	440
<b>4</b>	<b>Sensors</b>	<b>445</b>
4.1	Removing and installing steering angle sender G85	445