



Contents

01 - Self-diagnosis, Electrical check	1
1 Self-diagnosis function ITT Mark 20 GI and ITT Mark 20 IE	1
1.1 Self-diagnosis function ITT Mark 20 GI and ITT Mark 20 IE	1
1.2 Function	1
1.3 Distinguishing features of ABS ITT Mark 20 GI / ITT Mark 20IE and ABS/EDL ITT Mark 20 GI / ITT Mark 20 IE	2
1.4 Technical data of self-diagnosis	3
1.5 Safety precautions and fundamental points regarding fault finding	3
1.6 Fault finding with fault reader V.A.G 1551 on ABS and ABS/EDL, ITT Mark 20 GI and ITT Mark 20 IE (flow chart)	4
2 Electrical/electronic components and fitting locations >09.99	6
2.1 Electrical/electronic components and fitting locations >09.99	6
3 Faults displayed by warning lamps K47 and K7 > 09.99	12
3.1 Faults displayed by warning lamps K47 and K7 > 09.99	12
4 Performing self diagnosis > 09.99	13
4.1 Performing self diagnosis > 09.99	13
4.2 Test prerequisites for self-diagnosis	13
4.3 Safety precautions	13
4.4 Connecting Vehicle Diagnosis, Testing and Information System VAS 5051 and selecting ABS control unit	13
4.5 Connecting fault reader V.A.G 1551 and selecting functions	14
4.6 List of selectable functions	17
4.7 Interrogating fault memory	17
4.8 Automatic test sequence	18
4.9 Fault table	19
4.10 Erasing fault memory, ending output	24
4.11 Coding control unit	25
4.12 Read measured value block	26
4.13 Final control diagnosis	29
4.14 Initiating basic setting	36
5 Electrical check of ABS, ABS/EDL ITT Mark 20 GI and ITT Mark 20 IE	41
5.1 Electrical check of ABS, ABS/EDL ITT Mark 20 GI and ITT Mark 20 IE	41
5.2 Test prerequisites	42
5.3 Multi-pin connector with contact assignment - ABS, ABS/EDL ITT Mark 20 GI (to 07.97) . .	43
5.4 Test table - ABS, ABS/EDL ITT Mark 20 GI (to 07.97)	44
5.5 Multi-pin connector with contact assignment - ABS, ABS/EDL ITT Mark 20 IE (from 08.97)	49
5.6 Test table - ABS, ABS/EDL ITT Mark 20 IE (from 08.97)	50
5.7 Adjusting brake light switch	55
6 Mark 30 IE self-diagnosis function	56
6.1 Mark 30 IE self-diagnosis function	56
6.2 Function	56
6.3 ABS Mark 30 IE allocation	56
6.4 Technical data of self-diagnosis	57
6.5 Safety precautions and fundamental points regarding fault finding	57
6.6 Fault finding with fault reader V.A.G 1551 or with tester VAS 5051 on ABS Mark 30 IE (flow chart)	58
7 Electrical/electronic components and fitting locations, Caddy 10.99 >	60
7.1 Electrical/electronic components and fitting locations, Caddy 10.99 >	60
7.2 Electrical/electronic components and fitting locations, Polo Classic, Polo Estate 10.99 > . .	65
8 Faults displayed by warning lamps K47 and K118, 10.99 >	70
8.1 Faults displayed by warning lamps K47 and K118, 10.99 >	70
9 Performing self diagnosis 10.99 >	71



9.1	Performing self diagnosis 10.99 >	71
9.2	Test prerequisites for self-diagnosis	71
9.3	Safety precautions	71
9.4	Connecting Vehicle Diagnosis, Testing and Information System VAS 5051 and selecting engine electronics control unit	72
9.5	Connecting fault reader V.A.G 1551 and selecting function	73
9.6	List of selectable functions	75
9.7	Interrogating fault memory	75
9.8	Fault table	76
9.9	Erasing fault memory, ending output	82
9.10	Coding control unit	83
9.11	Read measured value block	84
9.12	Final control diagnosis	88
9.13	Initiating basic setting	88
10	Electrical check of ABS Mark 30 IE	89
10.1	Electrical check of ABS Mark 30 IE	89
10.2	Test prerequisites	90
10.3	Multi-pin connector with contact assignment	91
10.4	Test table	93
10.5	Adjusting brake light switch	100
11	Definitions	101
11.1	Definitions	101