



Contents

01 - Self-diagnosis	1
1 General to self-diagnosis	1
1.1 General to self-diagnosis	1
1.2 Features of self-diagnosis	1
1.3 Technical data of self-diagnosis	1
1.4 Connecting fault reader V.A.G 1551 and selecting engine control unit	2
1.5 Connecting vehicle diagnosis, testing and information system VAS 5051 and selecting engine control unit	5
2 Fault memory	7
2.1 Fault memory	7
2.2 Automatic test sequence for interrogating all fault memories	8
2.3 Interrogating and erasing engine control unit fault memory	9
3 Fault table	10
3.1 Fault table	10
4 Final control diagnosis	16
4.1 Final control diagnosis	16
4.2 Performing final control diagnosis	16
5 Measured value blocks	21
5.1 Measured value blocks	21
5.2 Safety precautions	21
5.3 Read measured value block	21
6 Evaluating measured value blocks, display groups 0...5 -Basic functions-	23
6.1 Evaluating measured value blocks, display groups 0...5 -Basic functions-	23
7 Evaluating measured value blocks, display groups 6...9 -Engine speed regulation-	27
7.1 Evaluating measured value blocks, display groups 6...9 -Engine speed regulation-	27
8 Evaluating measured value blocks, display groups 10...12 -Lambda regulation-	28
8.1 Evaluating measured value blocks, display groups 10...12 -Lambda regulation-	28
9 Evaluating measured value blocks, display groups 13...18 -Ignition-	31
9.1 Evaluating measured value blocks, display groups 13...18 -Ignition-	31
10 Evaluating measured value blocks, display groups 19...99 -Operating condition-	34
10.1 Evaluating measured value blocks, display groups 19...99 -Operating condition-	34
24 - Mixture preparation, Injection	39
1 Servicing injection system	39
1.1 Servicing injection system	39
1.2 Fitting locations overview	39
1.3 General notes on injection	43
1.4 Removing and installing parts of the injection system	44
1.5 Dismantling and assembling intake manifold - Upper part	51
1.6 Dismantling and assembling fuel rail with injectors	54
1.7 Dismantling and assembling air cleaner	57
1.8 Safety precautions	59
1.9 Rules for cleanliness	59
1.10 Technical data	59
2 Checking components	60
2.1 Checking components	60
2.2 Checking Lambda probe heating	60
2.3 Checking air mass meter	63
2.4 Checking throttle valve control part	65
2.5 Checking coolant temperature sender	73
2.6 Checking intake air temperature sender	77
2.7 Checking engine speed sender	81



2.8	Checking injectors	83
2.9	Checking fuel pressure regulator and holding pressure	89
2.10	Checking intake air system for leaks (unmetered air)	92
3	Checking functions	93
3.1	Checking functions	93
3.2	Idling check	93
3.3	Checking Lambda probe and Lambda regulation	95
3.4	Checking engine operating mode	98
3.5	Checking intake manifold change-over	100
4	Engine control unit	102
4.1	Engine control unit	102
4.2	Function	102
4.3	Checking control unit voltage supply	102
4.4	Replacing engine control unit	104
4.5	Coding engine control unit	105
4.6	Coding variations of engine control unit	106
4.7	Adapting engine control unit to throttle valve control part	106
5	Checking additional signals	108
5.1	Checking additional signals	108
5.2	Testing speed signal	108
5.3	Checking engine speed signal	110
5.4	Checking signal from/to air conditioning system	111
5.5	Checking driving range signal	115
5.6	Checking signal from power steering pressure switch	117
5.7	Checking signal from clutch pedal switch	119
28	- Ignition system	123
1	Servicing ignition system	123
1.1	Servicing ignition system	123
1.2	General notes on ignition system	123
1.3	Removing and installing parts of the ignition system	124
1.4	Safety precautions	127
1.5	Test data, spark plugs	128
1.6	Checking Hall sender	128
1.7	Checking ignition transformer	130
1.8	Checking knock sensor	134