



Contents

01 - Self-diagnosis	1
1 General to self-diagnosis	1
1.1 General to self-diagnosis	1
1.2 Features of self-diagnosis	1
1.3 Technical data of self-diagnosis	1
1.4 Significance of EPC warning lamp (fault lamp for electronic accelerator) in dash panel insert	2
1.5 Significance of exhaust emissions warning lamp	3
1.6 Connecting fault reader V.A.G 1551 and selecting engine control unit	4
1.7 Connecting vehicle diagnosis, testing and information system VAS 5051 and selecting engine control unit	6
2 Fault memory	9
2.1 Fault memory	9
2.2 Automatic test sequence for interrogating all fault memories	9
2.3 Interrogating and erasing engine control unit fault memory	10
3 Fault table: SAE P0 codes	11
3.1 Fault table: SAE P0 codes	11
4 Fault table: SAE P1 codes	16
4.1 Fault table: SAE P1 codes	16
5 Final control diagnosis	25
5.1 Final control diagnosis	25
5.2 Performing final control diagnosis	25
6 Readiness code	39
6.1 Readiness code	39
6.2 Reading readiness code	40
6.3 Generating readiness code	41
7 Measured value blocks	48
7.1 Measured value blocks	48
7.2 Safety precautions	48
7.3 Read measured value block	48
8 Evaluating measured value blocks, display groups 0...9 -Basic functions-	49
8.1 Evaluating measured value blocks, display groups 0...9 -Basic functions-	49
9 Evaluating measured value blocks, display groups 10...29 -Ignition-	54
9.1 Evaluating measured value blocks, display groups 10...29 -Ignition-	54
10 Evaluating measured value blocks, display groups 30...49 -Lambda regulation-	59
10.1 Evaluating measured value blocks, display groups 30...49 -Lambda regulation-	59
11 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	63
11.1 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	63
12 Evaluating measured value blocks, display groups 70...79 -Reducing emissions-	67
12.1 Evaluating measured value blocks, display groups 70...79 -Reducing emissions-	67
13 Evaluating measured value blocks, display groups 91...95 -Performance increase-	68
13.1 Evaluating measured value blocks, display groups 91...95 -Performance increase-	68
14 Evaluating measured value blocks, display groups 120...129 -Communication-	68
14.1 Evaluating measured value blocks, display groups 120...129 -Communication-	68
24 - Mixture preparation, Injection	69
1 Servicing injection system	69
1.1 Servicing injection system	69
1.2 Fitting locations overview	69
1.3 General notes on injection	77
1.4 Removing and installing parts of the injection system	78
1.5 Dismantling and assembling intake manifold - Upper part	85



1.6	Dismantling and assembling fuel rail with injectors	88
1.7	Dismantling and assembling air cleaner	91
1.8	Safety precautions	93
1.9	Rules for cleanliness	94
1.10	Technical data	94
2	Checking components	95
2.1	Checking components	95
2.2	Checking Lambda probe heating for Lambda probe before catalyst	95
2.3	Checking Lambda probe heating for Lambda probe after catalyst	98
2.4	Checking air mass meter	102
2.5	Checking intake air temperature sender	104
2.6	Checking throttle valve control part	108
2.7	Checking coolant temperature sender	113
2.8	Checking engine speed sender	116
2.9	Checking injectors	118
2.10	Checking fuel pressure regulator and holding pressure	125
2.11	Checking intake air system for leaks (unmetered air)	128
3	Checking functions	129
3.1	Checking functions	129
3.2	Idling check	129
3.3	Checking Lambda probe and Lambda regulation before catalyst	130
3.4	Checking Lambda probe and Lambda regulation after catalyst	135
3.5	Checking engine operating mode	139
3.6	Checking intake manifold change-over	141
4	Engine control unit	143
4.1	Engine control unit	143
4.2	Function	143
4.3	Checking control unit voltage supply	143
4.4	Replacing engine control unit	145
4.5	Coding engine control unit	146
4.6	Coding variations of engine control unit	147
4.7	Erasing learnt values and adapting engine control unit to throttle valve control part and exhaust gas recirculation valve	147
5	Checking additional signals	150
5.1	Checking additional signals	150
5.2	Checking speed signal	150
5.3	Checking engine speed signal	152
5.4	Checking signal from/to air conditioning system	153
5.5	Checking signal from clutch pedal switch	157
5.6	Checking signal from brake light switch and brake pedal switch	160
5.7	Checking signal from power steering pressure switch	165
5.8	Checking starter signal	167
5.9	Checking data bus	168
28	- Ignition system	170
1	Servicing ignition system	170
1.1	Servicing ignition system	170
1.2	General notes on ignition system	170
1.3	Removing and installing parts of ignition system	171
1.4	Safety precautions	174
1.5	Test data, spark plugs	175
1.6	Checking Hall sender	175
1.7	Checking ignition transformer	177
1.8	Checking knock sensor	181
1.9	Check misfiring recognition	183