



## Contents

<b>01 - Self-diagnosis . . . . .</b>	<b>1</b>
<b>1 General to self-diagnosis . . . . .</b>	<b>1</b>
1.1 General to self-diagnosis . . . . .	1
1.2 Features of self-diagnosis . . . . .	1
1.3 Technical data of self-diagnosis . . . . .	1
1.4 Significance of EPC warning lamp (fault lamp for electronic accelerator) in dash panel insert . . . . .	2
1.5 Significance of exhaust emissions warning lamp . . . . .	3
1.6 Connecting fault reader . . . . .	4
<b>2 Fault memory . . . . .</b>	<b>7</b>
2.1 Fault memory . . . . .	7
2.2 Interrogating and erasing fault memory of engine control unit . . . . .	7
2.3 Automatic test sequence . . . . .	8
<b>3 Fault table: SAE P0 codes . . . . .</b>	<b>9</b>
3.1 Fault table: SAE P0 codes . . . . .	9
<b>4 Fault table: SAE P1 codes . . . . .</b>	<b>13</b>
4.1 Fault table: SAE P1 codes . . . . .	13
<b>5 Final control diagnosis . . . . .</b>	<b>19</b>
5.1 Final control diagnosis . . . . .	19
5.2 Performing final control diagnosis . . . . .	19
<b>6 Readiness code . . . . .</b>	<b>22</b>
6.1 Readiness code . . . . .	22
6.2 Function . . . . .	22
6.3 Reading readiness code . . . . .	22
6.4 Generating readiness code . . . . .	23
<b>7 Measured value blocks . . . . .</b>	<b>29</b>
7.1 Measured value blocks . . . . .	29
7.2 Safety precautions . . . . .	29
7.3 Read measured value block . . . . .	29
<b>8 Evaluating measured value blocks, display groups 0...9 -Basic functions- . . . . .</b>	<b>31</b>
8.1 Evaluating measured value blocks, display groups 0...9 -Basic functions- . . . . .	31
<b>9 Evaluating measured value blocks, display groups 10...29 -Ignition- . . . . .</b>	<b>34</b>
9.1 Evaluating measured value blocks, display groups 10...29 -Ignition- . . . . .	34
<b>10 Evaluating measured value blocks, display grps 30...49, 99 -Lambda regulation- . . . . .</b>	<b>38</b>
10.1 Evaluating measured value blocks, display grps 30...49, 99 -Lambda regulation- . . . . .	38
<b>11 Evaluating measured value blocks, display groups 50...69 -Speed regulation- . . . . .</b>	<b>43</b>
11.1 Evaluating measured value blocks, display groups 50...69 -Speed regulation- . . . . .	43
<b>12 Evaluating measured value blocks, display groups 70...79 -Reducing emissions- . . . . .</b>	<b>46</b>
12.1 Evaluating measured value blocks, display groups 70...79 -Reducing emissions- . . . . .	46
<b>13 Evaluating measured value blocks, display group 100 -Readiness code- . . . . .</b>	<b>47</b>
13.1 Evaluating measured value blocks, display group 100 -Readiness code- . . . . .	47
<b>24 - Mixture preparation, Injection . . . . .</b>	<b>48</b>
<b>1 Servicing injection system . . . . .</b>	<b>48</b>
1.1 Servicing injection system . . . . .	48
1.2 Fitting locations overview . . . . .	48
1.3 General notes on injection . . . . .	52
1.4 Removing and installing parts of the injection system . . . . .	53
1.5 Dismantling and assembling intake manifold . . . . .	62
1.6 Dismantling and assembling fuel rail with injectors . . . . .	65
1.7 Dismantling and assembling air cleaner . . . . .	68
1.8 Safety precautions . . . . .	72



1.9	Rules for cleanliness . . . . .	73
1.10	Technical data . . . . .	73
<b>2</b>	<b>Checking components . . . . .</b>	<b>74</b>
2.1	Checking components . . . . .	74
2.2	Checking Lambda probe heating before catalyst . . . . .	74
2.3	Checking Lambda probe heating after catalyst . . . . .	78
2.4	Checking throttle valve control part . . . . .	81
2.5	Checking intake manifold pressure sender . . . . .	84
2.6	Checking intake air temperature sender . . . . .	86
2.7	Checking coolant temperature sender . . . . .	90
2.8	Checking engine speed sender . . . . .	94
2.9	Checking injectors . . . . .	96
2.10	Checking fuel pressure regulator and holding pressure . . . . .	102
2.11	Checking intake air system for leaks (unmetered air) . . . . .	106
2.12	Checking intake air preheating . . . . .	107
2.13	Checking vacuum valve . . . . .	107
<b>3</b>	<b>Checking functions . . . . .</b>	<b>109</b>
3.1	Checking functions . . . . .	109
3.2	Idling check . . . . .	109
3.3	Checking Lambda probe and Lambda regulation before catalyst . . . . .	111
3.4	Checking Lambda probe and Lambda regulation after catalyst . . . . .	116
3.5	Checking ageing of Lambda probe before catalyst . . . . .	120
3.6	Checking engine operating mode . . . . .	121
<b>4</b>	<b>Engine control unit . . . . .</b>	<b>123</b>
4.1	Engine control unit . . . . .	123
4.2	Checking control unit voltage supply . . . . .	123
4.3	Procedure after voltage supply open circuit . . . . .	125
4.4	Replacing engine control unit . . . . .	125
4.5	Coding engine control unit . . . . .	126
4.6	Adapting engine control unit to throttle valve control part . . . . .	127
4.7	Adapting engine control unit to electronic immobilizer . . . . .	129
<b>5</b>	<b>Checking additional signals . . . . .</b>	<b>130</b>
5.1	Checking additional signals . . . . .	130
5.2	Checking speed signal . . . . .	130
5.3	Checking signal from/to air conditioning system . . . . .	132
5.4	Checking signal from brake light switch and brake pedal switch . . . . .	133
5.5	Checking rpm signal . . . . .	135
5.6	Checking matching resistor of data bus . . . . .	136
<b>28 - Ignition system . . . . .</b>	<b>138</b>	
<b>1</b>	<b>Servicing ignition system . . . . .</b>	<b>138</b>
1.1	Servicing ignition system . . . . .	138
1.2	General notes on ignition system . . . . .	138
1.3	Removing and installing parts of the ignition system . . . . .	139
1.4	Safety precautions . . . . .	142
1.5	Test data, spark plugs . . . . .	142
1.6	Checking Hall sender . . . . .	143
1.7	Checking ignition transformer . . . . .	144
1.8	Checking knock sensor . . . . .	148
1.9	Check misfiring recognition . . . . .	150