



## Contents

<b>1</b>	<b>Safety Instructions</b>	<b>1</b>
1.1	Part removal	1
1.2	Battery and welding operation	1
1.3	Electronic control unit	1
1.4	Paint, glass, soft pad and trim	2
1.5	Fuel tank or fuel delivery pipeline	2
1.6	Air conditioner	2
1.7	Airbag system	3
1.8	Check the seat belts	3
1.9	Safety specifications for the seat belt tensioner	6
1.10	Body repair on a vehicle equipped with the seat belt tensioners	6
1.11	Perform cutting off, correcting and/or levelling on a vehicle equipped with airbags	8
1.12	Remove the front seats with a side airbag	8
<b>2</b>	<b>Basic instructions</b>	<b>9</b>
2.1	Diagnosis of the accident vehicle	9
2.2	Condition of the body and/or the parts for delivery to the painting workshop	9
2.3	Correction	9
2.4	Cutting	9
2.5	Body-cut part and part section	9
2.6	Original connection	10
2.7	Galvanized body parts	10
2.8	Remove the rest part	10
2.9	New parts	10
2.10	Parts	10
2.11	Moulded foam plastic pads	11
<b>3</b>	<b>Symbolic interpretation</b>	<b>12</b>
3.1	Symbolic interpretation for welding	12
3.2	Symbolic interpretation for the operation method	12
<b>4</b>	<b>Body repair tools</b>	<b>15</b>
4.1	Flaring tool V.A.G 1317	15
4.2	Punching pliers V.A.G 1329	15
4.3	Basic equipment V.A.G 1366/3	15
4.4	Bottom protection layer spray gun V.A.G 1379	15
4.5	Electric blower V.A.G 1416	16
4.6	Door tensioner V.A.G 1438	16
4.7	Body equipment component V.A.G 1439	16
4.8	Pneumatic cutting knife V.A.G 1523 A	16
4.9	Air chisel V.A.G 1577	17
4.10	Edge closing iron block V.A.G 1585	17
4.11	Welding fume ventilator V.A.G 1586	17
4.12	Welding spot releasing device V.A.G 1731	17
4.13	Pneumatic spray gun V.A.G 1761/1	18
4.14	Pneumatic punching and thinning pliers VAS 1996	18
4.15	Pneumatic adhesive spray gun V.A.G 2005	18
4.16	Door hinge correction tool	18
4.17	Hose kit 5023 for the inert gas protection welding	19
4.18	Angle grinder VAS 5174	19
4.19	Angle grinder VAS 5175	19
4.20	Wire brush VAS 5182	19
<b>5</b>	<b>Body bonding</b>	<b>20</b>
5.1	Transporter 1991 →	20
5.2	Bonding types	20
5.3	Repair method for replacing the parts	21



<b>6</b>	<b>Corrosion protection measures</b>	<b>22</b>
6.1	Corrosion protection	22
<b>7</b>	<b>Waste disposal instructions</b>	<b>23</b>
7.1	Waste disposal	23
7.2	Air pressure tappet exhaust	24
7.3	Airbag	24
<b>8</b>	<b>Contact corrosion protection</b>	<b>25</b>
8.1	Connection of aluminium alloy/magnesium alloy with steel	25
<b>9</b>	<b>Steel plate repair</b>	<b>26</b>
9.1	High-strength body plate	26
9.2	Galvanized body parts	26
9.3	Welding on the galvanized body steel plate	27
9.4	Tearing test	28
<b>10</b>	<b>Aluminium repair</b>	<b>29</b>
10.1	Painting	29
10.2	Surface treatment	29
10.3	Levelling	30
10.4	Temperature control for heating	30
<b>11</b>	<b>Plastic repair method</b>	<b>31</b>
11.1	Material	31
11.2	Repairing the pit	32
11.3	Repairing the scratch	34
11.4	Repair the crack	35
11.5	Repairing the small hole (the diameter is more than 30 mm)	36
11.6	Plastic repair (glass fibre material)	37
11.7	Repair process	38
<b>12</b>	<b>Glass repair</b>	<b>40</b>
12.1	Repairing the windshield	40