



Contents

91 - Communication	1
1 Communication systems	1
1.1 Fault finding	1
2 Radio and radio navigation systems in general	2
2.1 Removing and installing radio and radio navigation systems	2
2.2 Fault finding	4
2.3 Adapting radio components	5
2.4 Adapting radio navigation system components	5
3	6
3.1 General notes	6
3.2 Overview of radio system "RCD 300"	7
3.3 Overview of connectors on radio "RCD 300"	8
3.4 Anti-theft coding	9
4 Radio system "RCD 310"	11
4.1 General notes	11
4.2 Overview of radio system "RCD 310"	11
4.3 Overview of connectors on radio "RCD 310"	13
4.4 Anti-theft coding	15
5	18
5.1 General description	18
5.2 Overview of radio system "RCD 500"	19
5.3 Activating/deactivating transport lock for CD changer in "RCD 500"	20
5.4 Overview of connectors on radio "RCD 500"	21
5.5 Anti-theft coding	22
6 Radio system "RCD 510"	24
6.1 General notes	24
6.2 Overview of radio system "RCD 510"	25
6.3 Activating/deactivating transport lock for CD changer in "RCD 510"	26
6.4 Overview of connectors on radio "RCD 510"	27
6.5 Anti-theft coding	30
7	34
7.1 General description	34
7.2 Overview of radio system "Premium Sound System"	34
7.3 Overview of connectors on radio "Premium Sound System"	36
7.4 Anti-theft coding	38
8	40
8.1 General description	40
8.2 Overview of radio navigation system "RNS 300"	41
8.3 Overview of connectors on radio navigation system "RNS 300"	42
8.4 Anti-theft coding	44
9	46
9.1 General notes	46
9.2 Overview of radio navigation system "RNS 310"	47
9.3 Overview of connectors on radio navigation system "RNS 310"	49
9.4 Anti-theft coding	51
10	55
10.1 General notes	55
10.2 Features of radio navigation system "RNS 315"	55
10.3 System overview of the radio navigation system "RNS 315"	56
10.4 Overview of connectors on radio navigation system "RNS 315"	59
10.5 Anti-theft coding	62



11	66
11.1	General description	66
11.2	Overview of "RNS MFD 2 DVD"	67
11.3	Overview of connectors on "RNS MFD 2 DVD"	69
11.4	Anti-theft coding	73
12	74
12.1	General description	74
12.2	Overview of radio navigation system "RNS MFD 2 DVD"	75
12.3	Overview of connectors on radio navigation system "RNS MFD 2 DVD"	77
12.4	Anti-theft coding	81
13	83
13.1	General notes	83
13.2	Overview of radio navigation system "RNS 510"	83
13.3	Overview of connectors on radio navigation system "RNS 510"	85
13.4	Anti-theft coding	88
14	Sound system amplifier	91
14.1	General description	91
14.2	Removing and installing amplifier	91
14.3	Pin assignments on connectors of amplifier	93
15	Satellite digital radio tuner for vehicles for USA and Canada	95
15.1	General notes	95
15.2	Fault finding	95
15.3	Removing and installing satellite digital radio tuner	95
16	Compass, for vehicles for USA and Canada	97
16.1	General description	97
16.2	Removing and installing magnetic field sender	97
17	CD changer	99
17.1	Removing and installing CD changer	99
18	101
18.1	General notes	101
18.2	Removing and installing storage compartment with USB connection	103
18.3	Overview of connectors on USB connection	105
18.4	Fault finding procedure	106
19	Interface for external multimedia devices R215	107
19.1	General notes	107
19.2	System overview of interface for external multimedia devices R215	107
19.3	Interface for external multimedia devices R215	108
20	Connection for external audio sources	110
20.1	General notes	110
20.2	Removing and installing connection for external audio sources R199	110
20.3	Contact assignment on connection for external audio sources R199	111
21	Loudspeaker systems	112
21.1	Removing and installing front bass loudspeakers	112
21.2	Removing and installing rear bass loudspeakers	113
21.3	Removing and installing front treble loudspeakers	115
21.4	Removing and installing rear treble loudspeakers	116
21.5	Removing and installing front mid-range loudspeakers	117
22	Telephone system	118
22.1	General notes	118
22.2	Telephone system/universal preparation for mobile telephone	118
22.3	Removing and installing telephone system microphone	123
23	Aerial systems	125
23.1	General notes	125



23.2	Overview of aerial system for RCD 300, 500, RNS 300, RNS MFD	125
23.3	Overview of aerial system component locations in rear lid	127
23.4	Overview of aerial system as block circuit diagram for vehicles for USA and Canada	128
23.5	Overview of aerial system component locations in the rear lid for USA and Canada vehicles	129
23.6	Overview of aerial systems RCD 310, 510, RNS 300, 310, 315, 510	129
23.7	Removing and installing aerial amplifier	130
23.8	Removing and installing carrier plate for aerial modules	131
23.9	Removing and installing aerial modules	132
23.10	Renewal of aerial wiring	133
24	Multifunction steering wheel	134
24.1	Multifunction steering wheel ► 11.2010	134
24.2	Multifunction steering wheel 11.2010 ►	136
25	Mobile online services	139
25.1	General notes	139
25.2	Overview of fitting locations - mobile online services	139
25.3	Removing and installing emergency call module control unit and communication unit J949	140
26	Notes on operating mobile telephones and two-way radios	142
26.1	General notes	142
26.2	Notes on performing repair work	142
26.3	Overview of battery, transmitter and receiver unit, fuse and wiring harness	144
26.4	Transmitting power and aerial fitting locations	145
27	Suppression measures	147
27.1	Implementation of suppression measures	147