



Contents

01 - Self diagnosis	1
1 Self diagnosis of Climatronic	1
1.1 Self diagnosis of Climatronic	1
1.2 Tools	1
1.3 Function	2
1.4 Technical data of self diagnosis	2
1.5 Test prerequisites for self diagnosis	2
1.6 Connecting fault reader V.A.G 1551 and selecting function	3
1.7 Chart of functions that can be selected	5
1.8 Interrogating fault memory	6
1.9 Fault table	6
1.10 Final control diagnosis	12
1.11 Read measured value block	14
1.12 Erasing fault memory, ending output	20
80 - Heating	22
1 Servicing heating system	22
1.1 Servicing heating system	22
2 Dismantling and assembling heater	31
2.1 Dismantling and assembling heater	31
3 Installing and adjusting cables	35
3.1 Installing and adjusting cables	35
4 Dismantling and assembling heated air and fresh air controls	39
4.1 Dismantling and assembling heated air and fresh air controls	39
5 Servicing electronic heating control - Thermotronic	40
5.1 Tools	40
87 - Air conditioning	48
1 Safety measures for working on air conditioned vehicles and handling refrigerant - R12 ..	48
1.1 Safety measures for working on air conditioned vehicles and handling refrigerant - R12 ..	48
1.2 Safety precautions for working on air conditioned vehicles and handling refrigerant R12 ..	48
1.3 Service work on the air conditioner which can only be carried out in specially-equipped	
workshops	50
2 Refrigerant R12 - Air conditioner with manual controls	52
2.1 Refrigerant R12 - Air conditioner with manual controls	52
2.2 Servicing air conditioning and heating - Passenger compartment	52
2.3 Servicing air conditioning and heating - Engine compartment	59
2.4 Installing and adjusting cables	68
2.5 Vacuum hose connection diagram	71
2.6 Removing and installing compressor bracket - 4 Cyl. petrol engine	74
2.7 Removing and installing compressor bracket - 6 Cyl. petrol engine	77
3 Notes on repair work to vehicles with air conditioning and on handling refrigerant	81
3.1 Notes on repair work to vehicles with air conditioning and on handling refrigerant	81
3.2 Safety precautions for when working on vehicles with air conditioning and when handling	
refrigerant R134a	81
4 Refrigerant R134a - Air conditioner with manual controls	83
4.1 Refrigerant R134a - Air conditioner with manual controls	83
4.2 Servicing air conditioning and heating - Passenger compartment	83
4.3 Servicing air conditioning and heating - Engine compartment	91
4.4 Installing and adjusting cables	99
4.5 Vacuum hose connection diagram	102
4.6 Removing and installing compressor bracket - 4 Cyl. petrol engine	105
4.7 Removing and installing compressor bracket - 6 Cyl. petrol engine >08.93	108



4.8	Removing and installing compressor bracket - 6 Cyl. petrol engine 08.93 >	112
4.9	Removing and installing compressor bracket - Turbo Diesel engine	116
4.10	Removing and installing compressor bracket ("Harrison" compressor with "Diavia" bracket), Engine codes AAM, ADY, ADZ, AEK	119
5	Climatronic - Air conditioner with automatic regulation (R134a refrigerant)	129
5.1	Climatronic - Air conditioner with automatic regulation (R134a refrigerant)	129
5.2	Operation and function of the control and display unit	129
5.3	Servicing Climatronic - Passenger compartment	130
5.4	Servicing Climatronic - engine compartment	145
5.5	Checking and adjusting end position of installed temperature flap positioning motor	153
5.6	Vacuum hose connection diagram	154
6	Repair work on the refrigerant circuit which can only be carried out by properly trained mechanics (Specialist workshops for air conditioning systems)	159
6.1	Repair work on the refrigerant circuit which can only be carried out by properly trained mechanics (Specialist workshops for air conditioning systems)	159
6.2	Tools	159
6.3	Servicing components in the refrigerant circuit	160
6.4	Removing expansion valve	173
6.5	Servicing magnetic coupling -N25- when compressor is removed; Manufacturer Sanden	177
6.6	Removing and installing condenser	185
6.7	Dismantling and assembling evaporator housing	188
7	Capacities	191
7.1	Capacities	191
7.2	Refrigerant R134a	191
7.3	Refrigerant oil	191