



Contents

01 - Self diagnosis, Electrical check	1
1 Self diagnosis	1
1.1 Self diagnosis	1
1.2 Function	1
1.3 Technical data of self diagnosis	1
1.4 Connecting fault reader V.A.G 1551 and selecting engine electronics control unit	2
1.5 Interrogating fault memory	3
1.6 Fault table	3
1.7 Erasing fault memory	9
1.8 Final control diagnosis	10
1.9 Reading measuring value block	13
1.10 Display group overview	13
2 Electrical check	15
2.1 Electrical check	15
2.2 Wiring and component check with test box V.A.G 1598/18	15
24 - Mixture preparation, Injection	22
1 Motronic injection and ignition system	22
1.1 Motronic injection and ignition system	22
1.2 Fitting locations overview	22
1.3 Servicing injection part	25
1.4 Dismantling and assembling intake manifold - upper part	33
1.5 Dismantling and assembling intake manifold - lower part	36
1.6 Dismantling and assembling air cleaner	37
1.7 Safety precautions	38
1.8 Rules for cleanliness	39
1.9 Technical data	39
1.10 Idling check	39
1.11 Checking idling stabilization	40
1.12 Checking Lambda probe and Lambda control	42
1.13 Checking engine operation	44
1.14 Checking throttle valve potentiometer	45
1.15 Matching automatic gearbox control unit and throttle valve potentiometer to one another	46
1.16 Checking intake manifold temperature sender	47
1.17 Checking coolant temperature sender	48
1.18 Checking speed signal	49
1.19 Matching engine electronic control unit to electronic immobilizer	50
1.20 Checking fuel pressure regulator and holding pressure	51
1.21 Checking injectors	53
1.22 Checking intake air system for leaks (outside air)	55
1.23 Checking intake air preheating	56
28 - Ignition system	58
1 Motronic injection and ignition system	58
1.1 Motronic injection and ignition system	58
1.2 Servicing ignition part	58
1.3 Safety precautions	62
1.4 Test data, spark plugs	62
1.5 Installing distributor	62
1.6 Checking ignition transformer	64
1.7 Checking ignition transformer output stage	65
1.8 Checking Hall sender	66