



Contents

01 - Self-diagnosis	1
1 General to self-diagnosis	1
1.1 General to self-diagnosis	1
1.2 Features of self-diagnosis	1
1.3 Technical data of self-diagnosis	1
1.4 Significance of exhaust emissions warning lamp	3
1.5 Connecting fault reader V.A.G 1551 and selecting engine control unit	4
1.6 Connecting vehicle diagnosis, testing and information system VAS 5051 and selecting engine control unit	6
2 Fault memory	8
2.1 Fault memory	8
2.2 Interrogating and erasing fault memory	8
2.3 Automatic test sequence	9
3 Fault table: SAE P0 codes	10
3.1 Fault table: SAE P0 codes	10
4 Fault table: SAE P1 codes	14
4.1 Fault table: SAE P1 codes	14
5 Final control diagnosis	17
5.1 Final control diagnosis	17
5.2 Performing final control diagnosis	17
6 Readiness code	23
6.1 Readiness code	23
6.2 Reading readiness code	23
6.3 Generating readiness code	24
7 Measured value blocks	30
7.1 Measured value blocks	30
7.2 Safety precautions	30
7.3 Read measured value block	30
8 Evaluating measured value blocks, display groups 0...9 -Basic functions-	31
8.1 Evaluating measured value blocks, display groups 0...9 -Basic functions-	31
9 Evaluating measured value blocks, display groups 10...29, 212 -Ignition-	35
9.1 Evaluating measured value blocks, display groups 10...29, 212 -Ignition-	35
10 Evaluating measured value blocks, display grps 30...49, 99 -Lambda regulation-	38
10.1 Evaluating measured value blocks, display grps 30...49, 99 -Lambda regulation-	38
11 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	43
11.1 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	43
12 Evaluating measured value blocks, display groups 70...79 -Reducing emissions-	45
12.1 Evaluating measured value blocks, display groups 70...79 -Reducing emissions-	45
13 Evaluating measured value blocks, display groups 80...100 -Readiness code-	46
13.1 Evaluating measured value blocks, display groups 80...100 -Readiness code-	46
24 - Mixture preparation, Injection	48
1 Servicing injection system	48
1.1 Servicing injection system	48
1.2 Fitting locations overview	48
1.3 General notes on injection	52
1.4 Removing and installing parts of the injection system	54
1.5 Dismantling and assembling intake manifold - Upper part	63
1.6 Dismantling and assembling intake manifold - lower part	65
1.7 Dismantling and assembling air cleaner	66
1.8 Safety precautions	67
1.9 Rules for cleanliness	68



1.10	Technical data	68
2	Checking components	69
2.1	Checking components	69
2.2	Checking Lambda probe heating for Lambda probe before catalyst	69
2.3	Checking Lambda probe heating for Lambda probe after catalyst	71
2.4	Checking air mass meter	74
2.5	Checking throttle valve control part	76
2.6	Checking coolant temperature sender	83
2.7	Checking intake air temperature sender	87
2.8	Checking engine speed sender	90
2.9	Checking injectors	92
2.10	Checking fuel pressure regulator and holding pressure	96
2.11	Checking intake air system for leaks (unmetered air)	99
3	Checking functions	100
3.1	Checking functions	100
3.2	Idling check	100
3.3	Adapting idling speed	101
3.4	Checking Lambda probe and Lambda regulation before catalyst	103
3.5	Checking Lambda probe and Lambda regulation after catalyst	106
3.6	Checking Lambda probe ageing Lambda probe 1	111
3.7	Checking engine operating mode	112
3.8	Checking intake air preheating	113
4	Engine control unit	115
4.1	Engine control unit	115
4.2	Checking control unit voltage supply	115
4.3	Procedure after voltage supply open circuit	116
4.4	Replacing engine control unit	117
4.5	Coding engine control unit	117
4.6	Adapting engine control unit to throttle valve control part	119
5	Checking additional signals	120
5.1	Checking additional signals	120
5.2	Checking speed signal	120
5.3	Checking signal from/to air conditioning system	122
5.4	Checking driving range signal	123
5.5	Checking data bus	124
28 - Ignition system	126	
1	Servicing ignition system	126
1.1	Servicing ignition system	126
1.2	General notes on ignition system	126
1.3	Removing and installing parts of the ignition system	127
1.4	Safety precautions	130
1.5	Test data, spark plugs	131
1.6	Installing distributor	131
1.7	Checking and adjusting distributor basic setting	133
1.8	Checking Hall sender	134
1.9	Checking ignition transformer and output stage	135
1.10	Checking knock sensor	138
1.11	Check misfiring recognition	140