



Contents

01 - Self-diagnosis	1
1 General to self-diagnosis	1
1.1 General to self-diagnosis	1
1.2 Features of self-diagnosis	1
1.3 Technical data of self-diagnosis	1
1.4 Connecting fault reader V.A.G 1551 and selecting engine electronics control unit	2
2 Fault memory	6
2.1 Fault memory	6
2.2 Interrogating and erasing fault memory	6
2.3 Fault table	7
3 Final control diagnosis	18
3.1 Final control diagnosis	18
3.2 Performing final control diagnosis	18
4 Measured value blocks	22
4.1 Measured value blocks	22
4.2 Safety precautions	22
4.3 Read measured value block	22
4.4 Evaluating measured value blocks	23
24 - Mixture preparation, Injection	33
1 Servicing injection system	33
1.1 Servicing injection system	33
1.2 Fitting locations overview	33
1.3 General notes on injection	37
1.4 Removing and installing parts of the injection system	38
1.5 Dismantling and assembling air cleaner	41
1.6 Dismantling and assembling fuel rail with injectors	44
1.7 Removing and installing throttle valve control part	47
1.8 Safety precautions	53
1.9 Rules for cleanliness	53
1.10 Technical data	54
2 Checking components	54
2.1 Checking components	54
2.2 Checking Lambda probe heating	54
2.3 Checking air mass meter	57
2.4 Checking throttle valve control part	60
2.5 Checking throttle valve potentiometer	68
2.6 Checking coolant temperature sender	69
2.7 Checking intake manifold temperature sender	73
2.8 Checking engine speed sender	76
2.9 Checking fuel pressure regulator and holding pressure	77
2.10 Checking intake air system for leaks (unmetered air)	79
2.11 Matching engine electronic control unit to electronic immobilizer	80
2.12 Removing and installing injectors	81
2.13 Checking injectors	82
2.14 Checking and adjusting throttle closing damper	86
2.15 Matching automatic gearbox control unit and throttle valve potentiometer to one another ..	87
3 Checking functions	87
3.1 Checking functions	87
3.2 Idling check	87
3.3 Checking Lambda control	89
3.4 Checking engine operating mode	92
3.5 Checking driving characteristics after a cold start	94



4	Engine control unit	95
4.1	Engine control unit	95
4.2	Checking control unit voltage supply	95
4.3	Procedure after voltage supply open circuit	97
4.4	Replacing engine control unit	98
4.5	Coding engine control unit	98
4.6	Matching engine control unit to throttle valve control part	99
4.7	Matching engine control unit to electronic immobilizer	100
5	Checking additional signals	102
5.1	Checking additional signals	102
5.2	Checking speed signal	102
5.3	Checking air conditioner compressor signal	103
5.4	Checking driving range signal	105
28	- Ignition system	107
1	Motronic injection and ignition system with distributor-less ignition	107
1.1	Motronic injection and ignition system with distributor-less ignition	107
1.2	General notes on ignition system	107
1.3	Safety precautions	111
1.4	Test data, spark plugs	111
1.5	Checking Hall sender	111
1.6	Checking ignition transformer	113
1.7	Checking knock sensors	116
2	Motronic injection and ignition system with distributor	118
2.1	Motronic injection and ignition system with distributor	118
2.2	Servicing ignition part	118
2.3	Dismantling and assembling distributor	122
2.4	Safety precautions	124
2.5	Test data, spark plugs	125
2.6	Checking Hall sender	125
2.7	Checking ignition transformer	126
2.8	Checking ignition transformer output stage	126
2.9	Renewing rotor arm	128