



Contents

01 - Self-diagnosis	1
1 General to self-diagnosis	1
1.1 General to self-diagnosis	1
1.2 Features of self-diagnosis	1
1.3 Technical data of self-diagnosis	1
1.4 Connecting fault reader V.A.G 1551 and selecting engine control unit	2
2 Fault memory	5
2.1 Fault memory	5
2.2 Interrogating and erasing fault memory	5
3 Fault table, fault codes 00282...00530	7
3.1 Fault table, fault codes 00282...00530	7
4 Fault table, fault codes 00533...17978	13
4.1 Fault table, fault codes 00533...17978	13
5 Final control diagnosis	20
5.1 Final control diagnosis	20
5.2 Performing final control diagnosis	20
6 Measured value blocks	24
6.1 Measured value blocks	24
6.2 Safety precautions	24
6.3 Read measured value block	24
6.4 Evaluating measured value blocks, display groups 00 - 05	25
6.5 Evaluating measured value blocks, display groups 06 - 13	29
6.6 Evaluating measured value blocks	33
24 - Mixture preparation, Injection	40
1 Servicing injection system	40
1.1 Servicing injection system	40
1.2 Fitting locations overview	40
1.3 General notes on injection	43
1.4 Removing and installing parts of the injection system	45
1.5 Dismantling and assembling intake manifold - Upper part	54
1.6 Dismantling and assembling air cleaner	55
1.7 Dismantling and assembling fuel rail	57
1.8 Safety precautions	58
1.9 Rules for cleanliness	59
1.10 Technical data	59
2 Checking components	59
2.1 Checking components	59
2.2 Checking Lambda probe heating	59
2.3 Checking air mass meter	62
2.4 Checking throttle valve control part	64
2.5 Checking coolant temperature sender	71
2.6 Checking intake air temperature sender	74
2.7 Checking engine speed sender	77
2.8 Checking injectors	79
2.9 Checking fuel pressure regulator and holding pressure	84
2.10 Checking intake air system for leaks (unmetered air)	87
3 Checking functions	88
3.1 Checking functions	88
3.2 Idling check	88
3.3 Checking Lambda control	89
3.4 Checking engine operating mode	94
3.5 Checking driving characteristics after a cold start	96



3.6	Checking intake manifold change-over	97
4	Engine control unit	98
4.1	Engine control unit	98
4.2	Checking control unit voltage supply	98
4.3	Replacing engine control unit	100
4.4	Coding engine control unit	101
4.5	Adapting engine control unit to throttle valve control part	103
4.6	Adapting engine control unit to electronic immobilizer	105
5	Checking additional signals	106
5.1	Checking additional signals	106
5.2	Checking signal from/to air conditioning system	106
5.3	Checking data bus	108
5.4	Checking driving range signal	117
5.5	Testing speed signal	118
5.6	Checking engine speed signal	119
5.7	Checking signal from power steering pressure switch	120
5.8	Checking signal from clutch pedal switch	121
5.9	Checking signal from brake light switch and brake pedal switch	122
28	- Ignition system	124
1	Servicing ignition system	124
1.1	Servicing ignition system	124
1.2	General notes on ignition system	124
1.3	Removing and installing parts of the ignition system	125
1.4	Safety precautions	128
1.5	Test data, spark plugs	128
1.6	Checking Hall sender	128
1.7	Checking ignition coils with output stage	130
1.8	Checking knock sensor	133