



Contents

00 - Technical data	1
1 Technical data	1
1.1 Engine number	1
1.2 Engine data	1
10 - Removing and installing engine	2
1 Removing and installing engine	2
1.1 Removing engine	2
1.2 Installing engine	8
13 - Crankshaft group	11
1 Dismantling and assembling engine	11
1.1 Assembly overview	11
1.2 Removing and installing poly V-belt	15
2 Dismantling and assembling pistons and conrods	18
2.1 Assembly overview - Pistons and conrods	18
2.2 Checking pistons, piston rings and cylinder bores	21
2.3 Piston and cylinder dimensions	23
3 Removing and installing crankshaft	24
3.1 Colour identification	25
3.2 Crankshaft dimensions	25
15 - Cylinder head, Valve gear	27
1 Removing and installing cylinder head	27
1.1 Removing, installing and tensioning toothed belt	28
1.2 Checking semi-automatic toothed belt tensioning roller	33
1.3 Removing and installing cylinder head	34
1.4 Checking compression	38
2 Repairing valve gear	41
2.1 Reworking valve seats	43
2.2 Renewing camshaft oil seal	45
2.3 Removing and installing camshaft	48
2.4 Checking hydraulic bucket tappets	50
2.5 Checking valve guides	51
2.6 Renewing valve guides	52
2.7 Renewing valve stem seals	53
17 - Lubrication	56
1 Removing and installing parts of the lubrication system	56
1.1 Engine oil	56
1.2 Assembly overview - Parts of lubrication system	57
1.3 Assembly overview - Oil filter bracket	59
1.4 Removing and installing sump	60
1.5 Checking oil pressure and oil pressure switch	62
19 - Cooling system	65
1 Removing and installing parts of cooling system	65
1.1 Assembly overview - parts of cooling system - engine side	65
1.2 Assembly overview - parts of cooling system - body side	68
1.3 Draining and filling coolant	69
1.4 Removing and installing coolant pump	72
1.5 Removing and installing thermostat	73
1.6 Removing and installing radiator fan V7 and radiator fan 2 V177	75



1.7	Removing and installing radiator	76
1.8	Checking cooling system for leaks	77
20	- Fuel supply system	80
1	Fuel tank	80
1.1	Safety precautions when working on the fuel supply system	80
1.2	Rules for cleanliness	80
1.3	Assembly overview - fuel tank	80
1.4	Emptying fuel tank	82
1.5	Removing and installing fuel tank	84
2	Repairing fuel supply	87
2.1	Safety precautions when working on the fuel supply system	87
2.2	Rules for cleanliness	87
2.3	Removing and installing fuel delivery unit	88
2.4	Removing and installing fuel gauge sender G	90
2.5	Checking fuel pump	90
3	Checking electronic power control (EPC)	100
3.1	Function of EPC system	100
3.2	Assembly overview - accelerator pedal module	100
3.3	Removing and installing accelerator module	101
4	Active charcoal filter system	103
4.1	Function	103
4.2	Assembly overview - active charcoal filter system	103
4.3	Checking fuel tank breather	104
24	- Mixture preparation, Injection	106
1	Repairing injection system	106
1.1	General notes on injection	106
1.2	Safety precautions	107
1.3	Rules for cleanliness	107
1.4	Technical data	108
1.5	Dismantling and assembling intake manifold - upper part	108
1.6	Dismantling and assembling intake manifold - lower part	110
1.7	Fuel rail	111
1.8	Dismantling and assembling air cleaner	112
1.9	Removing and installing intake manifold	112
1.10	Removing and installing fuel rail with intake manifold flaps	113
1.11	Removing and installing injectors	115
1.12	Renewing Teflon seal on injector	117
1.13	Cleaning throttle valve module J338	119
2	Engine control unit	120
2.1	Removing and installing anti-theft engine control unit	120
2.2	Reading and erasing engine control unit fault memory	122
26	- Exhaust system	123
1	Removing and installing parts of exhaust system	123
1.1	Front exhaust pipe and catalytic converter with attachments	123
1.2	Silencer with mountings	125
1.3	Separating middle and rear silencers	125
1.4	Aligning exhaust system stress free	126
28	- Ignition system	128
1	Repairing ignition system	128
1.1	General notes on ignition system	128
1.2	Safety precautions	128



1.3	Assembly overview - ignition system	128
1.4	Spark plugs	129