



Contents

00 - Technical data	1
1 Safety information	1
1.1 Safety measures when working on vehicles with a start/stop system	1
2 Identification	2
2.1 Gearbox identification	2
3 Repair instructions	3
3.1 General repair instructions	3
4 Technical data	6
4.1 Allocation gearbox - engine	6
4.2 Capacities	6
5 Overview - power transmission	7
6 Electrical components	8
6.1 Overview of fitting locations - electrical components	8
30 - Clutch	9
1 Clutch mechanism	9
1.1 Assembly overview - pedal cluster	9
1.2 Assembly overview - clutch hydraulics	11
1.3 Checking clutch master cylinder and clutch slave cylinder	13
1.4 Removing and installing bearing bush	14
1.5 Removing and installing clutch position sender G476	15
1.6 Removing and installing return spring	16
1.7 Removing and installing over-centre spring	20
1.8 Removing and installing clutch pedal	23
1.9 Removing and installing mounting bracket	25
1.10 Removing and installing clutch master cylinder	31
1.11 Removing and installing lines for clutch mechanism	31
1.12 Bleeding clutch mechanism	35
2 Clutch	38
34 - Controls, housing	39
1 Selector mechanism	39
1.1 Assembly overview – gear knob and cover	39
1.2 Assembly overview - selector mechanism	40
1.3 Removing and installing gear knob	43
1.4 Removing and installing selector mechanism	45
1.5 Adjusting selector mechanism	55
1.6 Checking selector mechanism	58
2 Removing and installing gearbox	59
2.1 Specified torques for gearbox	59
2.2 Removing gearbox	61
2.3 Installing gearbox	69
3 Transporting gearbox	72
4 Gear oil	73
4.1 Checking gear oil level	73
4.2 Draining and filling gear oil	73
35 - Gears, shafts	75
1 Input shaft	75
2 Output shaft	76



39 - Final drive - differential	77
1 Oil seals	77
1.1 Overview of fitting locations - oil seals	77
1.2 Renewing left seal	78
1.3 Renewing right seal	82