



Contents

01 - Self-diagnosis	1
1 General to self-diagnosis	1
1.1 General to self-diagnosis	1
1.2 Features of self-diagnosis	1
1.3 Technical data of self-diagnosis	1
1.4 Significance of EPC warning lamp (fault lamp for electronic accelerator) in dash panel insert	2
1.5 Connecting fault reader V.A.G 1551 and selecting engine control unit	3
1.6 Connecting vehicle diagnosis, testing and information system VAS 5051 and selecting engine control unit	5
2 Fault memory	8
2.1 Fault memory	8
2.2 Automatic test sequence for interrogating all fault memories	8
2.3 Interrogating and erasing engine control unit fault memory	9
3 Fault table: SAE P0 codes	10
3.1 Fault table: SAE P0 codes	10
4 Fault table: SAE P1 codes	13
4.1 Fault table: SAE P1 codes	13
5 Final control diagnosis	19
5.1 Final control diagnosis	19
5.2 Performing final control diagnosis	19
6 Measured value blocks	25
6.1 Measured value blocks	25
6.2 Safety precautions	25
6.3 Read measured value block	25
7 Evaluating measured value blocks, display groups 0...9 -Basic functions-	26
7.1 Evaluating measured value blocks, display groups 0...9 -Basic functions-	26
8 Evaluating measured value blocks, display groups 10...29 -Ignition-	29
8.1 Evaluating measured value blocks, display groups 10...29 -Ignition-	29
9 Evaluating measured value blocks, display groups 30...49 -Lambda regulation-	32
9.1 Evaluating measured value blocks, display groups 30...49 -Lambda regulation-	32
10 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	36
10.1 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	36
11 Evaluating measured value blocks, display groups 70...79 -Reducing emissions-	39
11.1 Evaluating measured value blocks, display groups 70...79 -Reducing emissions-	39
11.2 Evaluating measured value blocks, display groups 90...95 -Variable valve timing/variable intake manifold-	40
12 Evaluating measured value blocks, display groups 120...129 -Communication-	41
12.1 Evaluating measured value blocks, display groups 120...129 -Communication-	41
12.2 Evaluating measured value blocks, display groups 130 and 131 -Cooling-	42
24 - Mixture preparation, Injection	43
1 Servicing injection system	43
1.1 Servicing injection system	43
1.2 Fitting locations overview	43
1.3 General notes on injection	51
1.4 Removing and installing parts of the injection system	52
1.5 Dismantling and assembling intake manifold - Upper part	59
1.6 Dismantling and assembling air cleaner	61
1.7 Dismantling and assembling fuel rail with injectors	62
1.8 Safety precautions	63
1.9 Rules for cleanliness	64



1.10	Technical data	64
2	Checking components	64
2.1	Checking components	64
2.2	Checking Lambda probe heating for Lambda probe before catalyst	64
2.3	Checking Lambda probe heating for Lambda probe after catalyst	67
2.4	Checking air mass meter	70
2.5	Checking intake air temperature sender	73
2.6	Checking throttle valve control part	75
2.7	Checking coolant temperature sender	79
2.8	Checking engine speed sender	81
2.9	Checking injectors	83
2.10	Checking fuel pressure regulator and holding pressure	89
2.11	Checking intake air system for leaks (unmetered air)	91
3	Checking functions	92
3.1	Checking functions	92
3.2	Idling check	92
3.3	Checking Lambda probe and Lambda regulation before catalyst	94
3.4	Checking Lambda probe and Lambda regulation after catalyst	98
3.5	Checking Lambda probe ageing Lambda probe 1	102
3.6	Checking engine operating mode	103
3.7	Checking intake manifold change-over	104
4	Engine control unit	105
4.1	Engine control unit	105
4.2	Function	105
4.3	Checking control unit voltage supply	105
4.4	Replacing engine control unit	107
4.5	Coding engine control unit	108
4.6	Coding variations of engine control unit	109
4.7	Erasing learnt values and adapting engine control unit to throttle valve control part and exhaust gas recirculation valve	110
4.8	Adapting engine control unit to electronic immobilizer	112
5	Checking additional signals	113
5.1	Checking additional signals	113
5.2	Checking speed signal	113
5.3	Checking engine speed signal	115
5.4	Checking signal from/to air conditioning system	115
5.5	Checking signal from clutch pedal switch	119
5.6	Checking signal from brake light switch and brake pedal switch	121
5.7	Checking signal from power steering pressure switch	124
5.8	Checking driving range signal	125
5.9	Checking data bus	126
28	- Ignition system	129
1	Servicing ignition system	129
1.1	Servicing ignition system	129
1.2	General notes on ignition system	129
1.3	Removing and installing parts of the ignition system	130
1.4	Safety precautions	133
1.5	Test data, spark plugs	133
1.6	Checking Hall sender	134
1.7	Checking ignition coils with output stage	135
1.8	Checking knock sensor	138
1.9	Check misfiring recognition	140