



Contents

01 - Self-diagnosis	1
1 General to self-diagnosis	1
1.1 General to self-diagnosis	1
1.2 Features of self-diagnosis	1
1.3 Technical data of self-diagnosis	1
1.4 Significance of EPC warning lamp (fault lamp for electronic accelerator) in dash panel insert	2
1.5 Significance of exhaust emissions warning lamp	3
1.6 Connecting fault reader	4
2 Fault memory	7
2.1 Fault memory	7
2.2 Interrogating and erasing engine control unit fault memory	7
2.3 Test sequence	8
3 Fault table: SAE P0 codes	9
3.1 Fault table: SAE P0 codes	9
4 Fault table: SAE P1 codes	16
4.1 Fault table: SAE P1 codes	16
5 Final control diagnosis	24
5.1 Final control diagnosis	24
5.2 Performing final control diagnosis	24
6 Readiness code	30
6.1 Readiness code	30
6.2 Function	30
6.3 Reading off readiness code	30
6.4 Generate readiness code	31
7 Measured value blocks	37
7.1 Measured value blocks	37
7.2 Safety precautions	37
7.3 Read measured value block	37
8 Evaluating measured value blocks, display groups 0...9 -Basic functions-	38
8.1 Evaluating measured value blocks, display groups 0...9 -Basic functions-	38
9 Evaluating measured value blocks, display groups 10...29 -Ignition-	42
9.1 Evaluating measured value blocks, display groups 10...29 -Ignition-	42
10 Evaluating measured value blocks, display groups 30...49, 99 -Lambda regulation-	46
10.1 Evaluating measured value blocks, display groups 30...49, 99 -Lambda regulation-	46
11 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	51
11.1 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	51
12 Evaluating measured value blocks, display groups 70...79 -Reducing emissions-	54
12.1 Evaluating measured value blocks, display groups 70...79 -Reducing emissions-	54
13 Evaluating measured value blocks, display group 100 -Readiness code-	56
13.1 Evaluating measured value blocks, display group 100 -Readiness code-	56
14 Evaluating measured value blocks, display groups 120...129 -Communication-	56
14.1 Evaluating measured value blocks, display groups 120...129 -Communication-	56
24 - Mixture preparation, Injection	58
1 Servicing injection system	58
1.1 Servicing injection system	58
1.2 Fitting locations overview	58
1.3 General notes on injection	62
1.4 Removing and installing parts of the injection system	64
1.5 Dismantling and assembling intake manifold	77



1.6	Dismantling and assembling fuel rail with injectors	81
1.7	Dismantling and assembling air cleaner	84
1.8	Dismantling and assembling the intake manifold	86
1.9	Safety precautions	89
1.10	Rules for cleanliness	90
1.11	Technical data	91
2	Checking components	91
2.1	Checking components	91
2.2	Checking Lambda probe heating for Lambda probe before catalytic converter	91
2.3	Checking Lambda probe heating for Lambda probe after catalytic converter	94
2.4	Checking throttle valve control part	96
2.5	Checking intake manifold pressure sender	100
2.6	Check intake air temperature sender	101
2.7	Check coolant temperature sender	106
2.8	Checking engine speed sender	111
2.9	Checking injectors	113
2.10	Checking fuel pressure regulator and holding pressure	119
2.11	Checking intake air system for leaks (unmetered air)	122
2.12	Checking intake air preheating	123
3	Checking functions	124
3.1	Checking functions	124
3.2	Idling check	124
3.3	Checking Lambda probe and Lambda regulation before catalytic converter	126
3.4	Check Lambda probe and Lambda regulation after catalytic converter	129
3.5	Checking Lambda probe ageing for Lambda probe before catalytic converter	133
3.6	Checking engine operating mode	135
4	Engine control unit	137
4.1	Engine control unit	137
4.2	Checking control unit voltage supply	137
4.3	Procedure after voltage supply open circuit	139
4.4	Replace engine control unit	139
4.5	Coding engine control unit	141
4.6	Coding variations of engine control unit	142
4.7	Erasing learnt values and adapting engine control unit to throttle valve control part and exhaust gas recirculation valve	142
5	Checking additional signals	144
5.1	Checking additional signals	144
5.2	Checking speed signal	144
5.3	Checking signal from/to air conditioning system	146
5.4	Checking signal from clutch pedal switch	148
5.5	Checking signal from brake light switch and brake pedal switch	150
5.6	Checking engine speed signal	153
5.7	Checking data bus	154
28	- Ignition system	156
1	Servicing ignition system	156
1.1	Servicing ignition system	156
1.2	General notes on ignition system	156
1.3	Removing and installing parts of the ignition system	157
1.4	Safety precautions	160
1.5	Test data, spark plugs	161
1.6	Checking Hall sender	161
1.7	Checking ignition coils with final output stage	163
1.8	Checking knock sensor	167
1.9	Check misfiring recognition	169