



## Contents

<b>01 - Self-diagnosis . . . . .</b>	<b>1</b>
<b>1 General to self-diagnosis (engine) . . . . .</b>	<b>1</b>
1.1 General to self-diagnosis (engine) . . . . .	1
1.2 Features of self-diagnosis . . . . .	1
1.3 Significance of EPC warning lamp (fault lamp for electronic accelerator) in dash panel insert . . . . .	1
1.4 Significance of exhaust emissions warning lamp . . . . .	2
1.5 Technical data of self-diagnosis . . . . .	3
1.6 Connecting fault reader V.A.G 1551 and selecting engine control unit . . . . .	4
1.7 Connecting vehicle diagnosis, testing and information system VAS 5051 and selecting engine control unit . . . . .	7
<b>2 Fault memory . . . . .</b>	<b>10</b>
2.1 Fault memory . . . . .	10
2.2 Interrogating and erasing fault memory . . . . .	10
<b>3 Fault table: from V.A.G code 16486 / SAE P0 codes . . . . .</b>	<b>12</b>
3.1 Fault table: from V.A.G code 16486 / SAE P0 codes . . . . .	12
3.2 Characteristics of the New Beetle RSi . . . . .	12
3.3 Fault table: from V.A.G code 16486 / SAE P0 codes . . . . .	15
<b>4 Fault table: from V.A.G code 17510 / SAE P1 codes . . . . .</b>	<b>21</b>
4.1 Fault table: from V.A.G code 17510 / SAE P1 codes . . . . .	21
4.2 Characteristics of the New Beetle RSi . . . . .	21
4.3 Fault table: from V.A.G code 17510 / SAE P1 codes . . . . .	24
<b>5 Final control diagnosis . . . . .</b>	<b>33</b>
5.1 Final control diagnosis . . . . .	33
5.2 Performing final control diagnosis . . . . .	33
<b>6 Readiness code . . . . .</b>	<b>49</b>
6.1 Readiness code . . . . .	49
6.2 Reading readiness code . . . . .	49
6.3 Generating readiness code . . . . .	50
<b>7 Measured value blocks . . . . .</b>	<b>68</b>
7.1 Measured value blocks . . . . .	68
7.2 Safety precautions . . . . .	68
7.3 Read measured value block . . . . .	69
<b>8 Evaluating measured value blocks, display groups 0...6 -Basic functions- . . . . .</b>	<b>70</b>
8.1 Evaluating measured value blocks, display groups 0...6 -Basic functions- . . . . .	70
<b>9 Evaluating measured value blocks, display groups 10...29 -Ignition- . . . . .</b>	<b>73</b>
9.1 Evaluating measured value blocks, display groups 10...29 -Ignition- . . . . .	73
<b>10 Evaluating measured value blocks, display groups 30...33, 99 -Lambda regulation- . . . . .</b>	<b>76</b>
10.1 Evaluating measured value blocks, display groups 30...33, 99 -Lambda regulation- . . . . .	76
<b>11 Evaluating measured value blocks, display groups 50...69 -Speed regulation- . . . . .</b>	<b>82</b>
11.1 Evaluating measured value blocks, display groups 50...69 -Speed regulation- . . . . .	82
<b>12 Evaluating measured block values, display groups 91...95 -Performance improvement- . . . . .</b>	<b>85</b>
12.1 Evaluating measured block values, display groups 91...95 -Performance improvement- . . . . .	85
<b>13 Evaluating measured value block, display group 125 -Communication- . . . . .</b>	<b>86</b>
13.1 Evaluating measured value block, display group 125 -Communication- . . . . .	86
<b>24 - Mixture preparation, Injection . . . . .</b>	<b>87</b>
<b>1 Servicing injection system . . . . .</b>	<b>87</b>
1.1 Servicing injection system . . . . .	87
1.2 Fitting locations overview . . . . .	87
1.3 General notes on injection . . . . .	94
1.4 Removing and installing parts of the injection system . . . . .	95



1.5	Dismantling and assembling intake manifold . . . . .	108
1.6	Dismantling and assembling fuel distributor . . . . .	112
1.7	Dismantling and assembling air cleaner . . . . .	114
1.8	Safety precautions . . . . .	116
1.9	Rules for cleanliness . . . . .	118
1.10	Technical data . . . . .	118
<b>2</b>	<b>Checking components . . . . .</b>	<b>118</b>
2.1	Checking components . . . . .	118
2.2	Checking Lambda probe heating for Lambda probe before catalyst . . . . .	119
2.3	Checking Lambda probe heating for Lambda probe after catalyst . . . . .	124
2.4	Checking air mass meter . . . . .	130
2.5	Checking throttle valve control part . . . . .	133
2.6	Checking coolant temperature sender . . . . .	137
2.7	Checking intake air temperature sender . . . . .	142
2.8	Checking engine speed sender . . . . .	148
2.9	Checking injectors . . . . .	149
2.10	Checking fuel pressure regulator and holding pressure . . . . .	155
2.11	Checking intake manifold change-over . . . . .	158
2.12	Checking intake air system for leaks (unmetered air) . . . . .	160
<b>3</b>	<b>Checking functions . . . . .</b>	<b>161</b>
3.1	Checking functions . . . . .	161
3.2	Idling check . . . . .	162
3.3	Checking Lambda probe and Lambda regulation before catalyst . . . . .	163
3.4	Checking Lambda probe and Lambda regulation after catalyst . . . . .	168
3.5	Checking Lambda probe ageing of Lambda probe 1 bank 1 . . . . .	171
3.6	Checking Lambda probe ageing of Lambda probe 1 bank 2 . . . . .	173
3.7	Checking Lambda probe ageing Lambda probe after catalyst (trim regulation) . . . . .	174
3.8	Checking engine operating mode . . . . .	176
3.9	Checking Lambda probe ageing of Lambda probes . . . . .	177
<b>4</b>	<b>Engine control unit . . . . .</b>	<b>177</b>
4.1	Engine control unit . . . . .	177
4.2	Checking control unit voltage supply . . . . .	178
4.3	Procedure after voltage supply open circuit . . . . .	180
4.4	Replacing engine control unit . . . . .	181
4.5	Coding engine control unit . . . . .	182
4.6	Matching engine control unit to electronic immobilizer . . . . .	183
4.7	Adapting engine control unit to throttle valve control part . . . . .	184
<b>5</b>	<b>Checking additional signals . . . . .</b>	<b>186</b>
5.1	Checking additional signals . . . . .	186
5.2	Checking speed signal . . . . .	186
5.3	Checking signal from/to air conditioner . . . . .	188
5.4	Checking signal from clutch pedal switch . . . . .	190
5.5	Checking signal from brake light switch and brake pedal switch . . . . .	193
5.6	Checking cruise control system (CCS) . . . . .	196
5.7	Checking data bus . . . . .	197
<b>28 - Ignition system . . . . .</b>	<b>199</b>	
<b>1</b>	<b>Servicing ignition system . . . . .</b>	<b>199</b>
1.1	Servicing ignition system . . . . .	199
1.2	General notes on ignition system . . . . .	199
1.3	Removing and installing parts of the ignition system . . . . .	200
1.4	Safety precautions . . . . .	205
1.5	Test data, spark plugs . . . . .	206
1.6	Checking Hall sender . . . . .	206
1.7	Checking ignition transformer . . . . .	208
1.8	Checking knock sensor . . . . .	212
1.9	Check misfiring recognition . . . . .	215