



## Contents

|   |           |
|---|-----------|
| <b>00 - Technical data</b>  | <b>1</b>  |
| <b>1 General information on air conditioning</b>  | <b>1</b>  |
| 1.1 Basics of air conditioning  | 1         |
| 1.2 Vapour pressure table for R134a refrigerant gas   | 3         |
| 1.3 R134a refrigerant gas   | 4         |
| 1.4 Properties of R134a refrigerant gas   | 5         |
| 1.5 Refrigeration system oil  | 7         |
| 1.6 Comfort   | 8         |
| 1.7 Environmental aspects   | 8         |
| 1.8 Air conditioning effects  | 8         |
| 1.9 Safety at work  | 9         |
| <b>2 General remarks on the refrigerant gas loop</b>  | <b>14</b> |
| 2.1 Refrigerant gas loop components   | 14        |
| 2.2 Refrigerant gas loop components   | 22        |
| 2.3 Quick coupling connections in the refrigerant gas loop  | 23        |
| 2.4 Switches and sensors for the refrigerant gas loop and their connections   | 24        |
| 2.5 Electrical components not assembled in the refrigerant gas loop   | 29        |
| 2.6 Pressures and temperatures in the refrigerant gas loop  | 31        |
| 2.7 Refrigerant circuit with expansion valve  | 31        |
| 2.8 Refrigerant circuit with butterfly (restrictor) and collection tank   | 33        |
| 2.9 Checking and measuring work with a pressure gauge   | 35        |
| 2.10 Notes on doing repair work on the refrigerant gas loop   | 36        |
| <b>3 Legislation and standards</b>  | <b>37</b> |
| 3.1 Legislation and standards   | 37        |
| 3.2 Regulations on recycling and disposal   | 40        |
| 3.3 Disposal of cooling agent and cooling machine oils  | 40        |
| <b>4 Using the climate control recovery, recycling, refilling, and cleaning equipment</b>   | <b>41</b> |
| 4.1 Important notes for using the Climate control recovery, recycling and refill set or EQ 7098 VAS 6008  | 41        |
| 4.2 Connect the Climate control recovery, recycling and refill set or EQ 7098 VAS 6008  | 42        |
| 4.3 Empty the refrigerant gas loop with the Climate control recovery, recycling and refill set or EQ 7098 VAS 6008  | 43        |
| 4.4 Fill the refrigerant gas loop with the Climate control recovery, recycling and refill set or EQ 7098 VAS 6008   | 44        |
| 4.5 Introduce refrigerant gas into the tank of the Climate control recovery, recycling and refill set or EQ 7098 VAS 6008   | 45        |
| 4.6 Emptying the tank of the Climate control recovery, recycling and refill set or EQ 7098 VAS 6008   | 46        |
| <b>5 Checking pressure values in the refrigerant gas loop</b>   | <b>47</b> |
| 5.1 Checking pressure values  | 48        |
| 5.2 Verification for vehicles with butterfly (throttle) and collection tank (air conditioning compressor with internal adjustment device)   | 50        |
| 5.3 Verification for vehicles with expansion valve and liquid loop / dryer (air conditioning compressor with internal adjustment device)  | 53        |
| 5.4 Verification for vehicles with expansion valve, liquid tank / dryer and Adjustment valve for the air conditioning compressor N280 (with air conditioning compressor with external adjustment device)  | 57        |
| 5.5 Verification for vehicles with butterfly (throttle), collection tank and regulating valve for the air conditioning compressor N280 (with air conditioning compressor with external adjustment device) | 66        |
| <b>6 Detecting leaks in the refrigerant gas loop</b>  | <b>72</b> |
| 6.1 Detecting leaks in the refrigerant gas loop with the R134a air conditioning leak detector or EQ 7051 VAG 1796   | 73        |
| 6.2 Detecting leaks in the refrigerant gas loop by pressurizing the system  | 73        |



|           |   |           |
|-----------|---|-----------|
| 6.3       | Detection of leaks in the refrigerant gas loop with the air conditioning recovery, recycling, recharging and cleaning set ..... | 74        |
| <b>7</b>  | <b>Cleaning the refrigerant gas loop</b> .....  | <b>77</b> |
| 7.1       | Venting the refrigerant gas loop .....  | 77        |
| 7.2       | Washing the refrigerant gas loop with R134a refrigerant gas (clean) .....   | 79        |
| <b>8</b>  | <b>Problems</b> .....   | <b>85</b> |
| 8.1       | Possible problems in the refrigerant circuit .....  | 85        |
| <b>9</b>  | <b>Replacing components</b> .....   | <b>87</b> |
| 9.1       | Leaking or damaged components (except the compressor, collection tank and liquid tank) ..                                       | 87        |
| 9.2       | Replace the air conditioning compressor .....   | 88        |
| 9.3       | Replace the liquid/collection tank and the butterfly (restrictor) .....   | 89        |
| <b>10</b> | <b>Test equipment and tools</b> .....   | <b>91</b> |
| 10.1      | List of test equipment, tools, and material .....   | 91        |
| 10.2      | Test equipment, tools, and material .....   | 91        |