



## Contents

<b>00 - Technical data</b>	<b>1</b>
<b>1 Safety information</b>	<b>1</b>
1.1 Safety precautions when working on air conditioning systems	1
1.2 Safety precautions when working on high-voltage system	2
1.3 Safety precautions when working in the vicinity of high-voltage components	2
1.4 Safety precautions when tow-starting or towing	3
<b>2 Repair instructions</b>	<b>4</b>
2.1 Rules for cleanliness when working on high-voltage system	4
<b>3 General information on air conditioning</b>	<b>5</b>
3.1 Other reference material	5
3.2 Basics of air conditioning technology	5
3.3 Vapour pressure table for refrigerant R134a	7
3.4 Refrigerant R134a	8
3.5 Properties of refrigerant R134a	9
3.6 Refrigerant oil	11
3.7 Comfort	12
3.8 How air conditioning works	13
3.9 General work safety	13
3.10 Safety measures when working on vehicles with air conditioning and when working with refrigerant R134a	16
3.11 Basics for working on refrigerant circuit	17
<b>4 General information on refrigerant circuit</b>	<b>20</b>
4.1 Components of refrigerant circuit	20
4.2 Design of refrigerant circuit	31
4.3 Evacuation and charging valves for quick-release couplings of air conditioner service station on refrigerant circuit	32
4.4 Switches and senders in refrigerant circuit and related connections	34
4.5 Electrical components not installed in refrigerant circuit	39
4.6 Pressures and temperatures in refrigerant circuit	42
4.7 Refrigerant circuit with expansion valve	42
4.8 Refrigerant circuit with restrictor and reservoir	44
4.9 Test and measurement work that can be performed using a pressure gauge	46
4.10 Air conditioner service and recycling equipment	47
4.11 Notes to repairs on refrigerant circuit	48
<b>5 Laws and regulations</b>	<b>49</b>
5.1 Laws and regulations	49
5.2 Recycling and refuse law	54
5.3 Converting R12 refrigerant circuits to R134a refrigerant circuits and repairing them (retrofitting)	55
5.4 Maintaining records on refrigerant	55
<b>6 Refrigerant circuit</b>	<b>56</b>
6.1 Important repair notes on air conditioning	56
6.2 Converting refrigerant circuits from R12 refrigerant to R134a	56
<b>7 Working with the air conditioner service station</b>	<b>57</b>
7.1 Important instructions for working with the air conditioner service station	57
7.2 Connecting a air conditioner service station for measuring and testing	58
7.3 Drain the refrigerant circuit using the air conditioner service station.	59
7.4 Evacuating refrigerant circuit using air conditioner service station	59
7.5 Filling refrigerant circuit with air conditioner service station.	61
7.6 Bringing air conditioning system into service after charging	62
7.7 Charging the container in the air conditioning service station with refrigerant	62
7.8 Emptying air conditioner service station	63



<b>8</b>	<b>Detecting leaks in refrigerant circuit</b>	<b>64</b>
8.1	Leak detection in refrigerant circuit using compressed air or nitrogen	65
8.2	Searching for leaks in refrigerant circuits using leak detector V.A.G 1796	66
8.3	Detecting leaks in refrigerant circuit using leak detecting system VAS 6196 or leak detecting system VAS 6201 or a later model	67
<b>9</b>	<b>Clearing refrigerant circuit of contaminants</b>	<b>75</b>
9.1	Vehicles with high-voltage system (hybrid vehicles)	75
9.2	Blowing through refrigerant circuit with compressed air and nitrogen	76
9.3	Flushing refrigerant circuit with refrigerant R134a	78
<b>10</b>	<b>Clearing refrigerant circuit of contaminants, commercial vehicles</b>	<b>110</b>
10.1	Vehicles with high-voltage system	110
10.2	Flushing refrigerant circuit with refrigerant R134a	111
10.3	Adapters for setting up flushing circuits	111
10.4	Procedure for setting up and flushing refrigerant circuit, Amarok 2010 ▶	115
10.5	Procedure for setting up and flushing refrigerant circuit, Caddy 2004 ▶	121
10.6	Procedure for setting up and flushing refrigerant circuit, Crafter ▶2017	128
10.7	Procedure for setting up and flushing refrigerant circuit, Crafter 2017 ▶ or MAN TGE ▶, Crafter Grand California ▶	145
10.8	Procedure for setting up and flushing refrigerant circuit, Transporter 2016 ▶, Transporter 2020 ▶	162
<b>11</b>	<b>Complaints</b>	<b>178</b>
11.1	Possible complaints about refrigerant circuit	178
11.2	Odours from heater and air conditioning unit	179
<b>12</b>	<b>Connecting the air conditioning service station</b>	<b>182</b>
12.1	For vehicles that have connections on both low-pressure and high-pressure sides of refrigerant circuit	182
<b>13</b>	<b>Checking pressures on vehicles</b>	<b>183</b>
13.1	Checking pressures in the refrigerant circuit (using a air conditioning service station)	183
13.2	Checking systems with a restrictor and collector (with internally regulated air conditioner compressor)	187
13.3	Checking systems with an expansion valve and reservoir (with internally regulated air conditioner compressor)	191
13.4	Checking systems with an expansion valve and reservoir (without regulated air conditioner compressor)	196
13.5	Checking systems with a restrictor and reservoir and air conditioner compressor regulating valve N280 (with externally regulated air conditioner compressor)	197
13.6	Checking systems with an expansion valve, receiver and air conditioner compressor regulating valve N280 (with externally regulated air conditioner compressor)	202
13.7	With expansion valve, receiver and electrical air conditioner compressor	213
<b>14</b>	<b>Renewing components</b>	<b>214</b>
14.1	In the event of leaking or damaged components (apart from the air conditioner compressor, receiver or reservoir)	215
14.2	Renew the air conditioner compressor	217
14.3	Replace receiver or reservoir and restrictor	219
<b>15</b>	<b>Testing equipment and tools</b>	<b>222</b>
15.1	List of test equipment, tools and materials	222