



Contents

00 - Technical data	1
1 Safety information	1
1.1 Safety regulations for working on fuel supply	1
1.2 Safety measures when working on vehicles with a start/stop system	2
1.3 Safety precautions when using testers and measuring instruments during a road test	2
1.4 Safety precautions when working on the SCR system	2
2 Identification	4
2.1 Engine number/engine data	4
3 General information	5
3.1 Rules for cleanliness when working on auxiliary/supplementary heater and fuel system ..	5
4 Repair notes	6
4.1 Pipe/wire routing and attachment	6
4.2 General repair instructions	6
20 - Fuel supply system	7
1 Procedure should vehicle be misfueled	7
1.1 Step 1, engine was started with incorrect fuel	7
1.2 Step 2, engine was not started with incorrect fuel	9
1.3 Step 3, there are metal particles in fuel delivery unit and fuel tank	11
1.4 Step 4, there are no metal particles in fuel delivery unit or fuel tank	12
1.5 Step 5, there are metal particles in high-pressure pump	13
1.6 Step 6, there are no metal particles in high-pressure pump	13
2 Fuel	14
2.1 Assembly overview - fuel tank	14
2.2 Emptying fuel tank	17
2.3 Removing and installing fuel tank	25
3 Fuel delivery unit, fuel gauge sender	35
3.1 Assembly overview - fuel delivery unit/fuel gauge sender	35
3.2 Removing and installing fuel delivery unit, fuel gauge sender	37
3.3 Removing and installing fuel gauge sender G	42
3.4 Removing and installing fuel gauge sender 2 G169	43
4 Plug-in connectors	46
4.1 Separating plug-in connectors	46
5 Fuel filter	50
5.1 Assembly overview - fuel filter	50
5.2 Removing and installing fuel filter	52
5.3 Fuel hoses in the engine compartment	56
6 Accelerator pedal	57
6.1 Assembly overview - accelerator module	57
6.2 Removing and installing accelerator pedal module GX2	57
7 Fuel pump	60
7.1 Checking fuel system pressurisation pump G6	60
7.2 Removing and installing suction-jet pump	91

