



Contents

01 - Self-diagnosis	1
1 General to self-diagnosis	1
1.1 General to self-diagnosis	1
1.2 Features of self-diagnosis	1
1.3 Technical data of self-diagnosis	1
1.4 Significance of EPC warning lamp (fault lamp for electronic accelerator) in dash panel insert	2
1.5 Significance of exhaust emissions warning lamp	3
1.6 Connecting fault reader	4
2 Fault memory	7
2.1 Fault memory	7
2.2 Interrogating and erasing fault memory	7
3 Fault table: from V.A.G code 16486 / SAE P0 codes	9
3.1 Fault table: from V.A.G code 16486 / SAE P0 codes	9
4 Fault table: from V.A.G code 17510 / SAE P1 codes	13
4.1 Fault table: from V.A.G code 17510 / SAE P1 codes	13
5 Final control diagnosis	21
5.1 Final control diagnosis	21
5.2 Performing final control diagnosis	21
6 Readiness code	28
6.1 Readiness code	28
6.2 Reading readiness code	28
6.3 Generating readiness code	29
7 Measured value blocks	33
7.1 Measured value blocks	33
7.2 Safety precautions	33
7.3 Read measured value block	33
8 Evaluating measured value blocks, display groups 0...6 -Basic functions	35
8.1 Evaluating measured value blocks, display groups 0...6 -Basic functions	35
9 Evaluating measured value blocks, display groups 10...29 -Ignition-	39
9.1 Evaluating measured value blocks, display groups 10...29 -Ignition-	39
10 Evaluating measured value blocks, display groups 30...49 -Lambda regulation-	42
10.1 Evaluating measured value blocks, display groups 30...49 -Lambda regulation-	42
11 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	48
11.1 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	48
12 Evaluating measured value blocks, display groups 70...75 -Exhaust gas recirculation-	51
12.1 Evaluating measured value blocks, display groups 70...75 -Exhaust gas recirculation-	51
13 Evaluating measured value blocks, display group 100 -Readiness code-	52
13.1 Evaluating measured value blocks, display group 100 -Readiness code-	52
14 Evaluating measured value blocks, display groups 120...129 -Communication-	52
14.1 Evaluating measured value blocks, display groups 120...129 -Communication-	52
24 - Mixture preparation, Injection	54
1 Servicing injection system	54
1.1 Servicing injection system	54
1.2 Fitting locations overview	54
1.3 General notes on injection	58
1.4 Removing and installing parts of the injection system	59
1.5 Dismantling and assembling intake manifold	69
1.6 Dismantling and assembling fuel rail with injectors	72
1.7 Dismantling and assembling air cleaner	75



1.8	Safety precautions	78
1.9	Rules for cleanliness	79
1.10	Technical data	80
2	Checking components	80
2.1	Checking components	80
2.2	Checking Lambda probe heating for Lambda probe before catalyst	80
2.3	Checking Lambda probe heating for Lambda probe after catalyst	83
2.4	Checking throttle valve control part	85
2.5	Checking intake manifold pressure sender	87
2.6	Checking intake air temperature sender	90
2.7	Checking coolant temperature sender	94
2.8	Checking engine speed sender	98
2.9	Checking injectors	100
2.10	Checking fuel pressure regulator and holding pressure	107
2.11	Checking intake air system for leaks (unmetered air)	110
2.12	Checking intake air preheating	111
3	Checking functions	112
3.1	Checking functions	112
3.2	Idling check	112
3.3	Adapting idling speed	114
3.4	Checking Lambda probe and Lambda regulation before catalyst	115
3.5	Checking Lambda probe and Lambda regulation after catalyst	118
3.6	Checking engine operating mode	122
4	Engine control unit	123
4.1	Engine control unit	123
4.2	Checking control unit voltage supply	123
4.3	Procedure after voltage supply open circuit	125
4.4	Replacing engine control unit	126
4.5	Coding engine control unit	127
4.6	Coding variants of engine control unit	128
4.7	Adapting engine control unit to throttle valve control part	128
4.8	Adapting engine control unit to electronic immobilizer	130
5	Checking additional signals	131
5.1	Checking additional signals	131
5.2	Checking speed signal	131
5.3	Checking signal from/to air conditioning system	133
5.4	Checking signal from brake light switch and brake pedal switch	134
5.5	Checking driving range signal	136
5.6	Checking rpm signal	137
5.7	Checking data bus	138
28	- Ignition system	140
1	Servicing ignition system	140
1.1	Servicing ignition system	140
1.2	General notes on ignition system	140
1.3	Removing and installing parts of the ignition system	141
1.4	Safety precautions	143
1.5	Test data, spark plugs	144
1.6	Checking Hall sender	145
1.7	Checking ignition transformer	147
1.8	Checking knock sensor	150
1.9	Check misfiring recognition	152