



Contents

01 - Self-diagnosis	1
1 General to self-diagnosis	1
1.1 General to self-diagnosis	1
1.2 Features of self-diagnosis	1
1.3 Technical data of self-diagnosis	1
1.4 Significance of EPC warning lamp (fault lamp for electronic accelerator) in dash panel insert	3
1.5 Connecting fault reader V.A.G 1551 and selecting engine electronics control unit	4
1.6 Connecting vehicle diagnosis, testing and information system VAS 5051 and selecting engine control unit	6
2 Fault memory	9
2.1 Fault memory	9
2.2 Interrogating and erasing fault memory of engine control unit	9
2.3 Automatic test sequence	10
3 Fault table: SAE P0 codes	11
3.1 Fault table: SAE P0 codes	11
4 Fault table: SAE P1 codes	14
4.1 Fault table: SAE P1 codes	14
5 Final control diagnosis	22
5.1 Final control diagnosis	22
5.2 Performing final control diagnosis	22
6 Readiness code	25
6.1 Readiness code	25
6.2 Function	25
6.3 Reading readiness code	25
6.4 Generating readiness code	26
7 Measured value blocks	33
7.1 Measured value blocks	33
7.2 Safety precautions	33
7.3 Read measured value block	33
8 Evaluating measured value blocks, display groups 0...9 -Basic functions-	34
8.1 Evaluating measured value blocks, display groups 0...9 -Basic functions-	34
9 Evaluating measured value blocks, display groups 10...29 -Ignition-	38
9.1 Evaluating measured value blocks, display groups 10...29 -Ignition-	38
10 Evaluating measured value blocks, display grps 30...49, 99 -Lambda regulation-	42
10.1 Evaluating measured value blocks, display grps 30...49, 99 -Lambda regulation-	42
11 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	47
11.1 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	47
12 Evaluating measured value blocks, display groups 70...79 -Reducing emissions-	50
12.1 Evaluating measured value blocks, display groups 70...79 -Reducing emissions-	50
13 Evaluating measured value blocks, display group 100 -Readiness code-	51
13.1 Evaluating measured value blocks, display group 100 -Readiness code-	51
24 - Mixture preparation, Injection	53
1 Servicing injection system	53
1.1 Servicing injection system	53
1.2 Fitting locations overview	53
1.3 General notes on injection	57
1.4 Removing and installing parts of the injection system	59
1.5 Dismantling and assembling intake manifold	68
1.6 Dismantling and assembling fuel rail with injectors	71
1.7 Dismantling and assembling air cleaner	74



1.8	Safety precautions	78
1.9	Rules for cleanliness	79
1.10	Technical data	79
2	Checking components	80
2.1	Checking components	80
2.2	Checking Lambda probe heating before catalyst	80
2.3	Checking Lambda probe heating after catalyst	84
2.4	Checking throttle valve control part	87
2.5	Checking intake manifold pressure sender	91
2.6	Checking intake air temperature sender	92
2.7	Checking coolant temperature sender	96
2.8	Checking engine speed sender	101
2.9	Checking injectors	103
2.10	Checking fuel pressure regulator and holding pressure	109
2.11	Checking intake air system for leaks (unmetered air)	113
2.12	Checking intake air preheating	114
2.13	Checking vacuum valve	114
3	Checking functions	116
3.1	Checking functions	116
3.2	Idling check	116
3.3	Checking Lambda probe and Lambda regulation before catalyst	118
3.4	Checking Lambda probe and Lambda regulation after catalyst	123
3.5	Checking ageing of Lambda probe before catalyst	127
3.6	Checking engine operating mode	128
4	Engine control unit	130
4.1	Engine control unit	130
4.2	Checking control unit voltage supply	130
4.3	Procedure after voltage supply open circuit	132
4.4	Replacing engine control unit	133
4.5	Coding engine control unit	134
4.6	Coding variations of engine control unit	135
4.7	Erasing learnt values and adapting engine control unit to throttle valve control part and exhaust gas recirculation valve	135
4.8	Adapting engine control unit to electronic immobilizer	137
5	Checking additional signals	137
5.1	Checking additional signals	137
5.2	Checking speed signal	137
5.3	Checking signal from/to air conditioning system	139
5.4	Checking signal from brake light switch and brake pedal switch	140
5.5	Checking rpm signal	143
5.6	Checking signal from power steering pressure switch	143
5.7	Checking data bus	145
28	- Ignition system	147
1	Servicing ignition system	147
1.1	Servicing ignition system	147
1.2	General notes on ignition system	147
1.3	Removing and installing parts of the ignition system	148
1.4	Safety precautions	151
1.5	Test data, spark plugs	151
1.6	Checking Hall sender	152
1.7	Checking ignition transformer	154
1.8	Checking knock sensor	157
1.9	Check misfiring recognition	159