



## Contents

<b>01 - Self-diagnosis</b> .....	<b>1</b>
<b>1 General to self-diagnosis</b> .....	<b>1</b>
1.1 General to self-diagnosis .....	1
1.2 Features of self-diagnosis .....	1
1.3 Technical data of self-diagnosis .....	1
1.4 Significance of EPC warning lamp (fault lamp for electronic accelerator) in dash panel insert .....	2
1.5 Significance of exhaust emissions warning lamp .....	3
1.6 Connecting fault reader .....	4
<b>2 Fault memory</b> .....	<b>7</b>
2.1 Fault memory .....	7
2.2 Automatic test sequence for interrogating all fault memories .....	7
2.3 Interrogating and erasing engine control unit fault memory .....	8
<b>3 Fault table: SAE P0 codes</b> .....	<b>9</b>
3.1 Fault table: SAE P0 codes .....	9
<b>4 Fault table: SAE P1 codes</b> .....	<b>14</b>
4.1 Fault table: SAE P1 codes .....	14
<b>5 Final control diagnosis</b> .....	<b>22</b>
5.1 Final control diagnosis .....	22
5.2 Performing final control diagnosis .....	22
<b>6 Readiness code</b> .....	<b>26</b>
6.1 Readiness code .....	26
6.2 Reading readiness code .....	26
6.3 Generating readiness code .....	27
<b>7 Measured value blocks</b> .....	<b>32</b>
7.1 Measured value blocks .....	32
7.2 Safety precautions .....	32
7.3 Read measured value block .....	32
<b>8 Evaluating measured value blocks, display groups 0...9 -Basic functions-</b> .....	<b>33</b>
8.1 Evaluating measured value blocks, display groups 0...9 -Basic functions-	33
<b>9 Evaluating measured value blocks, display groups 10...29 -Ignition-</b> .....	<b>37</b>
9.1 Evaluating measured value blocks, display groups 10...29 -Ignition-	37
<b>10 Evaluating measured value blocks, display groups 30...49 -Lambda regulation-</b> .....	<b>41</b>
10.1 Evaluating measured value blocks, display groups 30...49 -Lambda regulation-	41
<b>11 Evaluating measured value blocks, display groups 50...69 -Speed regulation-</b> .....	<b>47</b>
11.1 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	47
<b>12 Evaluating measured value blocks, display groups 91...95 -Performance increase-</b> .....	<b>51</b>
12.1 Evaluating measured value blocks, display groups 91...95 -Performance increase-	51
<b>13 Evaluating measured value blocks, display groups 120...129 -Communication-</b> .....	<b>53</b>
13.1 Evaluating measured value blocks, display groups 120...129 -Communication-	53
<b>24 - Mixture preparation, Injection</b> .....	<b>54</b>
<b>1 Servicing injection system</b> .....	<b>54</b>
1.1 Servicing injection system .....	54
1.2 Fitting locations overview .....	54
1.3 General notes on injection .....	60
1.4 Removing and installing parts of the injection system .....	61
1.5 Dismantling and assembling intake manifold .....	68
1.6 Dismantling and assembling fuel rail with injectors .....	71
1.7 Dismantling and assembling air cleaner .....	74
1.8 Safety precautions .....	77
1.9 Rules for cleanliness .....	78



1.10	Technical data . . . . .	78
<b>2</b>	<b>Checking components . . . . .</b>	<b>79</b>
2.1	Checking components . . . . .	79
2.2	Checking Lambda probe heating for Lambda probe before catalyst . . . . .	79
2.3	Checking Lambda probe heating for Lambda probe after catalyst . . . . .	82
2.4	Checking throttle valve control part . . . . .	85
2.5	Checking intake manifold pressure sender . . . . .	89
2.6	Checking intake air temperature sender . . . . .	90
2.7	Checking coolant temperature sender . . . . .	94
2.8	Checking engine speed sender . . . . .	98
2.9	Checking injectors . . . . .	100
2.10	Checking fuel pressure regulator and holding pressure . . . . .	107
2.11	Checking intake air system for leaks (unmetered air) . . . . .	111
<b>3</b>	<b>Checking functions . . . . .</b>	<b>112</b>
3.1	Checking functions . . . . .	112
3.2	Idling check . . . . .	112
3.3	Checking Lambda probe and Lambda regulation before catalyst . . . . .	113
3.4	Checking Lambda probe and Lambda regulation after catalyst . . . . .	118
3.5	Checking engine operating mode . . . . .	122
<b>4</b>	<b>Engine control unit . . . . .</b>	<b>124</b>
4.1	Engine control unit . . . . .	124
4.2	Function . . . . .	124
4.3	Checking control unit voltage supply . . . . .	124
4.4	Replacing engine control unit . . . . .	126
4.5	Coding engine control unit . . . . .	127
4.6	Coding variations of engine control unit . . . . .	128
4.7	Erasing learnt values and adapting engine control unit to throttle valve control part . . . . .	128
4.8	Adapting engine control unit to electronic immobilizer . . . . .	130
<b>5</b>	<b>Checking additional signals . . . . .</b>	<b>132</b>
5.1	Checking additional signals . . . . .	132
5.2	Checking speed signal . . . . .	132
5.3	Checking engine speed signal . . . . .	134
5.4	Checking signal from/to air conditioning system . . . . .	134
5.5	Checking signal from clutch pedal switch . . . . .	138
5.6	Checking signal from brake light switch and brake pedal switch . . . . .	140
5.7	Checking matching resistor of data bus . . . . .	143
<b>28</b>	<b>- Ignition system . . . . .</b>	<b>145</b>
<b>1</b>	<b>Servicing ignition system . . . . .</b>	<b>145</b>
1.1	Servicing ignition system . . . . .	145
1.2	General notes on ignition system . . . . .	145
1.3	Removing and installing parts of the ignition system . . . . .	146
1.4	Safety precautions . . . . .	148
1.5	Test data, spark plugs . . . . .	149
1.6	Checking Hall sender . . . . .	150
1.7	Checking ignition transformer . . . . .	151
1.8	Checking knock sensor . . . . .	155
1.9	Check misfiring recognition . . . . .	158