



Contents

00 - Technical data	1
1 General information	1
1.1 Notes concerning odours in air conditioned vehicles	1
1.2 Notes for vehicles with a start/stop system	1
1.3 Notes on repair work to vehicles with air conditioning and on handling refrigerant	2
1.4 Procedure when checking and adjusting components	2
1.5 Type plates	3
2 Safety information	4
2.1 Safety precautions when handling refrigerants	4
2.2 Safety measures when working on vehicles with a start/stop system	4
3 Repair instructions	5
3.1 Repair work on refrigerant circuit which may be performed only in appropriate workshops by specially trained mechanics	5
4 Technical data	7
4.1 Capacities for refrigerant R134a	7
4.2 Refrigerant oil	7
4.3 Oil distribution	7
80 - Heating	8
1 Overview of fitting locations - heating	8
1.1 Overview of fitting locations - components located in front section of passenger compartment	8
2 Heater	10
2.1 Removing and installing fresh air blower V2	10
2.2 Removing and installing fresh air blower series resistor with overheating fuse N24	10
2.3 Removing and installing dust and pollen filter	10
2.4 Removing and installing heater unit	10
2.5 Dismantling and assembling heater unit	12
2.6 Assembly overview - heat exchanger	14
2.7 Removing and installing heat exchanger	14
2.8 Removing and installing auxiliary air heater element Z35	16
2.9 Checking auxiliary air heater element Z35	17
3 Control motors	21
3.1 Removing and installing air distribution flap actuator	21
3.2 Removing and installing temperature flap actuator	22
4 Air duct	26
4.1 Removing and installing centre vent	26
4.2 Removing vents on driver or front passenger sides	26
4.3 Removing and installing left footwell vent	26
4.4 Removing and installing right footwell vent	26
4.5 Removing and installing rear air duct	26
4.6 Checking forced ventilation for passenger compartment	26
5 Operating and display unit	27
5.1 Removing and installing operating and display unit	27
5.2 Pin assignment for multi-pin connectors on back of controls for heated and fresh air	28
5.3 Removing and installing flexible shafts, checking	28
87 - Air conditioning system	30
1 Overview of fitting locations - air conditioning system	30
1.1 Overview of fitting locations - components located in front section of passenger compartment	30
2 Refrigerant circuit	34



2.1	Required special tools, workshop equipment, testers, measuring instruments and auxiliary items	34
2.2	System overview - refrigerant circuit	35
2.3	Removing and installing evacuating and charging valves on low and high-pressure side	37
2.4	Removing and installing high-pressure sender G65	38
2.5	Removing and installing condenser	40
2.6	Removing and installing desiccant cartridge	42
2.7	Removing and installing expansion valve	44
3	Air conditioner compressor	47
3.1	Assembly overview - drive unit of air conditioner compressor	47
3.2	Assembly overview - Denso pulley	48
3.3	Removing and installing air conditioner compressor	48
3.4	Removing and installing air conditioning system magnetic clutch N25	54
3.5	Checking high-pressure safety valve on air conditioner compressor	55
3.6	Removing and installing ancillary bracket for air conditioner compressor	56
4	Control motors	57
4.1	Removing and installing temperature flap control motor V68	57
4.2	Removing and installing centre flap control motor V70	59
4.3	Removing and installing air flow flap control motor V71	61
4.4	Removing and installing defroster flap control motor V107 and temperature flap control motor V68	63
4.5	Removing and installing fresh air and air recirculation flap control motor V154	67
4.6	Locally manufacturing an adapter cable to activate control motors	69
5	Front heater and air conditioning unit	70
5.1	Removing and installing heater and air conditioning unit	70
5.2	Dismantling and assembling heater and air conditioning unit	75
5.3	Removing and installing fresh air blower V2	83
5.4	Removing and installing fresh air blower series resistor with overheating fuse N24	86
5.5	Removing and installing dust and pollen filter	87
5.6	Dismantling and assembling evaporator housing	89
5.7	Checking condensation drain	91
5.8	Removing and installing fresh air blower control unit J126	92
5.9	Removing and installing evaporator output temperature sender G263	93
6	Air duct	95
6.1	Removing and installing centre vent	95
6.2	Removing vents on driver or front passenger sides	95
6.3	Removing and installing left footwell vent	96
6.4	Removing and installing right footwell vent	97
6.5	Removing and installing rear air duct	97
6.6	Checking forced ventilation for passenger compartment	98
7	Operating and display unit	99
7.1	Overview of fitting locations - operating and display unit	99
7.2	Removing and installing operating and display unit	103
7.3	Multi-pin connector pin assignment on back of operating and display unit	105
7.4	Removing and installing flexible shaft	108
8	Other controlling and regulating components	109
8.1	Removing and installing centre vent temperature sender G191	109
8.2	Removing and installing footwell vent temperature sender G192	110
8.3	Removing and installing sunlight penetration photosensor G107	110
8.4	Removing and installing radiator fan control unit J293	111