



Contents

00 - Technical data	1
1 Safety information	1
1.1 General safety notes	1
1.2 Safety measures for working on vehicles with high-voltage system	2
1.3 Safety precautions when working on vehicles with combustion engine	3
1.4 Safety precautions when working on the fuel system	5
1.5 Safety precautions when working on air conditioners	5
1.6 Safety precautions when working on vehicles with auxiliary/supplementary heater	6
1.7 Safety precautions when using testing and measuring instruments during a road test	6
1.8 Safety precautions when working on passenger protection systems	6
1.9 Safety precautions when working with chemical substances	7
1.10 Safety precautions when working with pressurised gas containers	8
2 Repair notes	9
2.1 Laws, specifications, guidelines and risk assessments	9
2.2 Notes on the application of the workshop manual	9
2.3 Spare parts, servicing materials and consumables	10
2.4 Replacement parts, servicing materials and consumables - vehicles with combustion engine	12
2.5 Transport and storage	12
2.6 Qualification	12
2.7 Environmental protection	13
2.8 Rules for cleanliness	13
2.9 Identification labels	13
2.10 Bolts and nuts	14
2.11 Using power tools	14
2.12 Contact corrosion	15
2.13 Gaskets, seals	15
2.14 Disconnecting electrical connectors	16
2.15 Routing and attachment of lines	16
2.16 Working on refrigerant circuit	17
2.17 Refrigerant and refrigerant oil	18
3 Identification	20
3.1 Label for refrigerant circuit	20
4 Technical data	21
4.1 Refrigerant capacities	21
4.2 Refrigerant oil capacities	21
5 Basic technical and physical principles	22
5.1 Physical properties	22
87 - Air conditioning system	24
1 Safety information	24
2 Refrigerant circuit	25
2.1 System overview - refrigerant circuit	25
2.2 General description - refrigerant circuit components	29
2.3 Locating leaks	30
2.4 Renewing components	37
2.5 Cleaning refrigerant circuit	44
2.6 Principle circuit diagrams for cleaning refrigerant circuit	47
2.7 Principle circuit diagram - cleaning electrically powered air conditioner compressor	51
2.8 Adapter for setting up flushing circuits	53
3 Working with air conditioner service station	81
3.1 Connecting air conditioner service station to refrigerant circuit	81



3.2	Performing gas analysis of refrigerant	82
3.3	Discharging refrigerant circuit	82
3.4	Evacuating refrigerant circuit	84
3.5	Filling refrigerant circuit	86
3.6	Starting up air conditioner after charging	87
3.7	Disconnecting air conditioner service station from refrigerant circuit	87
3.8	Filling reservoir with refrigerant	88
3.9	Emptying air conditioner service station	88
3.10	Cleaning electrically driven air conditioner compressor	88
3.11	Cleaning refrigerant circuit	89
3.12	Decanting contaminated refrigerant into recycling cylinder for analysis, treatment or disposal	91