



Contents

00 - Technical data	1
1 Notes on safety	1
1.1 Safety precautions when working on vehicles with high-voltage system	1
1.2 Safety precautions during a road test using test and measuring equipment	2
2 Repair instructions	3
2.1 Gaskets and seals	3
2.2 Nuts and bolts	3
2.3 Electrical components	3
3 Evaluating accident vehicles	4
3.1 Checklist for evaluating running gear on accident vehicles	4
40 - Front suspension	6
1 Front axle	6
1.1 Overview of fitting locations – front axle	6
2 Front axle carrier	7
2.1 Assembly overview – front axle carrier	7
2.2 Removing and installing front axle carrier	8
2.3 Assembly overview - anti-roll bar	12
2.4 Removing and installing anti-roll bar	13
2.5 Removing and installing coupling rod	14
3 Suspension strut, upper suspension link	16
3.1 Assembly overview - suspension strut, upper suspension link	16
3.2 Removing and installing suspension strut	16
3.3 Removing and installing upper links	20
4 Lower suspension link, swivel joint	23
4.1 Assembly overview - lower suspension link, swivel joint	23
4.2 Removing and installing lower suspension link	23
5 Wheel bearing assembly	27
5.1 Assembly overview - wheel bearing assembly	27
5.2 Removing and installing wheel bearing housing	28
5.3 Removing and installing wheel bearing unit	30
5.4 Repairing wheel bearing unit	32
42 - Rear suspension	36
1 Rear axle	36
1.1 Overview - rear axle	36
2 Anti-roll bar	37
2.1 Assembly overview - anti-roll bar	37
2.2 Removing and installing anti-roll bar	37
2.3 Removing and installing coupling rod	38
3 Lower suspension link, swivel joint	40
3.1 Assembly overview - suspension link	40
3.2 Removing and installing suspension link	41
4 Suspension strut, shock absorber, spring	44
4.1 Assembly overview - suspension strut, shock absorber, spring	44
4.2 Removing and installing suspension strut	44
5 Wheel bearing assembly	47
5.1 Assembly overview - wheel bearing assembly	47
5.2 Removing and installing wheel bearing unit	47
6 Drive shaft	50
6.1 Assembly overview - drive shaft	50



6.2	Removing and installing drive shaft	50
44	- Wheels, tyres, vehicle geometry	53
1	Wheels, tyres	53
1.1	Wheel change	53
1.2	Specified torque for wheel bolts	54
1.3	Pressing tyre off wheel rim	59
2	Tyre pressure monitor	64
2.1	System description – Tyre Pressure Monitoring System	64
3	Wheel alignment	65
3.1	Notes for wheel alignment	65
3.2	Test prerequisites	65
3.3	Test preparations	65
3.4	Specified values for wheel alignment	66
3.5	Necessity of wheel alignment	66
3.6	Adjusting camber at front axle	67
3.7	Adjusting camber on rear axle	68
3.8	Adjusting rear axle toe	69
3.9	Adjusting front axle toe	71
3.10	Setting vehicle to initial position for wheel alignment	72
4	Vibration due to wheels/tyres - causes and rectification	76
4.1	Balancing wheel	76
4.2	Checking radial and lateral run-out of wheels and tyres	78
4.3	Checking radial and lateral run-out on wheel rim	79
4.4	Matching wheels and tyres	79
4.5	Determining flat spots on tyres	80
48	- Steering	82
1	Steering wheel	82
1.1	Assembly overview - steering wheel	82
1.2	Removing and installing steering wheel	82
2	Steering column	84
2.1	Assembly overview - steering column	84
2.2	Checking steering column for damage	85
2.3	Handling and transporting steering column	85
2.4	Removing and installing steering column	86
2.5	Removing and installing control unit for electronic steering column lock J764	90
3	Steering rack	92
3.1	Assembly overview - steering rack	92
3.2	Removing and installing steering rack	93