

Contents

24 - Mixture preparation - injection	1
1 Safety precautions and rules for cleanliness	1
1.1 General notes on self-diagnosis	1
1.2 Safety precautions when using testers and measuring instruments during a road test	1
1.3 Rules for cleanliness and instructions for working on fuel system	2
1.4 Checking vacuum system	2
2 Injection system	3
2.1 Technical data	3
2.2 Overview of fitting locations - injection system	3
3 Intake manifold	7
3.1 Exploded view - intake manifold	7
3.2 Removing and installing intake manifold	7
4 Injectors	10
4.1 Removing and installing injectors	10
5 Checking fuel system	11
5.1 Checking injection quantity and spray pattern of injectors; checking for leaks	11
5.2 Fuel system without return line	12
5.3 Checking system pressure and residual pressure	15
6 Lambda probes	19
6.1 Removing and installing Lambda probe G39 / Lambda probe after catalytic converter G130	20
7 Engine control unit	22
7.1 Wiring and component check with test box V.A.G 1598/31	22
7.2 Removing and installing engine control unit	22
28 - Ignition system	27
1 General notes and safety precautions	27
1.1 General notes on ignition system	27
1.2 Safety precautions	27
1.3 Technical data	28
1.4 Exploded view - ignition system	28
1.5 Removing and installing ignition coils with output stages	29
1.6 Removing and installing knock sensor 1 G61 and knock sensor 2 G66	30