

Contents

00 - Technical data	1
1 Safety precautions	1
1.1 Safety information	1
2 Repair instructions	2
2.1 Repair instructions	2
2.2 Refrigerant and refrigerant oil	2
3 Identification	4
3.1 Label for refrigerant circuit	4
4 Technical data	5
4.1 Refrigerant capacities	5
4.2 Refrigerant oil capacities	5
5 Basic technical and physical principles	6
5.1 Physical properties	6
87 - Air conditioning system	8
1 Safety and repair instructions	8
1.1 Safety information	8
1.2 Repair instructions	8
2 Refrigerant circuit	9
2.1 System overview - refrigerant circuit	9
2.2 Cleaning refrigerant circuit	9
2.3 Block diagram for cleaning refrigerant circuit	10
2.4 Block diagram for cleaning electrically driven air conditioner compressor	13
3 Renewing components	15
3.1 Renewing components	15
3.2 Renewing air conditioner compressor	18
3.3 Renewing receiver	22
4 Locating leaks	23
4.1 General notes on locating leaks in refrigerant circuit	23
4.2 Locating leaks using vacuum test	23
4.3 Locating leaks with pressure test using nitrogen	23
4.4 Locating leaks using forming gas	25
4.5 Locating leaks using electronic leak detector	26
4.6 Locating leaks using UV leak detection system	27
5 Working with air conditioner service station	30
5.1 Connecting air conditioner service station to refrigerant circuit	30
5.2 Performing gas analysis on refrigerant - R1234yf	30
5.3 Discharging refrigerant circuit	32
5.4 Evacuating refrigerant circuit	33
5.5 Charging refrigerant circuit	36
5.6 Starting up air conditioner after charging	37
5.7 Disconnecting air conditioner service station from refrigerant circuit	38
5.8 Filling reservoir with refrigerant	39
5.9 Discharging air conditioner service station	39
5.10 Cleaning electrically driven air conditioner compressor	39
5.11 Cleaning refrigerant circuit	40
5.12 Decanting contaminated refrigerant into recycling cylinder for analysis, treatment or disposal - R1234yf	42