

Contents

00 - Technical data	1
1 Safety information	1
1.1 Safety precautions when working on air conditioners	1
1.2 Safety measures when handling refrigerant	1
1.3 Safety precautions when working on vehicles with start/stop system	2
1.4 Safety precautions when handling air conditioner service stations	2
1.5 Safety precautions when handling refrigerant R1234yf and R134a	2
1.6 Safety precautions when working on vehicles with high-voltage system	3
1.7 Safety precautions when working in the vicinity of high-voltage components	3
1.8 Safety precautions when using testers and measuring instruments during a road test	4
2 Laws and regulations	5
2.1 Legal regulations and standards	5
2.2 Charging refrigerant circuit with other refrigerants	6
2.3 Occupational health & safety	6
3 Repair instructions	7
3.1 Rules for cleanliness	7
3.2 Refrigerant circuit seals	7
3.3 Refrigerant and refrigerant oil	8
3.4 Handling pressure vessels	10
3.5 Handling refrigerant	11
4 Identification	13
4.1 Label for refrigerant circuit	13
5 Technical data	14
5.1 Refrigerant capacities	14
5.2 Refrigerant oil capacities	14
5.3 Safety data sheets	14
6 Basic technical and physical principles	15
6.1 Principles of air conditioning systems	15
6.2 Physical properties	21
6.3 Product properties	26
6.4 Function of air conditioner	27
6.5 Other reference material	28
87 - Air conditioning system	29
1 Refrigerant circuit	29
1.1 System overview - refrigerant circuit	29
1.2 General description - refrigerant circuit components	29
1.3 Possible complaints	41
1.4 Locating leaks	43
1.5 Renewing components	47
1.6 Cleaning refrigerant circuit	52
1.7 Checking pressure values with a pressure gauge	58
2 Working with air conditioner service station	60
2.1 General notes on working with air conditioner service station	60
2.2 Connecting air conditioner service station to refrigerant circuit	62
2.3 Discharging refrigerant circuit	63
2.4 Evacuating refrigerant circuit	65
2.5 Charging refrigerant circuit	68
2.6 Starting up air conditioner after charging	70
2.7 Switching off air conditioner service station and disconnecting from refrigerant circuit	71
2.8 Charging internal pressure vessel with refrigerant	72
2.9 Connecting and disconnecting bottle of refrigerant	72



2.10	Discharging air conditioner service station	72
2.11	Cleaning refrigerant circuit	73
2.12	Decanting contaminated refrigerant into recycling cylinder for analysis, treatment or disposal	73
3	Test equipment and tools	74
3.1	Tools and materials available from distribution centre or importer	74
3.2	Commercially available tools and materials	74
3.3	Tools you can make yourself	75