



Contents

00 - Technical data	1
1 Safety and repair instructions	1
1.1 Safety information	1
1.2 Repair instructions	1
2 Repair instructions	2
2.1 Refrigerant and refrigerant oil	2
3 Identification	3
3.1 Label for refrigerant circuit	3
4 Technical data	4
4.1 Refrigerant capacities	4
4.2 Refrigerant oil capacities	4
5 Basic technical and physical principles	5
5.1 Physical properties	5
87 - Air conditioning system	7
1 Safety and repair instructions	7
1.1 Safety information	7
1.2 Repair instructions	7
2 Refrigerant circuit	8
2.1 System overview - refrigerant circuit	8
2.2 Cleaning refrigerant circuit	8
2.3 Principle circuit diagram for cleaning refrigerant circuit	9
2.4 Block diagram for cleaning electrically driven air conditioner compressor	12
2.5 Adapters for setting up flushing circuits	14
3 Renewing components	16
3.1 Renewing components	16
3.2 Renewing air conditioner compressor	19
3.3 Renewing receiver	23
4 Locating leaks	25
4.1 General notes on locating leaks in refrigerant circuit	25
4.2 Locating leaks using vacuum test	25
4.3 Locating leaks with pressure test using nitrogen	25
4.4 Locating leaks using forming gas	27
4.5 Locating leaks using electronic leak detector	28
4.6 Locating leaks using UV leak detection system	29
5 Working with air conditioner service station	32
5.1 Connecting air conditioner service station to refrigerant circuit	32
5.2 Performing gas analysis on refrigerant - R1234yf	32
5.3 Discharging refrigerant circuit	34
5.4 Evacuating refrigerant circuit	36
5.5 Charging refrigerant circuit	38
5.6 Starting up air conditioner after charging	40
5.7 Disconnecting air conditioner service station from refrigerant circuit	41
5.8 Filling reservoir with refrigerant	41
5.9 Discharging air conditioner service station	41
5.10 Cleaning electrically driven air conditioner compressor	42
5.11 Cleaning refrigerant circuit	43
5.12 Decanting contaminated refrigerant into recycling cylinder for analysis, treatment or disposal - R1234yf	45