



Contents

00 - Technical data	1
1 Repair instructions	1
1.1 Refrigerant and refrigerant oil	1
2 Identification	3
2.1 Label for refrigerant circuit	3
3 Technical data	4
3.1 Refrigerant capacities	4
3.2 Refrigerant oil capacities	4
4 Basic technical and physical principles	5
4.1 Physical properties	5
87 - Air conditioning system	7
1 Safety and repair instructions	7
1.1 Safety information	7
1.2 Repair instructions	7
2 Refrigerant circuit	8
2.1 System overview - refrigerant circuit	8
2.2 Cleaning refrigerant circuit	10
2.3 Principle circuit diagram for cleaning refrigerant circuit	13
2.4 Block diagram for cleaning electrically driven air conditioner compressor	18
2.5 Adapters for setting up flushing circuits	20
2.6 Adapter for cleaning refrigerant circuit	21
2.7 Adapter for cleaning refrigerant circuit, vehicles with high-voltage system	23
3 Renewing components	26
3.1 Renewing components	26
3.2 Renewing air conditioner compressor	29
3.3 Renewing receiver	33
4 Locating leaks	34
4.1 General notes on locating leaks in refrigerant circuit	34
4.2 Locating leaks using vacuum test	34
4.3 Locating leaks with pressure test using nitrogen	34
4.4 Locating leaks using forming gas	36
4.5 Locating leaks using electronic leak detector	37
4.6 Locating leaks using UV leak detection system	38
5 Working with air conditioner service station	41
5.1 Connecting air conditioner service station to refrigerant circuit	41
5.2 Performing gas analysis on refrigerant - R1234yf	41
5.3 Discharging refrigerant circuit	43
5.4 Evacuating refrigerant circuit	44
5.5 Charging refrigerant circuit	47
5.6 Starting up air conditioner after charging	48
5.7 Disconnecting air conditioner service station from refrigerant circuit	49
5.8 Filling reservoir with refrigerant	50
5.9 Discharging air conditioner service station	50
5.10 Cleaning electrically driven air conditioner compressor	50
5.11 Cleaning refrigerant circuit	51
5.12 Decanting contaminated refrigerant into recycling cylinder for analysis, treatment or disposal - R1234yf	53