



Contents

00 - Technical data	1
1 Safety information	1
1.1 Safety regulations for working on fuel supply	1
1.2 Safety precautions when using testers and measuring instruments during a road test	2
1.3 Safety measures when working on vehicles with a start/stop system	2
2 Identification	4
2.1 Engine number/engine data	4
3 General information	5
3.1 Rules for cleanliness when working on auxiliary/supplementary heater and fuel system	5
20 - Fuel supply system	6
1 Procedure in event of misfuelling	6
1.1 Step 1 (Engine was started with incorrect fuel)	6
1.2 Step 2 (Engine was not started with incorrect fuel)	8
1.3 Step 3 (There are filings in fuel delivery unit and fuel tank)	11
1.4 Step 4 (There are no filings in fuel delivery unit and fuel tank)	11
1.5 Step 5 (There are filings in high-pressure pump)	12
1.6 Step 6 (There are no filings in high-pressure pump)	12
2 Fuel	14
2.1 Assembly overview - fuel tank	14
2.2 Removing and installing fuel tank	15
2.3 Emptying fuel tank	22
3 Fuel delivery unit, fuel gauge sender	28
3.1 Assembly overview - fuel delivery unit/fuel gauge sender	28
3.2 Removing and installing fuel delivery unit, fuel gauge sender	29
3.3 Removing and installing fuel gauge sender G	34
4 Plug-in connectors	36
4.1 Separating plug-in connectors	36
5 Fuel filter	40
5.1 Assembly overview - fuel filter	40
5.2 Removing and installing fuel filter	41
5.3 Fuel hoses in the engine compartment	42
6 Accelerator pedal	43
6.1 Assembly overview - accelerator module	43
7 Fuel pump	44
7.1 Checking fuel system pressurisation pump G6	44